



GPON OLT (access and aggregation node)

MA4000-PX

User manual

Firmware version 3.34.1

Contents

1	Introduction	9
2	Product Description	10
2.1	Purpose	10
2.2	Use cases	10
3	Delivery package	11
4	MA4000-PX access node hardware	12
4.1	Chassis	12
4.2	PP4X central switch module	16
4.3	GPON PLC8 Interface Module.....	20
5	MA4000-PX architecture	26
5.1	PP4X central switch module	26
5.2	GPON PLC8 Interface Module.....	28
6	Installation and connection.....	30
6.1	General requirements	30
6.2	Equipment installation.....	31
6.2.1	Preparing for installation.....	31
6.2.2	Position and mounting requirements	32
6.2.3	Installing into a rack.....	33
6.2.4	Laying and connecting cables.....	33
7	Connecting to the CLI	35
7.1	Introduction	35
7.2	Connecting to the CLI via COM port	35
7.3	Connecting to the CLI via Telnet.....	36
7.4	Connecting to the CLI via Secure Shell.....	38
8	Getting started with the CLI.....	40
8.1	Introduction	40
8.2	Command line operation rules.....	40
8.3	CLI commands structure.....	41
9	Configuring access node.....	45
9.1	Configuration structure	45
9.1.1	Introduction	45
9.1.2	Configuration structure	45
9.2	Configuration lifecycle.....	45
9.3	Creating a configuration backup.....	46
9.4	Recovering configuration	47

9.5	Reseting configuration	47
10	Network settings.....	48
10.1	Introduction	48
10.2	Configuring network parameters	48
11	Managing users	49
11.1	Introduction	49
11.2	Users list preview.....	50
11.3	Adding a new user	50
11.4	Changing user password.....	50
11.5	Viewing and changing user access rights.....	51
11.6	Deleting a user	51
11.7	Configuring user session.....	51
11.8	Configuring user authentication	52
11.9	Network access restriction	52
12	Service configuration.....	53
12.1	SNMP configuration	53
12.2	System log configuration	54
12.3	SSH configuration.....	54
12.4	Telnet configuration.....	55
12.5	Tacacs+ configuration.....	55
12.6	Radius configuration.....	55
12.7	SNTP configuration	56
12.8	Daylight saving change configuration	56
13	VLAN Configuration	57
13.1	Introduction	57
13.2	Adding a VLAN.....	57
13.3	Configuring VLAN	57
13.4	Deleting VLAN	58
14	PP4X stacking configuration.....	59
15	Interface configuration	60
15.1	Introduction	60
15.2	Ethernet interface configuration	62
15.3	GPON interface configuration.....	63
16	Isolation group configuration.....	64
16.1	Introduction	64
16.2	Isolation group configuration.....	64
17	SELECTIVE Q-IN-Q configuration	66

17.1	Introduction	66
17.2	SELECTIVE Q-IN-Q configuration	66
18	QoS configuration	67
19	LAG configuration	69
19.1	Introduction	69
19.2	LAG configuration	71
20	Spanning Tree configuration.....	73
20.1	Introduction	73
20.2	Spanning Tree configuration.....	73
21	Dual Homing configuration	75
21.1	Introduction	75
21.2	Dual Homing configuration	75
22	LLDP configuration	76
22.1	Introduction	76
22.2	LLDP configuration	76
23	Multicast configuration	77
23.1	Introduction	77
23.2	Multicast configuration	78
23.3	IPv6 Multicast configuration.....	79
24	DHCP Relay Agent configuration.....	81
24.1	Introduction	81
24.2	DHCP Relay Agent profiles management	82
24.3	DHCP Relay Agent profiles configuration	83
24.4	DHCPv6 Relay Agent profiles management.....	84
24.5	DHCPv6 Relay Agent profiles configuration	85
24.6	Broadcast-unicast relay configuration	85
25	PPPoE Intermediate Agent configuration	87
25.1	Introduction	87
25.2	PPPoE Intermediate Agent profiles configuration.....	88
26	IP Source Guard configuration.....	89
26.1	Introduction	89
26.2	IP Source Guard configuration.....	89
27	Configuring PLC line board traffic filtering.....	91
28	Service models.....	92
28.1	Introduction	92
28.1.1	VLAN for Subscriber architecture.....	92
28.1.2	VLAN for Service architecture.....	92

28.2	Operating principle.....	93
28.2.1	Model 1	94
28.2.2	Model 2.....	95
28.2.3	Model 3.....	95
28.2.4	Summary conversion table.....	96
28.3	Model configuration.....	97
29	ONT configuration	98
29.1	Introduction	98
29.2	General principles of configuration	98
29.3	ONT profiles configuration.....	99
29.3.1	Cross-connect profile configuration.....	99
29.3.2	DBA profile configuration	99
29.3.3	Shaper profile configuration.....	99
29.3.4	Ports profile configuration	99
29.3.5	Management profile configuration	100
29.4	ONT configuration procedure	100
29.4.1	Model 1	103
29.4.2	Model 2.....	108
29.4.3	Model 3.....	108
29.5	Tunnelling configuration.....	112
30	DBA configuration.....	116
30.1	Introduction	116
30.2	DBA profiles assignment.....	117
30.2.1	Services in different T-CONTs.....	117
30.2.2	Services in one T-CONT.....	118
30.2.3	One profile for multiple ONTs	119
30.2.4	Profiles assignment example	119
30.3	DBA parameters configuration	121
30.3.1	T-CONT type 1 configuration.....	121
30.3.2	T-CONT type 2 configuration.....	122
30.3.3	T-CONT type 3 configuration.....	123
30.3.4	T-CONT type 4 configuration.....	124
30.3.5	T-CONT type 5 configuration.....	124
31	RG ONT configuration.....	126
31.1	Introduction	126
31.2	Mixed configuration.....	127
32	High Speed Internet configuration.....	132

33	Multicast configuration	133
33.1	Introduction	133
33.2	Model 1 Multicast configuration.....	133
33.3	Model 3 Multicast configuration.....	136
34	VoIP configuration	139
35	TR-069 management configuration.....	140
35.1	Introduction	140
35.2	Configuration of a TR-069 Inband management	140
35.3	Configuration of a TR-069 OOB management channel	141
35.4	TR-069 client parameters configuration.....	143
36	ONT configuration templates.....	144
36.1	Introduction	144
36.2	Preparing ONT configuration template	144
36.3	ONT configuration template assignment.....	144
36.4	ONT configuration preview with templates.....	145
37	ONT licensing.....	148
37.1	Introduction	148
37.2	Loading a license file to OLT	148
38	ONT ports management.....	150
38.1	Introduction	150
38.2	Managing ONT Ethernet ports	150
38.3	Managing PoE on ONT ports.....	151
38.3.1	Enabling PoE on ONT ports.....	151
38.3.2	Power class control	151
38.3.3	Managing PoE priority	151
39	General information.....	152
39.1	Viewing current access node firmware version.....	152
39.2	View information on access node	152
39.3	Viewing interface modules status	154
39.4	Viewing access node uptime	154
39.5	Checking network connection.....	154
40	Access node operation log.....	155
41	Active alarms log	157
41.1	Introduction	157
41.2	Alarm generation and registration.....	157
41.2.1	Alarm/Event structure	157
41.2.2	Alarms rates	157

41.2.3	Alarms	157
41.2.4	Alarms normalization	159
41.2.5	Notifications.....	160
42	PP4X monitoring.....	163
42.1	PP4X resource status	163
42.2	MAC table preview	165
42.3	PP4X interface status preview.....	168
42.4	PP4X interface statistics preview	169
42.5	Interface mirroring	171
42.5.1	Configuration of the controlled port	171
42.5.2	Configuration of the controlling port	171
43	PLC8 monitoring	172
43.1	GPON OLT state.....	172
43.2	GPON interface state.....	173
43.3	MAC table preview	175
43.4	Statistics for GPON interfaces.....	175
43.5	Statistics for OLT V interfaces.....	176
43.6	Multicast statistics	176
44	ONT monitoring.....	177
44.1	ONT configurations list.....	177
44.2	List of empty ONT configurations.....	177
44.3	List of connected ONTs.....	177
44.4	List of disconnected ONTs.....	179
44.5	ONT statistics	179
44.6	ONT bit error rate	181
45	PWR IN modules replacement	182
46	MFC module replacement	183
47	PP4X central switch module replacement.....	184
48	GPON PLC8 interface module replacement.....	185
49	SFP transceivers replacement	187
50	PP4X firmware update.....	188
50.1	Firmware Update via CLI	188
50.1.1	Introduction	188
50.1.2	New firmware version installation procedure	188
50.1.3	Example of the new firmware version installation procedure.....	189
50.2	Firmware update via bootloader (U-Boot)	190
50.2.1	Firmware update via bootloader	190

50.2.2	Possible abnormal situations during the firmware upgrade via bootloader.....	192
51	PP4X firmware emergency recovery	193
52	ONT firmware update	194
52.1	Introduction	194
52.2	Overview	194
52.3	ONT firmware files management.....	195
52.4	ONT firmware manual update.....	195
52.5	ONT firmware auto update configuration	196
52.5.1	ONT auto update modes	196
52.5.2	ONT auto update rules.....	196
53	APPENDIX A. Configuring services on ONT Ericsson, Atron, CIG.....	197
53.1	Introduction	197
53.2	VoIP configuration	197

1 Introduction

MA4000-PX is a multifunctional modular node of subscriber access and aggregation. MA4000-PX is a new-generation device which incorporates various interfaces with a high density of ports for providing broadband service access. GPON technology is used for the subscriber access. ETTH (FTTB) technology is used when the device is in aggregation mode.

MA4000-PX subscriber access and aggregation node allows to create an economically profitable solution and may replace several GPON OLT LTP-8X.

This User Manual describes the purpose, general technical parameters, as well as configuring, monitoring and firmware replacement rules for MA4000-PX access node.

2 Product Description

2.1 Purpose

Multiservice access and aggregation node MA4000-PX is designed to construct GPON-based access networks. The system allows to construct a scalable, fault-resistant 'last mile' networks to ensure the highest safety standards, both in urban and suburban areas. The access node manages subscriber units, traffic switching and connection to the transport network.

The central element of the MA4000-PX is the scalable L2+ Ethernet switch (PP4X), which works in cooperation with various interface modules. PLC8 optical access module is used to connect subscriber devices via GPON technology.

Key advantages of the modular architecture are as follows:

- a step-by-step network upgrade without interruptions;
- high capacity determined by an unblocked switching capacity of a node;
- handling basket modules as an integrated device.

2.2 Use cases

MA4000-PX operates as a subscriber access node. Connection with the subscriber devices is provided by the peripheral modules PLC8 featuring 8 PON ports, each of them allows connecting up to 64 subscribers. Traffic switching and connection to the transport network are ensured by PP4X central processor modules which are connected by the peripheral modules via common high-speed bus of the device. Connection with the higher level equipment is effected by means of 10G(SFP+) interfaces and 1G combined interfaces.




Figure 1 – MA4000-PX subscriber access/aggregation node use case

3 Delivery package

The delivery package is defined in the equipment delivery contract.

The standard delivery package includes:

- MA4000-PX equipment and SPTA set according to an order;
- User manual on CD (optional);
- Technical passport;
- Declaration of conformity.

In addition to MA4000-PX equipment, the delivery package may also include:

- RS-232 connection cable DB9F to DB9F;
- Power cord;
- DB-15M connector of the object communication interface;
- optical transceivers SFP 1Gb;
- optical transceivers SFP+ 10Gb.

4 MA4000-PX access node hardware

This section describes the design of MA4000-PX: it shows an exterior view of the front panel of PP4X Ethernet switch, PLC-8 interface module as well as side panels of a chassis; it describes connectors, LEDs and controls.

4.1 Chassis

MA4000-PX device is metal cased and consists of one 19" chassis with 9U height. The chassis is used for uniting modules of different functional purpose ensuring interaction of modules through high-speed 10 Gbps communication lines as well as for power distribution and supporting and monitoring temperature mode of the entire device.




Figure 2 – Front and rear views of MA4000-PX chassis




Figure 3 – Side view of MA4000-PX chassis

MA4000-PX electric power supply system does not include group devices, which would determine reliability level of the entire system as a whole. The power supply is arranged by the distribution principle – each module has its own power unit. Herewith the chassis operates only as a distributor of power to the modules.

The device has a front-to-rear ventilation system. Air flow diagram is shown in [Figure 4](#).




Figure 4 – Air flow diagram




Figure 5 – Diagram of modules connections in a MA4000 chassis

The following designations are used in [Figure 5](#):

- PLC – GPON interface module;
- PP4X – central switch module;
- Env – chassis controller.

The chassis composition depends on the use case. The chassis features 18 positions for modules installation. PP4X central switch module is mandatory for installation into the chassis. Up to two modules of this type can be installed to ensure the redundancy and increase the system productivity. Two central positions are intended for these modules installation (see [Figure 6](#)).




Figure 6 – MA4000-PX chassis view

The other 16 positions in the chassis are universal – any position may fit a PLC-8 interface module. Installation of the PLC-8 module is described in section [GPON PLC8 interface module replacement](#).

To ensure interaction of modules, a cross-connect module is installed in the chassis. The module organizes interconnections between the central switches and interface modules. Each PP4X module features individual connection to the each interface module and to the neighbour module PP4X. The intermodular connections correspond to the high-speed communication channels operating at 10 Gbps speed. The system architecture shall be considered in detail in section [MA4000-PX architecture](#).

The following elements are located in the left part of the chassis:

1. Signalling connector (Telemetry input). The connector is intended for communication with an object, where the equipment is installed, and can be used for connecting various-purpose sensors with 'dry contacts' type interface as well for connecting different types of actuators.
2. Two power input modules. In order to ensure the required level of reliability, the device is equipped with two power input modules, which can be connected to two different power sources. The modules ensure automatic changeover to the standby power supply in case one of the supplies fails and protection from incorrect connection of the power supply feeders. The modules design allows to replace them in the course of device operation in case of alarm. The device provides for monitoring tools for power supply modules, i.e. input voltage and consumed current.
3. Grounding terminal.

Temperature control system of the device is designed to be used in combination with the air conditioning system of the equipment hall using hot and cold aisles principle. The ventilation system includes three fans arranged on the chassis rear wall (see [Figure 2](#)) and a controller to control the rotational speed of the fans. The fans controller module is installed inside the chassis.

The ventilation system performance is adjustable and can vary within the limits of 7 m³/min to 14 m³/min. The acoustic noise level – not more than 36 dB(A).

Basic technical parameters of the access platform are given in [Table 1](#).

Table 1 – Main Specifications

General parameters	
Types of modules	PP4X – control and switching module PLC8 – 8 linear interfaces GPON 2.5 Gbps
Number of interface modules	up to 16 modules
Bus type and performance	34 × 10GBASE-KX (XAUI), 340 Gbps
Control	
Management interfaces	SNMP, CLI (Telnet, SSH, Serial)
Physical specifications and ambient conditions	
Power voltage	36 .. 72 V
Maximum power consumption	850 W (at full load) ¹ chassis: 35 W PP4X: 70 W PLC8 without SFP ² : 30 W PLC8 with SFP ² : 40 W Fans: 18 W
Weight	25 kg max
Dimensions	480 × 400 × 350 mm
Operating temperature range	-10 to +45 °C
Operating humidity	relative humidity up to 80%
Average lifetime	20 years

¹ The maximum values for each of the modules have been considered when calculating the maximum power consumption at full load.

² Measurements have been made for PLC8 boards, version 2v0.

4.2 PP4X central switch module

Central switch module is the main element of the platform, which generally manages and diagnoses peripheral modules, switching, aggregation and communication interface modules with higher level network equipment. Modules operate in the mode of load sharing and redundancy via two internal 10 Gbps interfaces.

The front panel external view, description of PP4X module connectors, LEDs and controls are shown in [Figure 7](#).




Figure 7 – Front panel external view, description of PP4X module connectors, LEDs and controls

Front panel element		Description
1	Status	Device operation LED
	Alarm	Alarm LED
	Power	Device power LED
	Master	Device operation mode LED (master/slave)
	SSD	SSD data storage device LED
2	10/100/1000 [0 .. 1]	2 ports of Gigabit Ethernet (10/100/1000 Mbps) with RJ-45 connectors
3	[0 .. 5]	6 slots for installing 10GBASE-X(SFP+)/ 1000BASE-X(SFP) SFP transceivers

Front panel element		Description
	Link	Optical interface operation LED
	Speed	Optical interface speed mode LED
4	USB	Connector for connecting additional devices
5	F	Functional key that reboots the device and resets it to the factory default configuration: <ul style="list-style-type: none"> pressing the key for less than 10 seconds reboots the device; pressing the key for more than 10 seconds resets the device to the factory default configuration.
6	Console	RS-232 console port for local management of the device

- ✔ **Two electrical Gigabit Ethernet interfaces with numbers 0, 1 and two optical interfaces with numbers 0, 1 are Combo ports. Combo ports may have only one active interface (electrical or optical) at the same time.**

Technical specifications of the module are given in [Table 2](#).

Table 2 – PP4X module technical specifications

Processor	
Clock frequency	1000 MHz
Core quantity	2
RAM	DDR2 SDRAM 512 MB 800 MHz
Non-volatile memory	1GB NAND Flash 2GB NAND Flash (since version 3v0)
Interfaces	
USB interface	Compatible with USB 2.0 specification
Network interfaces	External connections 4 × 10GBASE-X (SFP+) 2 × (10/100/1000BASE-T/1000BASE-X (SFP)) Intermodular connections 16 × 10G XAUI (10GBASE-KX4)

Optical transceivers	1G SFP, 10G SFP+
Console port	RS-232, 115200 bps
Ethernet switch	
Bandwidth	480 Gbps
MAC table	32K entries
VLAN support	up to 4K in accordance with 802.1Q
Quality of service (QoS)	7 prioritized egress queus per port
Number of ports	24 ports up to 10 Gbps per port
Port modes	Duplex/half-duplex 10/100/1000 Mbps for electrical ports Duplex mode 1/10 Gbps for optical ports
Standards	IEEE 802.3 10BASE-T Ethernet IEEE 802.3u 100BASE-T Fast Ethernet IEEE 802.3ab 1000BASE-T Gigabit Ethernet IEEE 802.3z Fiber Gigabit Ethernet ANSI/IEEE 802.3 NWay auto-negotiation IEEE 802.3x Full Duplex and flow control IEEE 802.3ad Link aggregation IEEE 802.1p Protocol for Traffic Prioritization IEEE 802.1Q Virtual LANs IEEE 802.1ad Provider Bridges (QinQ) IEEE 802.1v VLAN Classification by Protocol and Port IEEE 802.3 ac VLAN tagging IEEE 802.1d MAC bridges IEEE 802.1w Rapid Reconfiguration of Spanning Tree IEEE 802.1s Multiple Spanning Trees IEEE 802.1x Port Based Network Access Control

Maximum power consumption	70 W
---------------------------	------

PP4X module current status is displayed by **Status, Alarm, Power, Master, SSD, Link, Speed** LEDs. A list of LED statuses and the values thereof are shown in the following tables.

Table 3 – Light indication of the module state

LED	LED state	Device state
Status	Solid green	Normal operation
	Green, flashing at 1 second interval	Operation in a limited mode, F button was pressed when starting the device
	Solid red	The device is booting
Alarm	Off	No alarms
	Solid yellow	Non-critical alarm, one or more
	Solid red	Critical module alarm
Power	Solid green	Module power is OK
	Solid red	Failure of one or more module power supply inputs
	Off	Module power supply is not available
Master	Solid green	The device operates as a master device in the chassis
	Off	The device operates as a slave device
SSD	Solid green	Data storage carrier is connected
	Off	Carrier is not connected

Table 4 – Combo-ports 0-1 status light indication

LED	LED state	Device state
Link	Solid green	Connection to an oncoming device is present
	Flashing green	Data is being received or transmitted

LED	LED state	Device state
	Off	Port is not connected
Speed	Solid yellow	1000 Mbps connection is established
	Off	If the Link LED is enabled, it means that connection at speed 10 or 100 Mbps is established

Table 5 – Ports 2-5 status light indication

LED	LED state	Device state
10 Gbps mode		
Link	Solid green	Connection to an oncoming device is present, transmitter is active
	Flashing green	Data transmission process
Speed	Solid yellow	10 Gbps connection to an oncoming device is present
	Flashing yellow	Data reception
Indication in 1 Gbps mode		
Link	Solid green	Connection to an oncoming device is present
	Flashing green	Data exchange
Speed	Off	1 Gbps connection to an oncoming device is present

4.3 GPON PLC8 Interface Module

The PLC8 module is designed to organize broadband access to the data network via GPON technology at speeds of up to 2.5 Gbps in the direction to the user. This module is designed for use on the site of the 'last mile' and enables to connect up to 512 communication terminals (ONT). The front panel external view, description of PLC8 module connectors, LEDs and controls are given in [Figure 8](#).




Figure 8 – Front panel external view, description of PLC8 module connectors, LEDs and controls

Front panel element		Description
1	Status	Device operation LED
	Alarm	Alarm LED
	Power	Device power LED
2	PON [Ch0 .. Ch7]	8 chassis for SFP modules of GPON
	Link	ONT connection LEDs
3	MGMT 10/100/1000	Gigabit Ethernet port (10/100/1000BASE-T) with RJ-45 connector for local control
4	F	Functional key that reboots the device and resets it to the factory default configuration: <ul style="list-style-type: none"> • pressing the key for less than 10 seconds reboots the device • pressing the key for more than 10 seconds resets the device to the factory default configuration
5	Console	RS-232 console port for local control of the device

Table 6 – PLC8 module technical specifications

Processor	
Clock frequency	800 MHz
Core quantity	1
RAM	DDR2 SDRAM 256 MB 800 MHz
Non-volatile memory	32MB Serial Flash
Interface	
Network interfaces	<p>External connections</p> <p>2 × 10G XAUI (10GBASE-KX4)</p> <p>Intermodular connections</p> <p>1 × 10/100/1000BASE-T RJ45 – Management port</p> <p>8 × 2.5 GPON</p>
Console port	RS-232, 115200 bps
SFP PON parameters	
Connector type	SC/UPC
Receiver sensitivity	from -28 to -8 dB
Transmission medium	Single-mode fibre optical cable SMF 9/125, G.652
Optical power budget (up/downstream)	26 dB/24.5 dB
Minimal attenuation upstream/downstream	11 dB/15 dB
Optical emission spectral width upstream/downstream $\Delta\lambda$	1 nm/1 nm
Connection wave length upstream/downstream	1310/1490 nm
Connection speed upstream/downstream	1.25/2.5 Gbps
Splitting ratio	1:4, 1:8, 1:16, 1:32, 1:64

Max. transmission distance	40 km
Ethernet switch	
Switch performance	128 Gbps
MAC table	16K entries
VLAN support	up to 4K in accordance with 802.1Q
Quality of service (QoS)	7 prioritized egress queues per port
Port modes	Duplex/half-duplex mode 10/100/1000 Mbps Duplex mode 10 Gbps for intermodular connections
Standards	<p>IEEE 802.3 10BASE-T Ethernet</p> <p>IEEE 802.3u 100BASE-T Fast Ethernet</p> <p>IEEE 802.3ab 1000BASE-T Gigabit Ethernet</p> <p>IEEE 802.3z Fiber Gigabit Ethernet</p> <p>ANSI/IEEE 802.3 NWay auto-negotiation</p> <p>IEEE 802.3x Full Duplex and flow control</p> <p>IEEE 802.3ad Link aggregation</p> <p>IEEE 802.1p Protocol for Traffic Prioritization</p> <p>IEEE 802.1Q Virtual LANs</p> <p>IEEE 802.1ad Provider Bridges (QinQ)</p> <p>IEEE 802.1v VLAN Classification by Protocol and Port</p> <p>IEEE 802.3 ac VLAN tagging</p> <p>IEEE 802.1d MAC bridges</p> <p>IEEE 802.1w Rapid Reconfiguration of Spanning Tree</p> <p>IEEE 802.1s Multiple Spanning Trees</p> <p>IEEE 802.1x Port Based Network Access Control</p> <p>ITU-T G.984x</p>

Maximum power consumption	PLC8 without SFP ¹ : 30 W PLC8 with SFP ¹ : 40 W
Weight	up to 2.5 kg

¹ Measurements have been made for PLC8 boards, version 2v0.

PLC8 module current status is displayed by **Status, Alarm, Power, Link** LEDs. [Table 7](#) provides possible statuses of LEDs.

Table 7 – light indication of the device

LED	LED state	Device state
Status	Solid green	Normal operation
	Solid red	The device is booting
Alarm	Off	Normal operation
	Flashing red	Alarms, one or more
	Solid red	Error on program core loading
Power	Solid green	Device power supply is enabled
Link	Solid green	Connection with at least one ONT is established
	Solid red	Loss of communication with all ONTs
	Off	Port is disabled

Correct and error-free operation of GPON interface requires exact parameters to be chosen and set for each transceiver type. This can be done only under laboratory conditions by the terminal vendor. [Table 8](#) lists SFP transceivers for which seamless terminal operation is guaranteed.

DDMI (Digital Diagnostic Monitoring Interface) provides information on transceiver parameters, such as temperature, power voltage, etc. DDMI also measures the level of ONT signal (RSSI). All compatible transceivers support this function.

Table 8 – List of compatible SFP transceivers

Vendor	SFP transceiver module	Class	DDMI
NEOPHOTONICS	PTB38J0-6538E-SC	B+	+
NEOPHOTONICS	38J0-6537E-STH1+	C+ HP	+
NEOPHOTONICS	38J0-6537E-STH2+	C+ HP	+
NEOPHOTONICS	38J0-6537E-STH3+	C+ HP	+
Ligent Photonics	LTE3680M-BC	B+	+
Ligent Photonics	LTE3680M-BH	B+	+
Ligent Photonics	LTE3680P-BC	C+	+
Ligent Photonics	LTE3680P-BH	C+	+
Ligent Photonics	LTE3680P-BC2	C+ HP	+
Fanghang	DLOLT43BCDS20	B+	+
Fanghang	DLOLT43CCDS20	C+	+
Fanghang	FH-DLT43CCDS20	C+	+

5 MA4000-PX architecture

MA4000-PX platform is a switching device for Ethernet networks with a distributed switching system. If combined with ONT subscriber devices, MA4000-PX data transmission networks (from its architecture perspective) perform functions relating to access and aggregation levels.

MA4000-PX logical structure is shown in [Figure 9](#).




Figure 9 – MA4000-PX Access Platform Architecture

MA4000-PX is a two-level system of Ethernet switches.

The system centre has switches located on PP4X modules. They perform the aggregating function with respect to the modules of linear interfaces. The system may have one or two PP4X modules. The installation of two modules will help build a high-reliability system owing to the redundancy of switches and increase the system communications capacity due to distribution of data flows between the modules, the modules work in the stacking mode. PP4X modules stacking means there is a possibility to consolidate network interfaces, located at different modules, into trunk groups (LAG, LACP) and an integrated control interface.

The second system level: Ethernet switches located at modules of linear interfaces. These switches perform a function of aggregation with respect to the linear interfaces of a module, on which they are installed.

The interaction between modules occurs via 10Gbps connections. Each PP4X switch is connected to an interface module. Two PP4X are interconnected by two 10Gbps lines.

Access platform architecture is shown in [Figure 9](#).

5.1 PP4X central switch module

Central switch module is the main element of the platform, which generally manages and diagnoses peripheral modules, switching, aggregation and communication interface modules with higher level network equipment. Modules operate in the mode of load sharing and redundancy via two internal 10 Gbps interfaces.

PP4X module block diagram is shown in [Figure 10](#).




Figure 10 – PP4X module block diagram

The module comprises:

- *Processor core* incorporating CPU, random-access memory DDR, non-volatile memory NAND. The processor core controls local module resources, it also controls and monitors all modules incorporated into MA4000 device, stores and processes configuration data, controls and monitors the chassis. Interaction between operator and processor core during control and monitoring procedures can be achieved via RS232 console or via network interface. The connection to Ethernet switch being a part of the module is used as the processor network interface. The processor has an interface, shown as 'shelf' in the Figure, to provide interaction with the chassis controller. The USB interface is a universal one and can be used, e.g., for configuration data transferring and software update.
- *Ethernet switch* which ensures data transfer between devices and modules connected to its interfaces. The switch has 24 multimode ports which can operate at speed up to 12Gbps. The switch is controlled by a processor connected via PCI-Express interface.
- *Data storage device SSD* corresponds to a replaceable solid-state disk. Disks of different capacities may be used. SSD allows to store various-purpose data: configuration files of subscriber devices, system runtime journals, etc.

PP4X module features:

- Support for standard management interface through CLI, SNMP interfaces;
- Processing (changing, storing, archiving) configuration data for all device modules;
- Aggregate switch functions with the support of the following feature:
 - MAC address learning/aging;
 - MAC address quantity restriction;
 - Unknown MAC address processing;
 - Broadcast traffic restriction;
 - Restricting multicast traffic;
 - Quantity of multicast group up to 2000;
 - Q-in-Q in accordance with IEEE 802.1ad;
 - STP, RSTP, MSTP;
 - Support for IGMP/MLD Proxy;

- Support for IGMP/MLD Snooping;
- Fast switching between TV programs (IGMP fast leave);
- Static routing¹;
- Dynamic routing based on RIP, OSPF¹ protocols;
- Bidirectional Forwarding Detect (BFD) for upstream interfaces¹;
- Port isolation, Isolation of ports within one VLAN;
- Static (LAG) and dynamic (LACP) aggregation of network interfaces, including interfaces belonging to different PP4X modules;
- Data channels reservation with short recovery time (less than 1 sec) in case of failure.
- Interaction with external monitoring and control devices using Telnet, SSH, SNMP protocols;
- Collection of alarm data on interface modules and the entire device, forming accident and informational messages for monitoring systems;
- System run time logging and storing in non-volatile memory;
- Device temperature and ventilation system control;
- Software update management for all modules of the device.
- There is a restriction (shaper) for the management interface – 500 packets per second. To ensure protection from ICMP flood, we have introduced additional restriction – 40 ICMP packets per second.

¹ Not supported in the current firmware version

5.2 GPON PLC8 Interface Module

The purpose of PLC8 module is to shape the subscriber access transportation network based on GPON technology.

PLC8v2 module block diagram is shown in [Figure 11](#).




Figure 11 – PLC8v2 module block diagram

The module includes:

- Two four-channel batch-mode processors used as GPON OLT shape up eight GPON interfaces in accordance with ITU-TG.984. Up to 64 ONT or ONU devices can be connected to each interface via optical splitters;
- Two packet Ethernet processors aggregating GPON transport flows and interacting via high-speed highway of MA4000-PX chassis with central switches. In order to ensure device reliability and increase throughput capability, PLC8 module is provided with two interfaces interacting with central switches (uplink) – one for each of them. These interfaces work in aggregated channel mode (trunk or LAG). If MA4000-PX includes only one central switch, one of the interfaces is not used;
- Processor, which tasks include coordination and monitoring of packet processors operation, processing network protocols, supporting protocols for MA4000 device centralized control.

PLC8v1 module block diagram is shown in [Figure 12](#).




Figure 12 – PLC8v1 module block diagram

The module includes:

- Two four-channel batch-mode processors used as GPON OLT shape up eight GPON interfaces in accordance with ITU-TG.984. Up to 64 ONT or ONU devices can be connected to each interface via optical splitters;
- Packet Ethernet processor aggregating GPON transport flows and interacting via high-speed highway of MA4000-PX chassis with central switches. In order to ensure device reliability and increase throughput capability, PLC8 module is provided with two interfaces interacting with central switches (uplink) – one for each of them. These interfaces work in aggregated channel mode (trunk or LAG). If MA4000-PX includes only one central switch, one of the interfaces is not used;
- Processor, which tasks include coordination and monitoring of packet processors operation, processing network protocols, supporting protocols for MA4000 device centralized control.

6 Installation and connection

This Section provides safety instructions, procedures for equipment installation into a rack and connection to power supply.

Prior to beginning the work it is necessary to carefully study working instructions and recommendations contained in equipment documentation.

Along with the safety requirements specified in this document and other documents accompanying the equipment, all industry relevant laws and regulations as well as operating company's individual requirements shall be observed when operating the equipment.

The personnel operating the equipment shall undergo relevant safety and operations training. Equipment may be handled by qualified personnel only.

In order to preclude personnel injuries and damage of equipment, all works shall be carried out in accordance with the following requirements.

6.1 General requirements

Equipment installation:

- devices should be installed in the premises, which help prevent unauthorized access to them;
- devices can be installed only above concrete or other surfaces that do not sustain combustion;
- prior to beginning operation the device should be put steadily on a steady surface – on the floor or in a telecommunication cabinet;
- special attention to grounding should be given during installation/uninstallation of the device. The grounding wire should be primarily connected to the device during installation and disconnected last during uninstallation;
- for trouble-free operation of the equipment, a proper ventilation should be ensured. There should be no foreign objects closer than 5 cm to ventilation openings available on equipment body;
- all the fasteners should be tightened sufficiently after completing installation works.

Grounding:

- operating the device without correctly arranged grounding is not allowed. The grounding should be arranged in accordance with Electrical Installations Code (EIC) requirements and shall be tested to comply with the Code requirements;
- a device or an equipment complex should be connected to the protective grounding prior to operation (prior to connecting power supply feeders). The section of grounding conductors should be at least than 10 mm²;
- in case additional instruments and devices are used together with the equipment which are powered from high-voltage mains, e.g., from 220 VAC mains, then such instruments should be reliably grounded for protecting personnel and preserving equipment integrity.

Power supplies:

- the device requires a DC power source;
- to connect power supplies, wires with sections corresponding to the maximum value of current used by a device should be used;
- adherence to polarity is mandatory when connecting power feeders;
- available power supplies should have protective devices to ensure quick load disconnection in case the maximum value for the device feed current had been exceeded;
- each power feeder should be connected via a device which allows to promptly switch off – a circuit breaker or any other device;
- the device features two power inputs and can be connected to one or both power supplies. In order to switch off the device completely, it is necessary to disable all used power supplies.

Personnel safety:

- no mounting or other works related to disconnection of cables from the device or disconnection of the device from the grounding circuits should be performed during thunderstorm;
- to lift or move the device hold it by the chassis elements. Do not load pushers by the basket weight at the front panels of modules and handles on the replacement in-feed modules and ventilation panel;
- two persons should be engaged to move the basket;
- to protect eyes from laser radiation, do not look into in the open optical ports. Infrared radiation of the lasers used in optical interfaces of devices can cause irreversible eye damage.

Personnel qualification:

- device installation, configuring and servicing shall be performed by qualified employees only;
- the device may be handle authorized personnel only;
- any changes to the device (replacement of modules, software replacement) can be made by properly qualified and attested personnel;
- any alarms or failures in equipment operation shall immediately be reported to the on-duty personnel.

Prior to perform any types of works, all sections of documentation should be carefully read.

6.2 Equipment installation**6.2.1 Preparing for installation**

Prior to equipment installation ensure that mounting location requirements are met. No high temperatures, dust, harmful gases, combustible and explosive materials, sources of intensive electromagnetic radiation (radio stations, transformer substations, etc.), sources of loud sound shall be found at the places of equipment installation.

The installation place shall be compliant with the typical requirements to the places of telecommunication equipment installation.

If temperature in the premises without equipment exceeds 35 °C, an air conditioner it should be additionally installed. The air conditioner shall automatically start-up after blackouts. A stream of cooled air shall not blow right to the equipment, instead it shall be uniformly distributed within the premises.

The device ventilation is organized following a diagram shown in [Figure 4](#).

The following conditions should be met for proper operation of the ventilation system:

- distance between the lower and the upper panels of the chassis and the closest neighbouring equipment should be at least 1U (44.45 mm);
- distance between the rear panel of the chassis and the rear panel of the wall should be at least than 200 mm;
- grounding shall be arranged in the installation premises, the power supply system shall correspond to equipment characteristics with respect to consumed power.

6.2.2 Position and mounting requirements

The device is intended to be installed in telecommunication cabinet. For maintenance operations, a free access to the device from the front and the rear should be provided.

Example for equipment arrangement is shown in [Figure 13](#).




Figure 13 – Example of positioning

6.2.3 Installing into a rack

The chassis of the device has attachment brackets intended for installation into telecommunication cabinet (19-inch rack). The delivery set of the device includes fasteners.

The ventilation requirements above should be met when arranging equipment in a rack. [Figure 14](#) shows an example for device arrangement in the rack.




Figure 14 – MA4000-PX rack installation

6.2.4 Laying and connecting cables

This Section explains an internal connections order to be made in the telecommunication cabinet.

Before connecting power feeders and communication lines to the device, grounding conductors should be connected first.

- ❗ **Telecommunication cabinet shall be grounded prior to perform works on feeding power to the devices.**

At the next step power cables should be connected. One or two power feeders may be connected to the device. During connection works, adherence to polarity should be ensured at all the stages.

⚠ All power sources should be disabled when performing power connection works.

To supply power to the devices installed in the cabinet, a power distribution device should be used. The equipment wiring diagram with a distribution device depends on its parameters. An approximate cable laying diagram is shown in [Figure 15](#).





Figure 15 – Cable laying and connecting and wire grounding diagram

- Red – wire connecting device terminal '+' with positive power supply pole;
- Blue – wire connecting device terminal '-' with negative power supply pole;
- Yellow – grounding wire (grounding terminals at the device and grounding bar are marked with a  sign).

The next step involves connection of subscriber lines and data transmission lines. The lines should be connected in accordance with the design diagram.

Data transmission lines should be connected to the ports at PP4X control modules. An optical or copper wire can be used for connection works.

In case of laying optical cable outside the cabinet and leading it into the cabinet, measures should be taken to protect the cable from damages by means of laying cable in the protective corrugated pipe. Cable bending radius when laying should be not less than 40 mm. Cable organizers should be used for horizontal cable laying in the equipment approach area.

In case of laying copper (electric cable) special attention should be paid to protection of cable insulation and sheath from damage. The windows for cable feed-in into the cabinet should be free from sharp cutting edges. In all cases laying of signal cables and data transmission cables in the same bundle with power cables should be avoided.

7 Connecting to the CLI

7.1 Introduction

This section describes various connection methods for Command Line Interface (CLI) of the access node. A serial port (hereafter – COM port) is recommended for preliminary adjustment of the access node.

7.2 Connecting to the CLI via COM port

This type of connection requires PC either to have an integrated COM port or to be supplied with an USB-COM adapter cable. The PC should also have a terminal program installed, e. g. HyperTerminal.

Step 1. Using the null modem cable, connect the **CONSOLE** port of the PP4X master module ('Master' LED indicator should be solid green) to the COM port of the PC, see [Figure 16](#).




Figure 16 – Connecting access node to PC via COM port

Step 2. Launch the terminal program and create a new connection. Select the corresponding COM port in the '**Connect to**' drop-down list. Assign the port settings according to the [Table 9](#). Click **OK**.

Table 9 – COM port specifications

Parameters	Value
Speed	115200
Data bits	8
Parity	none
Stop bits	1
Flow control	none

Step 3. Press **Enter**. Log into the device CLI.

- ✔ Factory settings:
 - login: **admin**
 - password: **password**

```
*****
*           Welcome to MA4000           *
*****

ma4000 login: admin
Password: *****

Technical support: http://eltex.nsk.ru/support
Wed Jan  8 11:58:08 T 2014

ma4000#
```

7.3 Connecting to the CLI via Telnet

The *Telnet* protocol connection is more flexible than the connection via COM port. Connection to CLI can be established directly at the device location or via an IP network with the help of a remote desktop.

This section considers direct connection to CLI at the terminal location. Remote connection is similar, but requires changes in the access node IP address that will be considered in detail in the [Network settings](#) section.

In order to be connected to the access node, a PC should have a Network Interface Card (NIC). The connection will additionally require the sufficient amount of network cable (Patching Cord RJ45) as it is not included in the delivery package.

Step 1. Connect the network cable to the **Gigabit Ethernet** port **0** or **1** (RJ-45 connector) of the PP4X master module ('Master' LED should be solid green) and to the PC's network card, see [Figure 17](#).




Figure 17 – Connecting access node to PC with the network cable

Step 2. Assign IP settings for network connections:

- IP address: **192.168.1.1**
- Subnet mask: **255.255.255.0**




Figure 18 – Network connection configuration

Step 3. On the PC, click **Start > Run**. Enter the **telnet** command and **IP address** of the access node. IP address factory setting: **192.168.1.2**. Click **OK**.




Figure 19 – Launching Telnet client

Step 4. Log into the access node CLI.

Factory settings:

- login: **admin**
- password: **password**

```

*****
*           Welcome to MA4000           *
*****

ma4000 login: admin
Password:

Technical support: http://eltex.nsk.ru/support
Mon Jan 13 13:40:02 T 2014

ma4000#
    
```

7.4 Connecting to the CLI via Secure Shell

Secure Shell (SSH) connection has functionality similar to the Telnet protocol. However, as opposed to Telnet, Secure Shell encrypts all traffic data, including passwords. This enables secure remote connection via public IP networks.

This section considers direct connection to CLI at the terminal location. Remote connection is similar, but requires changes in the access node IP address that will be considered in detail in the [Network settings](#) section.

In order to be connected to the access node, a PC should have a Network Interface Card (NIC). The PC should have an SSH client installed, e. g. PuTTY. The connection will additionally require the sufficient amount of network cable (Patching Cord RJ45) as it is not included in the delivery package.

Step 1. Perform Steps 1 and 2 from Section [Connecting to CLI via Telnet protocol](#).

Step 2. Run PuTTY. Enter IP address of the access node.

- IP address factory setting: **192.168.1.2**;
- Port – **22**;
- Protocol type – **SSH**.

Click **Open**.




Figure 20 – SSH client startup

Step 3. Log into the access node CLI.

Factory settings:

- login: **admin**
- password: **password**

```
*****  
*           Welcome to MA4000           *  
*****
```

```
ma4000 login: admin  
Password:
```

```
Technical support: http://eltex.nsk.ru/support  
Mon Jan 13 13:40:02 T 2014
```

```
ma4000#
```

8 Getting started with the CLI

8.1 Introduction

CLI is the main means of communication between user and the access node. This section considers general rules in operations with CLI.

Command Line Interface (CLI) allows to perform the device management and monitor its operation and status. You will require the PC application supporting Telnet protocol operation or direct connection via the console port (e.g. HyperTerminal).

8.2 Command line operation rules

To simplify the use of the command line, the interface supports automatic command completion. This function is activated when the command is incomplete and the <Tab> character is entered.

Another function that helps to use the command line – context help. At any stage of entering a command, you can get a prompt about the following command elements by entering <?> character.

For the convenience of managing the device via a command line, the **do** command is used, which allows you to execute global level commands (ROOT) when you are at other levels of the command interface.

For example:

```
ma4000# configure          switch to the device configuration mode
ma4000(config)# vlan 1
ma4000(vlan-1)# do show vlan 1
```

VID	Name	Tagged			Untagged		
1	VLAN0001	slot-channel 0	(M)	front-port 1/0	(S)		
		slot-channel 1	(M)	front-port 1/1	(S)		
		slot-channel 2	(M)	front-port 1/2	(S)		
		plc-pon-port 0/7	(D)	-			
		plc-slot-channel 0/0	(D)	-			

Membership type: (S) - **static**, (D) - dynamic, (M) - slot-channels in management vlan

To simplify the commands, the whole command system has a hierarchical structure. There are special branch commands for transition between levels of the hierarchy. This allows to use brief commands on each level. To designate a current level where a user is located, the system prompt string changes dynamically.

For example:

```
ma4000# configure          enter the device configuration mode
ma4000(config)#
ma4000(config)# exit      return to the highest command system layer
ma4000#
```

For the ease of command line use, shortcut keys listed in the [Table 10](#) are supported.


Table 10 – Description of CLI shortcut keys

Shortcut key	Description
Ctrl+D	In the nested section, return to the previous section ('exit' command); in the root section, exit the CLI ('logout' command).
Ctrl+Z ¹	Go to the root section
Ctrl+A	Transition to the beginning of line
Ctrl+E	Transition to the end of line
Ctrl+U	Removal of characters to the left of a cursor
Ctrl+K	Removal of characters to the right of a cursor
Ctrl+C	Clear the line
Ctrl+W	Remove a word
Ctrl+B ¹	Transition of a cursor one position backwards
Ctrl+F ¹	Transition of a cursor one position ahead

¹ Not supported in the current firmware version.

Command line interface enables user authorization and restricts access to commands depending on their access level, provided by the administrator.

You can create as many users as you like, access rights will be assigned individually to each user.

 **In factory configuration, the system includes one user with the 'admin' name and the 'password' password.**

The system supports multi-user privileged access.

8.3 CLI commands structure

MA4000 command line interface command system is divided into the hierarchical levels – modes (view).

From the global ROOT mode, you can enter the device parameters' configuration mode – **CONFIG** mode. Only users with the access level 15 are able to enter the configuration mode.

To switch from the global mode ROOT, you should run the following commands:

```
ma4000# configure terminal
ma4000(config)#
```




Figure 21 – Command mode hierarchy

Top level of the command hierarchy is shown in the [Table 11](#).

Table 11 – Command modes hierarchy (top level)

Level	Entry command	Prompt line view	Previous level
Global mode (ROOT)		ma4000#	
MA4000 configuration management mode (CONFIG)	configure terminal	ma4000(config)#	ROOT
Interface configuration	For detailed information see Table 12		CONFIG
Profiles management	For detailed information see Table 13		CONFIG
VLAN configuration (VLAN)	vlan	ma4000(vlan-N)#	CONFIG

Table 12 – Interface configuration command modes

Level	Entry command	Prompt line view	Previous level
PP4X module external uplink interface configuration (FRONT-PORT)	interface front-port	ma4000(front-port _)#	CONFIG
Configuration of PLC8 module external GPON interfaces (GPON-PORT)	interface gpon-port	ma4000(gpon-port _)#	

Level	Entry command	Prompt line view	Previous level
ONT GPON configuration (PLC ONT)	ont	ma4000(config)(if-ont-0/0/0)#	
Configuration of PLC8 module external management interface (mgmt) (PLC FRONT-PORT)	interface plc-front-port	ma4000 (plc-front-port-x)#	
Configuration of management interfaces located between the Ethernet switch and PLC8 module olt chips (PLC MGMT-PON-PORT)	interface plc-mgmt-pon-port	ma4000 (plc-mgmt-pon-port-x)#	
Configuration of PON interfaces located between the Ethernet switch and PLC8 module OLT chips (PLC PON-PORT)	interface plc-pon-port	ma4000 (plc-pon-port-x)#	
Configuration of the PLC8 module interface aggregation group used for connection to the PP4X module (PLC SLOT-CHANNEL)	Interface plc-slot-channel	ma4000(plc-slot-channel-x)#	
Configuration of PLC8 module interfaces used for connection to PP4X (PLC SLOT-PORT)	interface plc-slot-port	ma4000 (plc-slot-port-x)#	
LAG configuration of PP4X module uplink interfaces (PORT-CHANNEL)	interface port-channel	ma4000(port-channel-)#	
LAG configuration of PP4X module interfaces for PLC8 modules (SLOT-CHANNEL)	interface slot-channel	ma4000(slot-channel-)#	
Configuration of PP4X module interfaces for PLC8 modules (SLOT-PORT)	interface slot-port	ma4000(slot-port-)#	
Configuration of PP4X module internal stacking interfaces (STACK-PORT)	interface stack-port	ma4000(stack-port-)#	

Table 13 – Device profile command mode description

Level	Entry command	Prompt line view	Previous level
Address table profile configuration (PROFILE ADDRESS TABLE)	profile address_table	ma4000(config-address-table) ("NAME")#	CONFIG
ONT GEM port profile configuration (PROFILE CROSS CONNECT)	profile cross-connect	ma4000(config-cross-connect)("NAME")#	
DBA profile configuration (PROFILE DBA)	profile dba	ma4000(config-dba) ("NAME")#	
DHCP relay agent profile configuration (PROFILE DHCP_RA)	profile dhcp_ra	ma4000(config-dhcp-ra) ("NAME")#	
ONT management profile configuration (PROFILE MANAGEMENT)	profile management profile management-by-name	ma4000(config-management) ("NAME")#	
DHCPv6 relay agent profile configuration (PROFILE DHCP_RA)	profile dhcpv6-ra	ma4000(config-dhcpv6-ra) ("NAME")#	
ONT port profile configuration (PROFILE PORTS)	profile ports	ma4000(config-ports) ("NAME")#	
PPPoE intermediate agent profile configuration (PROFILE PPPoE_IA)	profile pppoe_ia	ma4000(config-pppoe-ia) ("NAME")#	
ONT bandwidth management profile configuration (PROFILE SHAPING)	profile shaping	(config-shaping)("NAME")#	
VLAN profile configuration (PROFILE VLAN)	profile vlan	ma4000(config-vlan) ("NAME")#	

9 Configuring access node

9.1 Configuration structure

9.1.1 Introduction

A collection of all access node settings is referred to as configuration. This section provides information about the parts configuration consists of. It also defines the lifecycle of configuration and describes main operations which can be performed.

9.1.2 Configuration structure

The access node configuration can be conventionally divided into 3 parts. [Figure 22](#) shows the configuration structure.




Figure 22 – The structure of access node configuration

- *General system part*. This group includes such settings as: network, service settings, user table, etc.
- *SLOT – Slot configuration*. Contains PLC8 interface module settings.
- *Profiles – OLT and ONT profiles*. Contains OLT and ONT profile settings, that could be assigned to the PLC8 interface modules and ONT subscriber terminals respectively.

9.2 Configuration lifecycle

There are several types of configuration in the system:

- *CANDIDATE* – a configuration under review.
- *RUNNING* – an active configuration. It refers to the current configuration of the access node.
- *BACKUP* – keeps the previous active configuration; used when you need to roll back configuration changes.

[Figure 23](#) shows the diagram of configuration type changes.




Figure 23 – Diagram of configuration type changes

To apply changes made to the configuration, you should execute the **commit** command. After that, running configuration becomes backup configuration, and RUNNING is copied to BACKUP.

If you need to cancel configuration changes made, perform the **rollback** operation. After that, the CANDIDATE configuration will be deleted. Next time configuration changes will be based on the RUNNING configuration.

To validate the applied configuration, the operator should enter the **confirm** command. If the confirmation is not provided until the expiration of the confirmation timer (default value is 5 minutes), the device configuration will return to the state before the last **commit** command execution. You can roll back configuration changes before the timer expires. To do that, use the **restore** command.

9.3 Creating a configuration backup

Configuration backups allow the access node operation to be quickly restored after abnormal situations or replacement. Manual or triggered (on events) creation of backups is recommended at a regular basis.

Access node configuration is uploaded to a TFTP server available in management network. The **copy** command is used to upload the data. Pass the uploaded device configuration **fs://backup** and destination URI as parameters.

```
ma4000# copy fs://backup tftp://192.168.22.1/config
```

To create backups automatically, you have to configure special events (triggers).

Step 1. If necessary, define the configuration backup upload on each change (on the **commit** command execution) with the **backup onchange** command:

```
ma4000(config)# backup onchange
```

Step 2. If necessary, define the configuration backup upload on timer with the **backup ontimer** command. Set the configuration backup upload timer with the **backup ontimer-period** command. Pass the timer value in seconds as a parameter:

```
ma4000(config)# backup ontimer
ma4000(config)# backup ontimer-period 3600
```

Step 3. Specify the URI for configuration upload:

```
ma4000(config)# backup path tftp://192.168.22.1/config
```

Step 4. Apply and confirm changes:

```
ma4000(config)# do commit
ma4000(config)# do confirm
```

9.4 Recovering configuration

Access node configuration is restored from a TFTP server available in management network. The **copy** command is used to restore the data.

Step 1. Load configuration using the **copy** command. Pass the restored configuration source URI and **fs://backup** as parameters:

```
ma4000# copy tftp://192.168.22.1/config fs://backup
```

Step 2. Apply and confirm changes:

```
ma4000# commit
ma4000# confirm
```

9.5 Resetting configuration

To reset an access node configuration to factory settings, use the **default** command:

```
ma4000# default
Entire candidate configuration will be reset to default, all settings will be lost upon
commit. Additional firmware will be deleted.
Do you really want to continue ? y/n y
```

10 Network settings

10.1 Introduction

This section describes adjustment of network settings for an access node. Adjusting network settings enables remote control and integration with OSS/BSS systems.

10.2 Configuring network parameters

Adjustments of network settings are recommended to be done via COM port connection, described in [Section C connecting to the CLI via COM port](#). This will prevent issues with connection loss before the access node being adjusted. Be very careful when using remote adjustment.

Step 1. Use the **show management** command to view the current network settings:

```
ma4000#show management
Network parameters :
  ip           192.168.0.1
  mask         255.255.255.0
  gateway      192.168.0.254
  vlan         1
```

Step 2. Switch to the **configure view** and set the access node name by using the **hostname** command:

```
ma4000# configure terminal
ma4000(config)# hostname ma4000
```

Step 3. Set the access node IP address by using the **management ip** command. Pass the IP address and the subnet mask as parameters:

```
ma4000(config)# management ip 192.168.22.22 255.0.0.0
```

Step 4. Set the default gateway by using the **management gateway** command:

```
ma4000(config)# management gateway 192.168.22.254
```

Step 5. Adjust the VLAN management of the access node by using the **management vlan** command, if necessary:

```
ma4000(config)# management vlan 9
```

Proper operation of the inband management function requires VLAN adjustment as described in [section VLAN configuration](#).

Step 6. Set the lifetime of MAC addresses by using the **mac address-table aging-time** command. Pass time in seconds as a parameter:

```
ma4000(config)# mac address-table aging-time 600
```

Step 7. The network settings will change as soon as the configuration is applied. No access node reboot is needed:

```
ma4000(config)# do commit
ma4000(config)# do confirm
```


11 Managing users

11.1 Introduction

This section is devoted to management of the access node users.

- ✔ **The factory settings provide only one user, i. e. the device administrator.**
login: *admin*
password: *password*
When you start to configure the access node, we recommend you to change the password of the *admin* user.

For security reasons, there is a strictly defined set of permissions, which can be delegated to access node users. For these purposes, each user gets his own level of privileges. Level 0 corresponds to a minimum set of permissions, Level 15 – to a maximum set of permissions.

CLI commands are ranked by the level of privileges. Level 0 commands are available to all users. Level 15 commands are available only to Level 15 users. Commands available to the user will correspond to his/her privilege level. Privilege list and description:

- view-switch – allows to view PP4X switch and slot configuration;
- view-alarm – allows to view active alarms, their configuration and event log;
- view-system – allows to view system settings: logging, user configuration, Tacacs;
- view-general: allows to view basic settings – management, firmware information, status of boards and log message reading;
- view-gpon – allows to view configuration and status of OLT chips, GPON ports, and OLT;
- view-ont – allows to view MAC tables and ONT counters;
- view-ont-profile – allows to view ONT profile configuration;
- view-switch-interfaces – enables Ethernet interface operation monitoring: counters; Ethernet port status, utilization and configuration; MAC table configuration;
- config-switch – enables switch configuration: LACP, QoS, STP;
- config-alarm – enables alarm configuration;
- config-system – enables configuration of system parameters: logging, user configuration, Tacacs;
- config-general – enables configuration of management parameters and operations with software;
- config-gpon – enables configuration of OLT profiles and configuration of OLT chip basic operation parameters;
- config-ont – enables ONT configuration: adding, removing, service activation;
- ont-operation – allows to execute specific ONT management commands: reboot, reconfiguration, firmware update;
- config-ont-profile – enables configuration of ONT profiles;
- config-switch-interfaces – enables Ethernet interface configuration: aggregation, enabling/disabling, VLAN operations.

11.2 Users list preview

To view the list of access node users, enter the **show users config** command:

```
ma4000# show users config

  System users
  ~~~~~
User name          User privilege level
-----
root               15
admin              15
remote             15
linux              0
4 system users.
```

The *admin*, *root* and *linux* users always exist and cannot be deleted or duplicated. The node supports up to 16 users.

11.3 Adding a new user

In order to operate effectively and safely, the access node, as a rule, requires one or several additional users. To add a new user, enter the **user** command in the **configure view**:

```
ma4000(config)# user operator
ma4000(config)# do commit
ma4000(config)# do show users

  System users
  ~~~~~
User name          User privilege level
-----
root               15
admin              15
remote             15
linux              0
operator           0
5 system users.
```

Pass the name of the new user to the **user** command as a parameter. The name should not be longer than 32 characters. The name should not contain special characters.

11.4 Changing user password

To change user password, enter the **user** command. Pass the user name and a new password as parameters:

```
ma4000(config)# user operator password newpassword
```

Maximum password length is 31 characters. If the password contains a space, use quotations for the password.

11.5 Viewing and changing user access rights

To manage user access rights, a user priority system is implemented.

A newly created user is granted with a minimal set of permissions:

```
ma4000(config)# user operator
ma4000(config)# do show users
ma4000(config)# do show users

System users
~~~~~
User name          User privilege level
-----
root                15
admin               15
remote             15
linux               0
operator           0
5 system users.
```

To change the user priority level, enter the **user** command. Pass the user name and a new priority as parameters:

```
ma4000(config)# user operator privilege 15
ma4000(config)# do show users

System users
~~~~~
User name          User privilege level
-----
root                15
admin               15
remote             15
linux               0
operator           15
5 system users.
```

11.6 Deleting a user

To delete a user, enter the **no user** command in the **configure view**. Pass the user name as a parameter:

```
ma4000# configure terminal
ma4000(config)# no user operator
ma4000(config)# do commit
ma4000(config)# do confirm
```

11.7 Configuring user session

Timeouts are used to limit the duration of CLI sessions. If no commands are executed before the timeout, the session will be closed automatically. Use the **cli session-timeout** from the **configure view** command. Pass the time period in minutes as a parameter.

```
ma4000(config)# cli session-timeout 300
```

11.8 Configuring user authentication

There are several methods of user authentication in the system:

- do not use authentication;
- local – use a local user database for authentication;
- tacacs+ – use TACACS+ server for authentication;
- radius – use RADIUS server for authentication.

Step 1. Define the default authentication procedure using the **aaa authentication login** command:

```
ma4000(config)# aaa authentication login default tacacs+
```

In this example, the system will attempt to perform authentication using the Tacacs+ server in the first place (see Section [Tacacs+ configuration](#)). If the server is unavailable, the authentication will be performed using the local user database.

Step 2. Switch to configuration of the connection method, e.g. the console:

```
ma4000(config)# line console
```

Step 3. Define the authentication procedure for the selected method. You can use the default authentication procedure or a custom procedure, created by analogy to the Step 1:

```
ma4000(config)# line console
ma4000(config-line-console)# login authentication default
```

Step 4. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
ma4000(config)# do confirm
```

11.9 Network access restriction

To improve security and restrict access to the device by persons not intended for its maintenance, the **management access-list** functionality is used.

There are two options for this functionality: **default allow** (default behavior) – all non-restricted traffic will be processed, **default deny** – all unauthorized traffic will be discarded.

Example. Restrict access to the device for a specific subnet.

Let's forbid management of the device except by means of ssh protocol, traffic from subnet 10.0.0.0/24 coming to front-port 1/0.

Step 1. Restrict all unauthorized traffic:

```
ma4000(config)# management access-list default deny
```

Step 2. Configure restrictive criteria:

```
ma4000(config)# management access-list-ip
ma4000(acl-ip)# add allow ssh front-port 1/0 10.0.0.0 255.255.255.0
```

Step 3. Apply changes:

```
ma4000(acl-ip)# do commit
ma4000(acl-ip)# do confirm
```

12 Service configuration

12.1 SNMP configuration

Step 1. Enable SNMP agent using the **ip snmp agent enable** command:

```
ma4000(config)# ip snmp agent enable
```

Step 2. Define the SNMP device name using the **ip snmp agent system name** command:

```
ma4000(config)# ip snmp agent system name ma4000
```

Step 3. Define SNMPv3 EngineID:

```
ma4000(config)# ip snmp agent engine id test
```

Step 4. Define the SNMP trap destination server. Pass SNMP Trap version and destination IP address as parameters:

```
ma4000(config)# ip snmp agent traps informs 192.168.1.100
```

Step 5. Define SNMPv2 community, if necessary:

```
ma4000(config)# ip snmp agent community readonly public
```

Step 6. Add SNMPv3 users using the **ip snmp agent user add** command. Pass username, password (8-31 symbols) and access mode as parameters:

```
ma4000(config)# ip snmp agent user add test test ro
```

Step 7. If necessary, change the type of transport protocol for SNMP messages transmission. By default the messages are sent in UDP.

```
ma4000 (config)# ip snmp agent transport tcp
```

Step 8. Apply the configuration using the **commit** command:

```
ma4000(config)# do commit  
ma4000(config)# do confirm
```

12.2 System log configuration

Step 1. Define the level of messages, that will be sent to the console and the remote CLI sessions (SSH and Telnet):

```
ma4000(config)# logging console debug
ma4000(config)# logging monitor debug
```

Step 2. Define the maximum system log file size. When the file size is exceeded, the system will perform the rotation:

```
ma4000(config)# logging file-size 1000
```

Step 3. Define the quantity of system log files of the same type:

```
ma4000(config)# logging max-files 5
```

Step 4. If necessary, perform the message level configuration for the files listed in the [Table 24](#):

```
ma4000(config)# logging file pp debug
```

Step 5. If necessary, perform the message filter configuration for the files listed in the [Table 24](#) using the **match** command. Use the **destination** command to define the destination for messages:

```
ma4000(config)# logging builtin-filter pp
ma4000(config-log-filter-pp)# match pp
ma4000(config-log-filter-pp)# destination file pp
ma4000(config-log-filter-pp)# destination host 192.168.1.100 port 55 transport udp
```

Step 6. If necessary, enable system log message forwarding to the remote SYSLOG server:

```
ma4000(config-log-filter-pp)# exit
ma4000(config)# logging host 192.168.1.120 port 55 transport udp debug
```

Step 7. If necessary, enable the system log file storage to the non-volatile memory:

```
ma4000(config)# logging storage persistent
```

Step 8. If necessary, configure the message level on each PLC:

```
ma4000(config)# logging filter slot2
ma4000(pp4x-config-log-filter-slot2)# facility any debug
ma4000(pp4x-config-log-filter-slot2)# exit
```

Step 9. Apply the configuration using the commit command:

```
ma4000(config)# do commit
ma4000(config)# do confirm
```

12.3 SSH configuration

Step 1. Enable SSH server using the **ip ssh server** command:

```
ma4000(config)# ip ssh server
```

Step 2. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
ma4000(config)# do confirm
```

12.4 Telnet configuration

Step 1. Enable Telnet server using the **ip telnet server** command:

```
ma4000(config)# ip telnet server
```

Step 2. Specify the connection port using the **ip telnet port** command:

```
ma4000(config)# ip telnet port 9000
```

Step 3. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
ma4000(config)# do confirm
```

12.5 Tacacs+ configuration

Step 1. Define the Tacacs server connection settings:

```
ma4000(config)# tacacs-server timeout 10
ma4000(config)# tacacs-server key 12345
ma4000(config)# tacacs-server encrypted key 98C7D37909
```

Step 2. Add Tacacs server into the list of utilized servers using the **tacacs-server host** command. Define the connection settings for this server:

```
ma4000(config)# tacacs-server host 192.168.1.200
ma4000(config-tacacs)# key 123
ma4000(config-tacacs)# timeout 12
ma4000(config-tacacs)# priority 0
ma4000(config-tacacs)# port-number 3000
```

Step 3. If necessary, enable accounting for commands entered by the user:

```
ma4000(config)# aaa accounting commands tacacs+
```

Step 4. If necessary, enable accounting for user logins/logouts:

```
ma4000(config)# aaa accounting start-stop tacacs+
```

Step 5. Apply the configuration using the commit command:

```
ma4000(config)# do commit
```

12.6 Radius configuration

Step 1. Define common parameters of connection to Radius servers:

```
ma4000(config)# radius-server timeout 10
ma4000(config)# radius-server key 12345
ma4000(config)# radius-server encrypted key 98C7D37909
```

Step 2. Add Radius server into the list of utilized servers using the **radius-server host** command. Define the connection settings for this server:

```
ma4000(config)# radius-server host 192.168.1.200
ma4000(config-radius)# key 123
ma4000(config-radius)# timeout 12
ma4000(config-radius)# priority 0
ma4000(config-radius)# port-number 3000
```

Step 3. Apply the configuration using the commit command:

```
ma4000(config)# do commit
```

12.7 SNTP configuration

Step 1. Enable time synchronization using the **ip sntp client** command:

```
ma4000(config)# ip sntp client
```

Step 2. Define the time synchronization server IP address using the **ip sntp server** command:

```
ma4000(config)# ip sntp server 192.168.1.254
```

Step 3. Specify the synchronization interval in minutes:

```
ma4000(config)# ip sntp poll-period 60
```

Step 4. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
ma4000(config)# do confirm
```

12.8 Daylight saving change configuration

The device allows you to flexibly adjust the transition to daylight saving time and back. There are 2 possible configuration options:

- **clock summer-time date** – hard bind to a specific date.

Example: to schedule time transfer at +1 hour on December 3 at 00:00 and back on March 16 00:00 from 2015 to 2035.

```
clock summer-time date zone TEST start-day 3 start-month dec start-year 2015 start-time 00:00
end-day 16 end-month mar end-year 2035 end-time 00:00 hours 1 minutes 0
```

- **clock summer-time recurring** – bind to a floatation date

Example: to schedule time transfer for +1 hour on the third Saturday of November at 00:00 and back on the second Saturday of March at 00:00.

```
clock summer-time recurring zone TEST start-week 3 start-day sat start-month nov start-time 00:
00 end-week 2 end-day sat end-month mar end-time 00:00 hours 1 minutes 00
```


13 VLAN Configuration

13.1 Introduction

This section describes VLAN configuration in the access node.

VLAN (*Virtual Local Area Network*) is a group of devices, which communicate on the channel level and are combined into a virtual network, connected to one or more network devices (GPON terminals or switches). VLAN is a very important tool for creating a flexible and configurable logical network topology over the physical topology of a GPON network. VLAN has two or more switch interfaces. A VLAN member interface can be either tagged or untagged. An outgoing packet of a tagged interface has a VLAN tag. An outgoing packet of an untagged interface has no VLAN tags. For more details on interfaces configuration and rules see Section [Interface configuration](#).

13.2 Adding a VLAN

Step 1. Switch to the access node **configure view**:

```
ma4000# configure terminal
```

Step 2. Add a VLAN by using the **vlan** command. Pass *VID* as a parameter:

```
ma4000(config)# vlan 100
```

- ✔ **CLI automatically switches view to work with the VLAN. The same command is used to configure existing VLANs.**

13.3 Configuring VLAN

Step 1. Add tagged interfaces with the help of the **tagged** command. Pass interface type and number (or a range) as parameters. The interface types and numbers are given in [Table 14](#):

```
ma4000(vlan-100)# tagged front-port 1/0
```

Step 2. Add untagged interfaces by using the **untagged** command if needed. Pass interface type and number (or a range) as parameters:

```
ma4000(vlan-100)# untagged front-port 1/1
```

Step 3. Delete all unnecessary interfaces from the VLAN with the help of the **forbidden** command. Pass interface type and number (or a range) as parameters:

```
ma4000(vlan-100)# forbidden front-port 1/2-3
```

Step 4. Enable IGMP snooping by using the **ip igmp snooping enable** command, if necessary:

```
ma4000(vlan-100)# ip igmp snooping slot 0-15 enable
ma4000(vlan-100)# ip igmp snooping pp4x enable
```

Step 5. Enable *IGMP querier* by using the **ip igmp snooping querier enable** command, if necessary:

```
ma4000(vlan-100)# ip igmp snooping querier enable
```

Step 6. Enable MLD snooping by using the **ip mld snooping enable** command, if necessary:

```
ma4000(vlan-100)# ipv6 mld snooping slot 0-15 enable
ma4000(vlan-100)# ipv6 mld snooping pp4x enable
```

Step 7. Enable MLD *querier* by using the **ipv6 mld snooping querier enable** command, if necessary:

```
ma4000(vlan-100)# ipv6 mld snooping querier enable
```

Step 8. For further convenience, specify a VLAN name by using the **name** command. To clear the name, use the **no name** command. The default name is *VID*.

```
ma4000(vlan-100)# name iptv
```

Step 9. If it is necessary to allow the user to move between ONTs (for example, to implement a PON service), you should disable the ONT blocking when a duplicate mac address is detected:

```
ma4000(vlan-100)# mac duplication allow
```

Step 10. Apply the configuration by using the **commit** command:

```
ma4000(vlan-100)# do commit
ma4000(vlan-100)# do confirm
```

13.4 Deleting VLAN

Step 1. Delete a VLAN by using the **no vlan** command. Pass *VID* (or its range) as a parameter:

```
ma4000(config)# no vlan 100
```

Step 2. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
ma4000(config)# do confirm
```

14 PP4X stacking configuration

When using two PP4X modules, their configuration files will be synchronized. If PP4X master fails, PP4X slave will keep the running configuration.

The **no stack sync-allow** command allows to disable the configuration file synchronization for the stack.

If the configuration file synchronization is disabled, PP4X slave will be able to get and apply the configuration from the master device, but will not be able to save it to its own file system for the future use.

Enable the synchronization of configuration files using the **stack sync-allow** command:

```
ma4000# stack sync-allow
Command accepted. Automatic synchronization (if needed) will be performed in the background
shortly.
```

15 Interface configuration

15.1 Introduction

This section describes the configuration of the access node interfaces.

Access node interfaces can be divided into two groups: Ethernet interfaces and GPON interfaces. Ethernet interfaces are used for access node connection to operator's network core. GPON interfaces are used for ONT connections.




Figure 24 – Access node interface name system

For accepted access node interface name system, see [Table 14](#).

Table 14 – Access node interface name system and numbering

Interface name	Description	Range
front-port	PP4X module external uplink interfaces	Specified as: U/P U – PP4X module number [1 .. 2] P – PP4X uplink interface number [0..5]
port-channel	LAG of PP4X module uplink interfaces	[1..8] – aggregation group number
slot-port	PP4X module interface for PLC8 GPON module connection	Specified as: U/P U – PP4X module number [1 .. 2] P – interface number for PLC8 module [0..15]

Interface name	Description	Range
slot-channel	LAG of PP4X module interfaces for PLC8 modules	[0..15] – PLC8 module number
stack-port	PP4X module internal stacking interfaces	Specified as: U/P U – PP4X module number [1 .. 2] P – interface number for PP4X module [0..1]
plc-slot-port	PLC8 module interfaces for connection to central switches – PP4X modules	Specified as: S/P S – PLC8 module number [0 .. 15] P – interface number for PP4X module [0..1]
plc-slot-channel	PLC8 module interface LAG for connection to central switches – PP4X modules	Specified as: S/P S – PLC8 module number [0..15] P – module channel number [0]
plc-front-port	PLC8 module external management interface (mgmt)	Specified as: S/P S – PLC8 module number [0..15] P – module channel number [0]
plc-pon-port		Specified as: S/P S – PLC8 module number [0 .. 15] P – port number [0..7]
plc-mgmt-pon-port		Specified as: S/P S – PLC8 module number [0 .. 15] P – port number [0..1]
gpon-port	PLC8 module external GPON interfaces	Specified as: S/P S – PLC8 module number [0 .. 15] P – port number [0..7]

Interface name	Description	Range
ont	Interfaces for the subscriber-side ONT terminals	Specified as: S/P/I S – PLC8 module number [0..15] P – PLC8 module port number [0..7] I – ONT interface number [0..63]

15.2 Ethernet interface configuration

Step 1. Switch to the *view* of the interface (of interface group), which settings should be changed:

```
ma4000(config)# interface front-port 1/0
```

Step 2. Enable the interface by using the **no shutdown** command. On the contrary, the **shutdown** command disables the interface:

```
ma4000(front-port-1/0)# no shutdown
```

Step 3. Enable or disable flow control (IEEE 802.3x PAUSE) by using the **flow-control** command:

```
ma4000(front-port-1/0)# flow-control on
```

Step 4. Enable or disable incoming packets filtering by using the **ingress-filtering** command. Only the packets of the VLANs, which have this interface, will pass the enabled filter. Other packets will be filtered out. If the filter is disabled, a packet will be processed regardless of its VID field:

```
ma4000(front-port-1/0)# ingress-filtering
```

Step 5. Specify a rule for VLAN tags processing for incoming packets by using the **frame-types** command. As a parameter, specify the packets to be allowed: either *tagged* (tagged only) or *all* (both tagged and untagged):

```
ma4000(front-port-1/0)# frame-types tagged
```

Step 6. Specify the port PVID – the VLAN, which will accommodate untagged packets:

```
ma4000(front-port-1/0)# pvid 100
```

Step 7. If necessary, enable or disable packets transfer from this interface to another one (or a range of interfaces) by using the **bridging to** command. Pass interface type and number (or a range) as parameters. The interface types and numbers are given in [Table 14](#).

```
ma4000(front-port-1/0)# bridging to front-port 1/1
```

Step 8. Set automatic determination of speed and duplex of the interface either by using the **speed auto** command or manually:

```
ma4000(front-port-1/0)# speed auto
```

Step 9. Apply the configuration by using the **commit** command:

```
ma4000(front-port-1/0)# do commit
ma4000(front-port-1/0)# do confirm
```

15.3 GPON interface configuration

Step 1. Switch to the *configure* view:

```
ma4000# configure terminal
```

Step 2. Activate traffic encryption with the **gpon olt encryption** command if necessary. Specify the encryption key renewal period with the **gpon olt encryption key-update** command. Pass time period in seconds as a parameter:

```
ma4000(config)# gpon olt encryption
ma4000(config)# gpon olt encryption key-update 60
```

Step 3. Specify ONT authentication method with the **gpon olt authentication** command:

```
ma4000(config)# gpon olt authentication both
```

Step 4. Switch to GPON interface configuration:

```
ma4000(config)# interface gpon-port 0-7
```

Step 5. Enable or disable interfaces with the **no shutdown** or **shutdown** command respectively if necessary:


```
ma4000(config)(if-gpon-0-7)# no shutdown
```

Step 6. Activate FEC for the interface with the **fec** command, if necessary:

```
ma4000(config)(if-gpon-0-7)# fec
```

Step 7. Adjust time settings of optical transceivers if needed:

```
ma4000(config)(if-gpon-0-7)# optics use-custom
ma4000(config)(if-gpon-0-7)# optics ...
```

 **Optical transceivers should be adjusted only by agreement with Eltex Service Centre.**

Step 8. Apply the configuration by using the **commit** command:

```
ma4000(config)(if-gpon-0-7)# do commit
```

16 Isolation group configuration

16.1 Introduction

Isolation group is the mechanism, that allows to restrict the traffic flow inside the VLAN. Isolation groups allow to configure one-way data transmission or divide interfaces located inside the VLAN into 2 logical groups. Operating principle is shown in [Figure 25](#).

✔ This functionality is incompatible with operation on Model 1.




Figure 25 – Isolation group operating principle

16.2 Isolation group configuration

Step 1. Specify the interface isolation group using the **isolation group** command. Pass the isolation group number as a parameter:

```
ma4000(config)# isolation group 0
```

Step 2. Add the required number of destination interfaces into the group using the **allow** command:

```
ma4000(pp4x-config-isolation-0)# allow front-port 1/0-2
```

Step 3. Repeat Steps 1 and 2 for another group:

```
ma4000(pp4x-config-isolation-0)# exit
ma4000(config)# isolation group 1
ma4000(pp4x-config-isolation-1)# allow front-port 1/3-5
```

Step 4. Go to the configuration mode for the required VLAN:

```
ma4000(pp4x-config-isolation-1)# exit
ma4000(config)# vlan 100
```


Step 5. Enable isolation with the **isolation enable** command:

```
ma4000(vlan-100)# isolation enable
```

Step 6. Enable the data transmission from the specific interface to the isolation group (destination interfaces) using the **isolation assign** command. Pass the source interface name and the isolation group number as parameters:

```
ma4000(vlan-100)# isolation assign front-port 1/0-2 group 0  
ma4000(vlan-100)# isolation assign front-port 1/3-5 group 1
```

Step 7. Apply the configuration using the **commit** command:

```
ma4000(vlan-100)# do commit  
ma4000(vlan-100)# do confirm
```

17 SELECTIVE Q-IN-Q configuration

17.1 Introduction

The SELECTIVE Q-IN-Q functionality allows to add an external SPVLAN (Service Provider's VLAN), replace the Customer VLAN, and deny traffic based on configurable filtering rules by internal VLAN (Customer VLAN) numbers.

17.2 SELECTIVE Q-IN-Q configuration

Step 1. Switch to the selective Q-in-Q configuration mode:

```
ma4000(config)# selective-qinq common
ma4000(config-selective-qinq)#
```

Attention! You can create only 1024 rules Selective Q-in-Q for PP4X board. To cover larger numbers of CVLANs, use 'ignore' function.

Step 2. Add external tag adding rules with the **add-tag** command. Pass the external tag VID and internal tag VID or range as parameters:

```
ma4000(config-selective-qinq)# add-tag svlan 20 cvlan 100-200
ma4000(config-selective-qinq)# add-tag svlan 30 cvlan ignore
```

Such configuration implies, that packets coming to an interface with CVLAN 100-200 tag will have the external tag 20 added to them, and all other packets falling outside the scope of this rule will have the external tag 30 added. Rules with 'ignore' option have a lower priority compared to rules with explicitly assigned CVLAN.

Step 3. And/or add VLAN translation rules:

```
ma4000(config-selective-qinq)# overwrite-tag new-vlan 1000 old-vlan 2000 ingress
ma4000(config-selective-qinq)# overwrite-tag new-vlan 2000 old-vlan 1000 egress
```

Step 4. Switch to the configuration of interfaces, that should use the selective Q-in-Q. Enable the function using the **selective-qinq enable** command:

```
ma4000(config-selective-qinq)# exit
ma4000(config)# interface front-port 1/3-5
ma4000(front-port-1/3-5)# selective-qinq enable
```

Step 5. Apply the configuration using the **commit** command:

```
ma4000(front-port-1/3-5)# do commit
ma4000(front-port-1/3-5)# do confirm
```

Attention! If the global Q-in-Q rule table is not sufficient for the purpose, and different interfaces require different settings, you should use Q-in-Q rule lists. You can configure these lists in the separate selective-qinq list <name> by analogy to the sequence shown. To assign the list for the interfaces, use the 'selective-qinq list <name>' command.

18 QoS configuration

The traffic prioritization method will be chosen depending on the configured system rules (IEEE 802.1p/DSCP).

Table 15 – Traffic prioritization methods

Priority	Description
0	All the priorities are equal
1	Packet selection according to IEEE 802.1p
2	Packet selection only according to IP ToS (Type of Service) on 3 level - support for Differentiated Services Codepoint (DSCP)
3	Interaction according to either 802.1p or DSCP/TOS

Step 1. Define the queue, that will be used for packets without any preconfigured rules. The 0 queue has the least priority:

```
ma4000(config)# qos default 0 slot 0
```

Step 2. Set a traffic prioritization method by using **qos type** command. Pass the prioritization type as a parameter (see [Table 15](#)):

```
ma4000(config)# qos type 1 slot 0
```

Step 3. Using the **qos map** command, set rules for translation of 802.1p and DSCP/TOS to a queue number. Send field type and priorities lists as parameters:

```
ma4000(config)# qos map 1 0-4,15,63 to 6
ma4000(config)# do show qos
Priority assignment by NONE packet field, all priorities are equal
Default priority queue is 0
DSCP/TOS queues:
0:
1:
2:
3:
4:
5:
6: 0-4,15,63
802.1p queues:
0:
1:
2:
3:
4:
5:
6:
```

Step 4. Apply the configuration using the **commit** command:

```
ma4000(config)# do commit  
ma4000(config)# do confirm
```

19 LAG configuration

19.1 Introduction

This section describes configuration of uplink interfaces aggregation. Link aggregation (IEEE 802.3ad) is a technology that allows multiple physical links to be combined into one logical link (aggregation group). Aggregation group has a higher throughput and is very reliable.




Figure 26 – Multiple physical links combined to an aggregation group

The access node supports two interface aggregation modes: static and dynamic. Static aggregation implies that all communication links of a group are always active. As for dynamic aggregation, link activity is dynamically determined during operation via LACP.

Table 16 – Operation modes of aggregation groups

Mode	Description
static	link aggregation protocol is not used

Mode	Description
lacp	LACP is used

The access node supports several load balancing algorithms within an aggregation group.

Table 17 – Load balancing modes

Mode	Description
ip	based on IP address of sender and receiver
ip-l4	based on IP address of sender and receiver, and L4
mac	based on MAC address of sender and receiver
mac-ip	based on MAC address and IP address of sender and receiver
mac-ip-l4	based on MAC address, IP address and L4 of sender and receiver

The access node supports two LACP modes.

- Passive – MA40000 does not initiate creation of a logical link, but processes incoming LACP packets.
- Active – MA4000 creates an aggregated communication link and initiates parameters conformance. The parameters are coordinated if equipment operates in active or passive LACP modes.

19.2 LAG configuration

LAG configuration represents configuration of static aggregation or LACP. To configure LAG, perform the steps marked blue in [Figure 27](#). LACP configuration requires all steps to be performed.




Figure 27 – LAG and LACP configuration procedure

Step 1. Create a *port-channel* logical interface by using the **interface port-channel** command.

As a parameter, pass the number of the interface being created. Up to eight logical interfaces can be created.

```
ma4000(config)# interface port-channel 1
ma4000(express-config-port-channel-1)#
```

Step 2. Set general interface parameters: speed, duplex, flow-control, etc. Interfaces configuration is described in detail in the [Interface configuration](#) section.

Step 3. Configure aggregation by using the **mode** command. Pass the operation mode as a parameter. Operation modes are specified in [Table 16](#):

```
ma4000(express-config-port-channel-1)# mode lacp
```

Step 4. This step should only be performed for LACP configuration. Set a LACP system priority by using the **lacp system-priority** command. The **no lacp system-priority** command returns 32768 by default:

```
ma4000(express-config-port-channel-1)#exit
ma4000(config)# lacp system-priority 32768
```

Step 5. Specify load balance rules with the help of the **port-channel load-balance** command if needed. Pass the balance mode as a parameter. Balance modes are specified in [Table 17](#).

```
ma4000(config)# port-channel load-balance ip
```

Step 6. Add physical interfaces into the logical one by using the **channel-group** command. As a parameter, pass the number of the logical interface:

```
ma4000(config)# interface front-port 1/3-5
ma4000(front-port-1/3-5)# channel-group 1 normal
```

Step 7. This step should only be performed for LACP configuration. Set a priority for the physical interface with the help of the **lacp port-priority** command if necessary. The **no lacp port-priority** command resets port priority to the default value of 32768. 1 is the highest priority.

```
ma4000(front-port-1/3-5)# no lacp port-priority
ma4000(front-port-1/3-5)# exit
ma4000(config)# interface front-port 1/3
ma4000(front-port-1/3)# lacp port-priority 256
```

Step 8. This step should only be performed for LACP configuration. Use the **lacp mode** command to set an active or passive LACP mode:

```
ma4000(front-port-1/3)# exit
ma4000(config)# interface front-port 1/3-5
ma4000(front-port-1/3-5)# lacp mode active
```

Step 9. This step should only be performed for LACP configuration. In case of the active LACP mode, set an interval for transmission of LACP control packets with the help of the **lacp rate** command. Pass *slow* (30 seconds) or *fast* (1 second) as a parameter:

```
ma4000(front-port-1/3-5)# lacp rate slow
```

Step 10. Apply the configuration by using the **commit** command:

```
ma4000(front-port-1/3-5)# do commit
ma4000(front-port-1/3-5)# do confirm
```


20 Spanning Tree configuration

20.1 Introduction

Spanning Tree Protocol (STP) is a network protocol. The main task of STP is to eliminate loops in the arbitrary Ethernet network topology with one or multiple network bridges connected with redundant links. STP solves this task by automatically blocking connections that are redundant for the full switch interconnection at the given moment of time.

Spanning Tree configuration may be applied globally, or for selected front interfaces of LAGs only.

20.2 Spanning Tree configuration

Step 1. Enable STP with the **spanning-tree enable** command:

```
ma4000(config)# spanning-tree enable
```

Step 2. Define the spanning tree protocol type: STP, MST or RSTP:

```
ma4000(config)# spanning-tree mode rstp
```

Step 3. Define the command forwarding delay using the **spanning-tree fdelay** command. Forwarding delay is the time, during which the port remains in 'Listening' and 'Learning' states prior to going into 'Forwarding' state:

```
ma4000(config)# spanning-tree fdelay 10
```

Step 4. Specify the sending time for hello packets using the **spanning-tree hello¹** command:

```
ma4000(config)# spanning-tree hello 2
```

¹ Not used in this version (default value is 2)

Step 5. Define the STP bridge priority using the **spanning-tree priority** command:

```
ma4000(config)# spanning-tree priority 4096
```

Step 6. Set path value parameters for different interfaces:

```
ma4000(config)# interface front-port 1/3
ma4000(front-port-1/3)# spanning-tree pathcost 1
ma4000(front-port-1/3)# exit
ma4000(config)# interface front-port 1/4
ma4000(front-port-1/4)# spanning-tree pathcost 2
ma4000(front-port-1/4)# exit
```

Step 7. Define BPDU packet processing mode by the interface with disabled STP protocol.

Pass the operation mode as an argument.

- filtering – BPDU packets are filtrated on the interface with disabled STP;
- flooding – untagged BPDU packets are transmitted on the interface with disabled STP, tagged ones are filtrated.

```
ma4000(config)# spanning-tree bpdu flooding
```

Step 8. Define the maximum quantity of BPDU packets, that could be received by the device in a second of time, using the **spanning-tree holdcount** command:

```
ma4000(config)# spanning-tree holdcount 5
```

Step 9. If necessary, specify the BPDU packet timeout using the **spanning-tree maxage** command:

```
ma4000(config)# spanning-tree maxage 15
```

Step 10. If necessary, define the connection type as the edge link to the host (on configurable port/ports). In this case, data transmission is enabled automatically for the port, when the link is established:

```
ma4000(front-port 1/1)# spanning-tree admin-edge
```

Step 11. If necessary, define the automatic bridge identification for configured port(s):

```
ma4000(front-port 1/1)# spanning-tree auto-edge
```

Step 12. Apply the configuration using the **commit** command:

```
ma4000(config)# do commit  
ma4000(config)# do confirm
```

21 Dual Homing configuration

21.1 Introduction

The operating principle of *Dual Homing* technology is similar to the Spanning Tree technology. However, the Spanning Tree technology has a major disadvantage. If there are more than 7 computers in a network, fault identification and performance restoration can take up to several minutes. During this time, the network will not be available. While it may not be significant for office networks, loss of control for several minutes at production and transportation facilities, and financial institutions may lead to catastrophe.

In case of Dual Homing technology, these operations will take up just 3 seconds. To make a decision about switching to the reserve, the state of the master port is used, and when the main channel falls, it automatically switches to the reserve. After switching to the backup channel, the device generates a frame for each record in the table of mac source = record in the table, mac destination = 01:00:0c:cd:cd:cd. Then sends all these packages from the new interface.

21.2 Dual Homing configuration

Step 1. Switch to the selected interface or interface group configuration:

```
ma4000(config)# interface front-port 1/3
```

Step 2. Specify a redundant interface to which the switching will occur when the connection is lost on a primary one:

- ✔ **Redundancy is enabled only on those interfaces on which the SPANNING TREE protocol is disabled and VLAN Ingress Filtering is enabled. If the reserve is specified globally for the interface, it will be used for all VLANs. If another reserve is specified for some VLANs, this setting will take priority over the global setting.**

```
ma4000(front-port-1/3)# backup interface front-port 1/4 vlan 10
```

Step 3. Specify the packet quantity per second, that will be sent into the active interface during the fallback:

```
ma4000(front-port-1/3)#exit
ma4000(config) backup-interface mac-per-second 200
```

Step 4. Specify the quantity of packet copies per second, that will be sent into the active interface during the fallback:

```
ma4000(config)# backup-interface mac-duplicate 4
```

Step 5. If necessary, configure the switching to the main interface, when the communication is restored:

```
ma4000(config)# backup-interface preemption
```

Step 6. Apply the configuration using the **commit** command:

```
ma4000(config)# do commit
```

22 LLDP configuration

22.1 Introduction

Link Layer Discovery Protocol (LLDP) is a Data link layer protocol that allows network devices to announce information about themselves and their capabilities to the network, as well as to collect this information about neighboring devices.

22.2 LLDP configuration

Step 1. Enable LLDP for operation using **lldp enable** command:

```
ma4000(config)# lldp enable
```

Step 2. Specify the amount of time for the receiver to keep LLDP packets before dropping them:

```
ma4000(config)# lldp hold-multiplier 5
```

- ✔ **This value will be transmitted to the receiving side in the LLDP update packets; and should be an increment for the LLDP timer. Thus, the lifetime of LLDP packets is calculated by the formula: $TTL = \min(65535, LLDP-Timer * LLDP-HoldMultiplier)$.**

Step 3. Set LLDP reinitialization time:

```
ma4000(config)# lldp reinit 3
```

Step 4. Specify how frequently the device will send LLDP information updates:

```
ma4000(config)# lldp timer 60
```

Step 5. Specify the delay between the subsequent LLDP packet transmissions caused by the changes of values or status in the local LLDP MIB database:

```
ma4000(config)# lldp tx-delay 3
```

- ✔ **It is recommended that this delay be less than $0.25 * LLDP-Timer$.**

Step 6. Set LLDP packet processing mode:

- ✔ **LLDP packet processing mode:**
 - **filtering** – LLDP packets are filtered if LLDP is disabled on the switch;
 - **flooding** – LLDP packets are transmitted if LLDP is disabled on the switch.

```
ma4000(config)# lldp lldpdu flooding
```

Step 7. Apply the configuration using the **commit** command:

```
ma4000(config)# do commit
```

23 Multicast configuration

23.1 Introduction

The section describes peculiarities of IPTV service configuration.

Internet Group Management Protocol (IGMP) and MLD (Multicast Listener Discovery) are used in hosts and routers for multicasting support. It provides all systems of a physical network with relevant information: which hosts are included in groups and which group corresponds to a host.

IGMP snooping is a technique that allows network devices of the channel level (switches) to snoop IGMP requests from hosts to a group router in order to decide whether group traffic transmission to the corresponding interfaces should be started or stopped. When a switch snoops a host's IGMP request for connection to a multicast group, it adds the port the host is connected to into the group (for group traffic retranslation). Having snooped a `leave_group` request, the switch removes the corresponding port from the group.




Figure 28 – IGMP snooping is disabled

Figure 28 shows multicasting of IGMP traffic regardless of whether an end host needs the traffic or not. When IGMP snooping is enabled, the multicasting situation changes as follows: the switch will analyse all IGMP packets between connected devices and the routers the multicast traffic comes from. When the switch receives a consumer's IGMP request for connection to a multicast group, it adds the port the consumer is connected to into the group. And vice versa, having received a request for leaving a group, the switch removes the corresponding port from the group.




Figure 29 – IGMP snooping is enabled

As you may see from [Figure 29](#), access node with enabled IGMP snooping translates multicast traffic only to those trees, that have sent the IGMP group connection request.

IGMP proxy is an IGMP client and group router at the same time (IGMP router). On the one hand, proxy requests an upstream router for group channels; on the other hand, it receives join/leave requests from hosts and replicates upstream traffic to the corresponding interfaces.

MLD protocol in IPv6 is similar to IGMP in IPv4, thus above information is relevant to MLD protocol too.

23.2 Multicast configuration

Step 1. Enable IGMP snooping by using the **ip igmp snooping enable** command:

```
ma4000(vlan-100)# ip igmp snooping enable
```

Step 2. Configure IGMP protocol settings for a specific slot:

```
ma4000(vlan-100)# ip igmp slot 0 query-interval 100
ma4000(vlan-100)# ip igmp slot 0 robustness 3
ma4000(vlan-100)# ip igmp slot 0 query-response-interval 125
ma4000(vlan-100)# ip igmp slot 0 last-member-query-interval 25
```

Step 3. Enable *fast-leave* feature, if necessary:

```
ma4000(vlan-100)# ip igmp snooping querier fast-leave
```

Step 4. Specify the source of multicast traffic:

```
ma4000(vlan-100)# ip igmp snooping mrouter add front-port 1/4
```

Step 5. Enable *Querier* for the specific VLAN, if necessary:

```
ma4000(vlan-100)# ip igmp snooping querier enable
```

Step 6. Define processing policy for the unrequested multicast traffic:

```
ma4000(vlan-100)# exit
ma4000(config)# ip igmp unregistered ip4-mc drop
```

Step 7. If necessary, enable *IGMP proxy*:

```
ma4000(config)# ip igmp proxy report enable
```

Step 8. Define the rules for proxying from one VLAN into another. Pass the group range, source vlan, and destination vlan as parameters:

```
ma4000(config)# ip igmp proxy report range 224.0.0.0 239.255.255.255 from 100 to 98
```

Step 9. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
```

23.3 IPv6 Multicast configuration

Step 1. Enable MLD snooping by **ipv6 mld snooping enable** command:

```
ma4000(vlan-100)# ipv6 mld snooping enable
```

Step 2. Configure MLD protocol settings for a specific slot:

```
ma4000(vlan-100)# ipv6 mld slot 0 query-interval 100
ma4000(vlan-100)# ipv6 mld slot 0 robustness 3
ma4000(vlan-100)# ipv6 mld slot 0 query-response-interval 125
ma4000(vlan-100)# ipv6 mld slot 0 last-member-query-interval 25
```

Step 3. Enable *fast-leave* feature, if necessary:

```
ma4000(vlan-100)# ipv6 mld snooping querier fast-leave
```

Step 4. Specify the source of multicast traffic:

```
ma4000(vlan-100)# ipv6 mld snooping mrouter add front-port 1/4
```

Step 5. Enable *Querier* for the specific VLAN, if necessary:

```
ma4000(vlan-100)# ipv6 mld snooping querier enable
```

Step 6. Define processing policy for the unrequested multicast traffic:

```
ma4000(vlan-100)# exit
ma4000(config)# ipv6 mld unregistered ip6-mc drop
```

Step 7. If necessary, enable *MLD proxy*:

```
ma4000(config)# ipv6 mld proxy report enable
```

Step 8. Define the rules for proxying from one VLAN into another. Pass the group range, source vlan, and destination vlan as parameters:

```
ma4000(config)# ipv6 mld proxy report range ff15:: ff15::ffff from all to 30
```

Step 9. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
```


24 DHCP Relay Agent configuration

24.1 Introduction

This section describes configuration of *DHCP Relay Agent* in the access node.

DHCP Relay Agent is used to provide a DHCP server with additional information about a received DHCP request. This may include information about the device running DHCP Relay Agent as well as information about the ONT, which sent the DHCP request. DHCP packets are modified by interception and further processing in the device CPU.

The DHCP server identifies the ONT by analyzing *DHCP option 82* and *DHCPv6 options 37 and 38*. DHCP Relay Agent allows the option to be both transparently transmitted from the ONT and formed/rewritten according to a specified format. DHCP option 82 is especially useful for networks, which have no private VLANs dedicated for each user.

DHCP Relay Agent supports configurable formats for both *Circuit ID* and *Remote ID*. The format of the suboptions is configured with the help of the tokens listed in [Table 18](#). DHCPv6 Relay Agent supports adjustable format for Interface ID and Remote ID suboptions. The configuration of suboption format is performed by using tokens represented in [Table 19](#). The placeholders will be replaced with corresponding values, while the rest of the words will be passed as is.

Table 18 – DHCP Option 82 tokens

Token	Description
%HOSTNAME%	The access node network name
%SLOTID %	MA4000 slot number
%MNGIP%	The IP address of the access node.
%GPON-PORT%	The number of PON port from which DHCP request has been received
%ONTID%	ID of the ONT, which sent the DHCP request
%PONSERIAL%	Serial number of the ONT, which sent the DHCP request
%GEMID%	ID of the GEM port the DHCP request arrived to
%VLAN0%	External VID
%VLAN1%	Internal VID
%MAC%	MAC address of the ONT, which sent the request
%OPT60%	DHCP option 60 received from the ONT
%OPT82_CID%	Circuit ID received from the ONT

Token	Description
%OPT82_RID%	Remote ID received from the ONT
%DESCR%	ONT description

Table 19 – DHCPv6 option 37 and 38 Tokens

Token	Description
%HOSTNAME%	The access node network name
%MNGIP%	The IP address of the access node
%GPON-PORT%	The number of PON port from which DHCP request has been received
%ONTID%	ID of the ONT, which sent the DHCP request
%PONSERIAL%	Serial number of the ONT, which sent the DHCP request
%GEMID%	ID of the GEM port the DHCP request arrived to
%VLAN0%	External VID
%VLAN1%	Internal VID
%MAC%	MAC address of the ONT, which sent the request
%SLOTID%	MA4000 slot number
%DESCR%	ONT description

In addition to DHCP option 82, DHCP Relay Agent has some more functions related to network security. It provides protection from DoS attacks by setting a threshold for intensity of DHCP messages, which are received from ONT. Exceeding the threshold blocks DHCP requests. The blocking time can be configured.

It also protects from illegal DHCP servers by controlling the source IP address of DHCP responses. Transmitted are only the DHCP responses, which arrived from IP addresses of trusted DHCP servers.

24.2 DHCP Relay Agent profiles management

A set of profiles is used for DHCP Relay Agent configuration. All VLANs use dhcp-ra-00 profile by default.

The configuration is flexible as it allows DHCP profiles to be assigned not only to a MA4000 slot, but separately to each VLAN as well. To assign a profile, the following steps should be taken.

Step 1. Assign the default profile for all VLANs with the help of the **slot <id> profile dhcp-ra** command:

```
ma4000# configure terminal
ma4000(config)# slot 0 profile dhcp-ra dhcp-ra-00
```

Step 2. Create a new *DHCP Relay Agent* profile with the help of the **profile dhcp-ra** command if necessary. Pass profile name as a parameter:

```
ma4000(config)# profile dhcp-ra dhcp-ra-01
ma4000(config-dhcp-ra)("dhcp-ra-01")# exit
```

Step 3. If necessary assign the newly created profile to the selected VLAN with the **slot <id> profile dhcp-ra** command. As a parameter, pass the profile name and VLAN ID:

```
ma4000(config)# slot 0 profile dhcp-ra dhcp-ra-01 vlan 100
```

Step 4. Check the changes by using the **show slot <id> gpon olt configuration** command:

```
ma4000(config) do show slot 0 gpon olt configuration
Profile pppoe-ia:                pppoe-ia-00                OLT Profile PPPoE Intermediate
Agent 0
Profile dhcp-ra:                 dhcp-ra-00                 OLT Profile DHCP Relay Agent 0
Profile dhcp-ra per VLAN 100 [0]:
Profile:                         dhcp-ra-01                 OLT Profile DHCP Relay Agent 1
```

Step 5. Apply the changes by using the **commit** command:

```
ma4000(config)# do commit
```

24.3 DHCP Relay Agent profiles configuration

Step 1. Switch to the corresponding DHCP Relay Agent profile:

```
ma4000(config)# profile dhcp-ra dhcp-ra-01
```

Step 2. Enable DHCP traffic processing with the **enable** command:

```
ma4000(config-dhcp-ra)("dhcp-ra-01")# enable
```

Step 3. Enable insert/overwrite of DHCP option 82 with the help of the **overwrite-option82** command if needed:

```
ma4000(config-dhcp-ra)("dhcp-ra-01")# overwrite-option82
```

Step 4. Specify the DHCP option 82 format with the help of the **overwrite-option82 circuit-id** and **overwrite-option82 remote-id** commands if needed. A list of possible tokens is given in [Table 18](#):

```
ma4000(config-dhcp-ra)("dhcp-ra-01")# overwrite-option82 circuit-id "%PONSERIAL%"
ma4000(config-dhcp-ra)("dhcp-ra-01")# overwrite-option82 remote-id "%OPT82_RID%"
```

Step 5. Enable DoS attack protection with the help of the **dos-block** command if needed. Specify a threshold for the number of DHCP queries per second that will block queries when exceeded. Use the **dos-block packet-limit** command for it. Use the **dos-block block-time** command to specify the blocking time in seconds:

```
ma4000(config-dhcp-ra)("dhcp-ra-01"># dos-block
ma4000(config-dhcp-ra)("dhcp-ra-01"># dos-block packet-limit 200
ma4000(config-dhcp-ra)("dhcp-ra-01"># dos-block block-time 300
```

Step 6. Set a list of trusted DHCP servers with the help of the **trusted-primary** and **trusted-secondary** commands. Specify a response timeout for DHCP servers by using the **trusted-timeout** command. Activate filters with the help of the **trusted** command:

```
ma4000(config-dhcp-ra)("dhcp-ra-01"># trusted primary 10.0.0.1
ma4000(config-dhcp-ra)("dhcp-ra-01"># trusted secondary 10.0.0.2
ma4000(config-dhcp-ra)("dhcp-ra-01"># trusted timeout 200
ma4000(config-dhcp-ra)("dhcp-ra-01"># trusted
```

Step 7. Apply the changes by using the **commit** command:

```
ma4000(config-dhcp-ra)("dhcp-ra-01"># do commit
```

✔ To apply the changes, the OLT should be reconfigured.

24.4 DHCPv6 Relay Agent profiles management

A set of profiles is used for DHCPv6 Relay Agent configuration. All VLANs use dhcpv6-ra-00 profile by default. The configuration is flexible as it allows DHCPv6 profiles to be assigned not only to a MA4000 slot, but separately to each VLAN as well. To assign a profile, the following steps should be taken.

Step 1. Assign the default profile for all VLANs with the help of the **slot <id> profile dhcpv6-ra** command:

```
ma4000# configure terminal
ma4000(config)# slot 0 profile dhcpv6-ra dhcpv6-ra-00
```

Step 2. Create a new *DHCPv6 Relay Agent* profile with the help of the **profile dhcpv6-ra** command if necessary. Pass profile name as a parameter:

```
ma4000(config)# profile dhcpv6-ra dhcpv6-ra-01
ma4000(config-dhcpv6-ra)("dhcpv6-ra-01"># exit
```

Step 3. If necessary assign the newly created profile to the selected VLAN with the **slot <id> profile dhcpv6-ra** command. As a parameter, pass the profile name and VLAN ID:

```
ma4000(config)# slot 0 profile dhcpv6-ra dhcpv6-ra-01 vlan 100
```

Step 4. Check the changes by using the **show slot <id> gpon olt configuration** command:

```
ma4000# show slot 1 gpon olt configuration
    Profile pppoe-ia:                pppoe-ia-00      OLT Profile PPPoE
Intermediate Agent 0
    Profile dhcp-ra:                 dhcp-ra-00       OLT Profile DHCP Relay
Agent 0
    Profile dhcp-ra per VLAN:        <list is empty>
    Profile dhcpv6-ra per VLAN:     <list is empty>
    Profile dhcpv6-ra:              dhcpv6-ra-00     OLT Profile DHCPv6
Relay Agent 0
```

Step 5. Apply the changes by using the **commit** command:

```
ma4000(config)# do commit
```

24.5 DHCPv6 Relay Agent profiles configuration

Step 1. Switch to the corresponding DHCP Relay Agent profile:

```
ma4000(config)# profile dhcpv6-ra dhcpv6-ra-01
```

Step 2. Enable DHCPv6 traffic processing with the **enable** command:

```
ma4000(config-dhcpv6-ra)("dhcpv6-ra-01")# enable
```

Step 3. If necessary, enable adding of DHCPv6 option 37 and 38 by **add-suboptions** command:

```
ma4000(config-dhcp-ra)("dhcp-ra-01")# add-suboptions
```

Step 4. If necessary, define DHCPv6 option 37 and 38 formats, using **add-remote-id** and **add-interface-id** commands. A list of possible tokens is given in [Table 19](#):

```
ma4000(config-dhcpv6-ra)("dhcp-rav6-01")# add-interface-id "%PONSERIAL%"
ma4000(config-dhcpv6-ra)("dhcp-rav6-01")# add-remote-id "%OPT82_RID%"
```

Step 5. Enable DoS attack protection with the help of the **dos-block** command if needed. Specify a threshold for the number of DHCP queries per second that will block queries when exceeded. Use the **dos-block packet-limit** command for it. Use the **dos-block block-time** command to specify the blocking time in seconds:

```
ma4000(config-dhcpv6-ra)("dhcpv6-ra-01")# dos-block
ma4000(config-dhcpv6-ra)("dhcpv6-ra-01")# dos-block packet-limit 200
ma4000(config-dhcpv6-ra)("dhcpv6-ra-01")# dos-block block-time 300
```

Step 6. Set a list of trusted DHCP servers with the help of the **trusted-primary** and **trusted-secondary** commands. Specify a response timeout for DHCP servers by using the **trusted-timeout** command. Activate filters with the help of the **trusted** command:

```
ma4000(config-dhcpv6-ra)("dhcp-rav6-01")# trusted primary 1010::1
ma4000(config-dhcpv6-ra)("dhcp-rav6-01")# trusted secondary 1010::2
ma4000(config-dhcpv6-ra)("dhcp-rav6-01")# trusted timeout 200
ma4000(config-dhcpv6-ra)("dhcp-rav6-01")# trusted
```

Step 7. Apply the changes by using the **commit** command:

```
ma4000(config-dhcp-ra)("dhcp-ra-01")# do commit
```

 **To apply the changes, the OLT should be reconfigured.**

24.6 Broadcast-unicast relay configuration

To reduce the broadcast traffic and avoid responses from illegal DHCP-servers, unicast messages can be configured to interact with the specified DHCP Relay Agent.

Step 1. Create L3 interface: define IP address on VLAN in which customer devices are located, using **ip interface** command (only for single-tag service):

```
ma4000(config)# vlan 2000
ma4000(vlan-2000)# ip interface 10.10.10.10/32
```

Step 2. Create an L3 interface by specifying the IP address of the VLAN, which is used for switching in the network where the DHCP server is located:

```
ma4000(config)# vlan 1209
ma4000(vlan-1209)# ip interface 192.168.209.240/24
```

Step 3. Specify the DHCP server address. If necessary, you can specify up to three addresses. If the address of the DHCP server are located after the router available after the specified L3 interface, configure a static route:

```
ma4000(vlan-1209)# relay 192.168.56.1
ma4000(vlan-1209)# relay 192.168.66.1
ma4000(vlan-1209)# relay 192.168.76.1
ma4000(config)# ip route allow 192.168.56.0/24 192.168.209.5
ma4000(config)# ip route allow 192.168.66.0/24 192.168.209.5
```

25 PPPoE Intermediate Agent configuration

25.1 Introduction

This section describes configuration of *PPPoE Intermediate Agent* of the access node.

PPPoE Intermediate Agent is used to provide BRAS with additional information about a received PADI request. This may include information about the node running PPPoE Intermediate Agent as well as information about the ONT, which sent the PADI request. PADI packets are modified by interception and further processing in the access node CPU.

BRAS analyses the Vendor Specific tag and identifies the ONT. PPPoE Intermediate Agent forms or rewrites the Vendor Specific tag using a specified format. Vendor Specific tags are especially useful for networks, which have no private VLANs dedicated for each user.

PPPoE Intermediate Agent supports configurable formats for Circuit ID and Remote ID. The format of the suboptions is configured with the help of the tokens listed in [Table 20](#). The placeholders will be replaced with corresponding values, while the rest of the words will be passed as is.

Table 20 – Vendor Specific tag tokens

Token	Description
%HOSTNAME%	The access node network name
%SLOTID%	MA4000 slot number
%MNGIP%	The IP address of the access node.
%GPON-PORT%	The number of PON port from which PADI has been received
%ONTID%	ID of the ONT, which sent the PADI request
%PONSERIAL%	Serial number of the ONT, which sent the DHCP request
%GEMID%	ID of the GEM port the PADI request arrived to
%VLAN0%	External VID
%VLAN1%	Internal VID
%MAC%	MAC address of the ONT, which sent the request
%DESCR%	First 20 characters of ONT configuration description

In addition to vendor specific tag support, PPPoE Intermediate Agent has some more functions related to network security. It provides protection from DoS attacks by setting a threshold for intensity of PADI messages, which are received from ONT. Exceeding the threshold blocks PADI requests. The blocking time can be configured.

PPPoE Intermediate Agent also limits the number of simultaneous PPPoE sessions. The restriction can be set for both the total number of access node sessions and for every ONT separately.

25.2 PPPoE Intermediate Agent profiles configuration

To configure PPPoE Intermediate Agent:

Step 1. Switch to the PPPoE Intermediate Agent profile:

```
ma4000# configure terminal
ma4000(config)# profile pppoe-ia pppoe-ia-00
ma4000(config-pppoe-ia)("pppoe-ia-00")#
```

Step 2. Enable PPPoE traffic processing with the **enable** command:

```
ma4000(config-pppoe-ia)("pppoe-ia-00")# enable
```

Step 3. Specify the vendor specific tag format with the help of the **format circuit-id** and **format remote-id** commands. A list of possible tokens is given in [Table 20](#):

```
ma4000(config-pppoe-ia)("pppoe-ia-00")# format circuit-id "%HOSTNAME%"
ma4000(config-pppoe-ia)("pppoe-ia-00")# format remote-id "%GEMID%"
```

Step 4. Enable DoS attack protection with the help of the **dos-block** command if needed. Specify a threshold for the number of DHCP queries per second that will block queries when exceeded. Use the **dos-block packet-limit** command for it. Use the **dos-block block-time** command to specify the blocking time in seconds:

```
ma4000(config-pppoe-ia)("pppoe-ia-00")# dos-block
ma4000(config-pppoe-ia)("pppoe-ia-00")# dos-block packet-limit 200
ma4000(config-pppoe-ia)("pppoe-ia-00")# dos-block block-time 300
```

Step 5. Set the limits of PPPoE sessions by using the **sessions-limit** command:

```
ma4000(config-pppoe-ia)("pppoe-ia-00")# sessions-limit 128 per-user 2
```

Step 6. If necessary, disable session monitoring with the command **no sessions-monitoring enable**:

```
ma4000(config-pppoe-ia)("pppoe-ia-00")# no sessions-monitoring enable
```

Step 7. Apply the changes by using the **commit** command:

```
ma4000(config-pppoe-ia)("pppoe-ia-00")# do commit
ma4000(config-pppoe-ia)("pppoe-ia-00")# do confirm
```

✔ To apply the changes, the OLT should be reconfigured.

26 IP Source Guard configuration

26.1 Introduction

The IP Source Guard function allows restriction of unauthorised usage of IP addresses in the network by linking IP and MAC addresses of the source to a specific service on a specific ONT. There are two operation modes:

- To enable transmission of any traffic from clients, it is necessary to specify an explicit match between MAC and IP addresses of client equipment.
- Client equipment obtains its address via the DHCP protocol. Based on data exchange between client equipment and the DHCP server, a DHCP snooping table is generated on the OLT that contains MAC-IP-GEM port matches and information about lease period. Only the packets with source MAC and source IP fields matching the records in the DHCP snooping table are passed from the client. To support client equipment with static IP addresses, static entries can be created in the dynamic mode.

✔ **To enable the IP Source Guard functions, enable DHCP-RA. For more information on DHCP-RA, see [DHCP Relay Agent Configuration](#) section.**

✔ **These functionality is not supported in Model 1 (for more information about models, see [Service models](#))**

✔ **When IP Source Guard is enabled, any non-IP traffic is forbidden.**

26.2 IP Source Guard configuration

Step 1. Switch to the **configure** view:

```
ma4000# configure terminal
```

Step 2. Enable IP Source Guard and specify the mode:

```
ma4000(config)# ip source-guard enable
ma4000(config)# ip source-guard mode dynamic
```

Step 3. If necessary, disable IP Source-Guard for a particular VLAN:

```
ma4000(config)# ip source-guard ignore-vlan 1000
```

Step 4. Apply changes by the do commit command:

```
ma4000(config)# do commit
```

✔ **After the IPSG mode has been enabled/disabled/changed, the OLT is reconfigured automatically.**

To add static matches, use the following command:

```
ma4000(config)# ip source-guard bind ip <IP> mac <MAC> interface-ont <ONT> service <NUM>
```

Where:

- IP – IP address of client equipment in X.X.X.X format,
- MAC – MAC address of client equipment in XX:XX:XX:XX:XX:XX format,
- ONT – ONT identifier in SLOT_ID/CNANNEL_ID/ONT_ID format,
- NUM – ONT service number, through which traffic with specific addresses will be transmitted, from 0 to 7.

To disable IP Source Guard and remove static matches, use the negative no command:

```
ma4000(config)# no ip source-guard enable
ma4000(config)# no ip source-guard bind
ma4000(config)# no ip source-guard bind ip <IP>
```

To view information about the status, mode, and static matches, use the show command:

```
ma4000# show slot 1 ip source-guard
IP Source Guard:
  Enabled:                true
  Mode:                   dynamic
  Bind [0]:
    Ip:                   192.168.200.90
    Mac:                   00:22:B0:50:59:71
    Interface-ont:        1/0/4
    Service:               2
```

27 Configuring PLC line board traffic filtering

You can use access-list functionality to control traffic passing through line cards. There are two options of this functionality, access-list mode whitelist – all the non-restricted traffic will be processed, access-list mode blacklist (default behavior) – all the non-allowed traffic will be discarded.

Example: Restrict incoming http traffic on pon-port 8/0

Step 1. Create the list:

```
ma4000(config)# slot 8 access-list create deny_http
```

Step 2. Add rule in the list.

✔ **The port is specified in hex format.**

```
ma4000(config)# slot 8 access-list filter add tcp-dport 0x50 deny_http
```

Step 3. Bind the list of rules to the interface:

```
ma4000(config)# slot 8 access-list bind plc-pon-port 8/0 deny_http
```

Step 4. Apply changes:

```
ma4000(acl-ip)# do commit  
ma4000(acl-ip)# do confirm
```

To unbind the list from the interface, use the **unbind** command:

```
ma4000(config)# slot 8 access-list unbind plc-pon-port 8/0 deny_http
```

28 Service models

This section considers main terms and classification of service models.

28.1 Introduction

In general, a service model is based on a method which describes how the services are provided: 'VLAN for Subscriber' or 'VLAN for Service'. The VLAN for Service architecture means that a service VLAN (S-VLAN) is used to provide users with a certain service. The VLAN for Subscriber architecture implies that a client VLAN (C-VLAN) is used to provide a user with multiple services. These methods are often combined in practice and form a hybrid model, which uses S-VLAN and C-VLAN simultaneously.

28.1.1 VLAN for Subscriber architecture

A separate VLAN is used for each subscriber in the C-VLAN model. A dedicated C-VLAN is used to provide services to each user between the OLT and service routers. Service GEM ports are created for every OLT service between every ONT and the OLT. When a service request is generated upstream, records are added to the MAC table in the OLT according to C-VLAN. In case of downstream traffic, a corresponding GEM port is determined for a definite service according to the MAC table in the OLT.

If the destination address of the downstream transmission is unknown (broadcast or unknown unicast), i. e. the GEM port cannot be determined, two options are available:

- transmission through a dedicated broadcast GEM port;
- transmission to all GEM ports, which correspond to the services provided to the subscriber.

If destination address of downstream transmission is not known (broadcast or unknown unicast), i. e. the GEM port cannot be determined, it will be determined based on the method implemented in a definite service model.

The architecture of this service model is shown in [Figure 30](#).




Figure 30 – 'VLAN for subscriber' service model architecture

28.1.2 VLAN for Service architecture

The S-VLAN model has a separate VLAN for every service. Consider its operation on an example of an abstract S-VLAN 100 service.

S-VLAN 100 is used between the OLT and service routers that is global for all subscribers in terms of this service. When a service request is generated upstream, records are added to the MAC table in the OLT according to S-VLAN and subscriber's MAC address. In case of downstream traffic, a corresponding subscriber of the service is determined based on the MAC table.

If the destination address of the downstream transmission is unknown (broadcast or unknown unicast), i. e. the GEM port cannot be determined, two options are available:

- transmission through a dedicated broadcast GEM port (traffic is transmitted to all subscribers);
- transmission to every subscriber through a GEM port corresponding to the service.

If destination address of downstream transmission is not known (broadcast or unknown unicast), i. e. the GEM port cannot be determined, it will be determined based on the method implemented in a definite service model.

The architecture of this service model is shown in [Figure 31](#).




Figure 31 – 'VLAN for service' service model architecture

28.2 Operating principle

The configuration model concept is used for implementation of different service models in the access node. A configuration model defines general principles for data communication channelling for both OLT and ONTs.

- Model 1 is an implementation of the 'VLAN for Subscriber' service model. The model does not have dedicated broadcast GEM ports and uses U-VLAN on the ONT side.
- Model 2 is an implementation of the 'VLAN for Service' service model. This model uses a dedicated broadcast GEM port.
- Model 3 is an implementation of the 'VLAN for Service' service model. This model uses a dedicated broadcast GEM port. It differs from Model 2 by the order of S-VLAN to U-VLAN modification.

✔ **After changing the model, the OLT will be automatically reconfigured.**

Table 21 – Service Models

	VLAN for service	VLAN for subscriber	Broadcast to Unicast GEM	Dedicated Broadcast GEM
Model 1	-	+	+	-
Model 2	-	+	-	+
Model 3	+	-	-	+

28.2.1 Model 1

Consider an example of Model 1 implementation. The chart of this service model is shown in the [Figure 32](#).




Figure 32 – Service model 1 chart

A C-VLAN is used between an ONT and service routers (BRAS, VoIP SR) that encapsulate services for one subscriber (one ONT), such as VoIP, Internet, and IPTV unicast. An S-VLAN that is global for all subscribers (ONTs) is used for the TR-069 management service. Corresponding GEM ports are created for every OLT service between the ONTs and OLT. A dedicated MC-VLAN is used for multicast transmissions.

The OLT casts C-VLAN (for VoIP, Internet, and IPTV unicast) or S-VLAN (for TR-069) and GEM port number for every service into a corresponding U-VLAN. An ONT associates the U-VLAN with corresponding ONT interfaces or program modules. For example, the TR-069 service is associated with a TR-069 client with the help of a corresponding interface. The VoIP, Internet, and IPTV unicast services can operate in the router or bridge modes depending on the ONT configuration. The chart shows all services configured in the router mode.

Broadcast and unknown unicast traffic is transmitted in this model by replicating a corresponding packet (broadcast or unknown unicast) to the OLT. C-VLAN replicates services to all associated GEM ports and at the same time translates data to the corresponding U-VLAN for each service. The TR-069 service is replicated between the corresponding GEM ports of all subscribers (ONTs). Thus, the model implements 'VLAN for Subscriber' for the VoIP, Internet, and IPTV unicast services, but uses 'VLAN for Service' for the TR-069 service.

28.2.2 Model 2

Consider an example of Model 2 implementation. The chart of this service model is shown in the [Figure 33](#).




Figure 33 – Service model 2 chart

Dedicated S-VLANs are used between the OLT and service routers (BRAS, VoIP SR) for each of the following services: VoIP, Internet, IPTV unicast, TR-069. Dedicated S-VLANs are common for all subscribers (ONTs). Corresponding GEM ports are created for every OLT service between the ONTs and OLT. A dedicated MC-VLAN is used for multicast transmissions.

OLT transmits S-VLAN into a corresponding U-VLAN for each service. An ONT associates the U-VLAN with corresponding ONT interfaces or program modules. For example, the TR-069 service is associated with a TR-069 client with the help of a corresponding interface. The VoIP, Internet, and IPTV unicast services can operate in the router or bridge modes depending on the ONT configuration. The chart shows all services configured in the router mode.

All broadcast and unknown unicast traffic is redirected to a dedicated broadcast GEM port in this model. Broadcast and unknown unicast packets are sent to C-VLAN (for VoIP, Internet, and IPTV unicast services) in ONT. In general, the model is similar to model 3 except the one thing: transmission of C-VLAN to U-VLAN is performed on the OLT side; VoIP, Internet, and IPTV unicast traffic comes in U-VLAN to ONT.

Thus, the model implements VLAN for Service for the VoIP, Internet, IPTV unicast, and TR-069 services.

28.2.3 Model 3

Consider an example of Model 3 implementation.

The chart of this service model is shown in the [Figure 34](#).

Dedicated S-VLANs are used between the OLT and service routers (BRAS, VoIP SR) for each of the following services: VoIP, Internet, IPTV unicast, TR-069. These S-VLANs are common for all subscribers (ONTs). Corresponding GEM ports are created for every OLT service between the ONTs and OLT. A dedicated MC-VLAN is used for multicast transmissions.

The VoIP, Internet, IPTV, and TR-069 unicast services are associated with S-VLAN in an ONT. The ONT transmits S-VLAN into a corresponding U-VLAN for each service. An ONT associates the U-VLAN with corresponding ONT interfaces or program modules. For example, the TR-069 service is associated with a TR-069 client with the help of a corresponding interface. The VoIP, Internet, and IPTV unicast services can operate in the router or bridge modes depending on the ONT configuration. The chart shows all services configured in the router mode.

All broadcast and unknown unicast traffic is redirected to a dedicated broadcast GEM port in this model. Broadcast and unknown unicast packets come to S-VLAN in the ONT. These packets are transmitted into the corresponding U-VLANs on the ONT side. In this case, broadcast and unknown unicast are replicated neither in the OLT nor in the ONT since every service has a separate S-VLAN for broadcast and unknown unicast traffic.




Figure 34 – Service model 3 chart

Thus, the model implements VLAN for Service.

Internet, IPTV unicast, TR-069 service is provided on a 'VLAN for service' principle.

28.2.4 Summary conversion table

For illustrative presentation there is an example of passing a service with two VLAN S:C labels.




Figure 35 – Summary conversion table

28.3 Model configuration

Step 1. Check the current configuration with the help of the **show gpon olt** command:

```
ma4000# show gpon olt
  Block duplicated mac:          enabled
  DBA reduced latency:         disabled
  Ont block time:              5
  Dhcprr shaper:              100
  Datapath:
    Model:                      modell
    Broadcast gem port:        4095
    Multicast gem port:        4094
  Encryption:
    Enable:                    false
    Key update interval:       1
  ONT authentication mode:     both
  Auto reconfigure ont:        true
  Auto reconfigure channel:    true
  Auto reconfigure olt:        true
  Ont sn format:               literal
```

Step 2. Set the model by using the **gpon olt model** command:

```
ma4000# configure terminal
ma4000(config)# gpon olt model 1
```

Step 3. Apply the changes by using the **commit** command:

```
ma4000(config)# do commit
```

29 ONT configuration

29.1 Introduction

This section describes general principles of ONT configuration. It also defines configuration profiles.

ONT is configured with the help of a profile, which defines high-level expression of data communication channels. All operations related to channel creation are performed automatically. The way the data communication channels are created depends on the selected service model (see Section [Service models](#)).

ONT configuration includes assignment of configuration profiles and specification of ONT specific parameters. Configuration profiles allow general parameters to be set for all or for a range of ONTs. Profile parameters may include, for instance, DBA settings, configuration of VLAN operations in OLT and ONT, settings of Ethernet ports in ONT. Specific ONT parameters allow each separate ONT to have its own settings specified. Such settings include, for example, GPON password, subscriber's VLAN.

29.2 General principles of configuration

Service is the key term of ONT configuration. This term completely includes a channel through which data is transferred from the interfaces located on the front panel of the terminal (see Section [Interface configuration](#)) to users' ports of ONT.

There are two service profiles: *cross-connect* and *dba*. The *cross-connect* profile creates a GEM service port, the *dba* profile allocates an Alloc-ID for this ONT and associates a corresponding GEM port to the Alloc-ID.

Table 22 – ONT profile description

Profile	Description
cross-connect	Defines VLAN transformation in OLT and ONT
dba	Defines upstream traffic parameters
shaping	Defines restrictions for upstream and downstream service traffic
management	Defines TR-69 management service parameters
ports	Defines user port groups in ONT as well as IGMP and multicast parameters for user ports




Figure 36 – ONT scope of operation

29.3 ONT profiles configuration

29.3.1 Cross-connect profile configuration

Step 1. To configure a *cross-connect* profile, first you need to specify whether the service will be *routed* (transmitted through an ONT router) or *bridged* (use bridge connection). This can be done by changing the **model** parameter.

Step 2. Then, you need to specify a service type in the **type** parameter. Some service types require the **iphost-*eid*** parameter to be set that allows you to choose a definite instance of IP interface in the ONT.

Step 3. A VLAN is configured in a cross-connect profile with the help of the following parameters: **tag-mode**, **outer vid**, **outer-cos**, **inner-vid**, **u-vid**, **u-cos**.

Step 4. **tag-mode** enables upstream Q-in-Q mode; **outer-vid**, **outer-cos**, and **inner-vid** specify internal and external Q-in-Q tags correspondingly. The CoS value of the internal tag is copied from the external one in this case. If the Q-in-Q mode is not used, only the **outer-vid** and **outer-cos** parameters are valid. The **u-vid** and **u-cos** parameters allow a tag to be specified, which will be used on the ONT side.

Step 5. The **mac-table-entry-limit** parameter allows restriction of records number in the MAC table of the OLT for this service.

Step 6. The **priority-queue** parameter allows allocation of all services of one T-CONT into queues with priorities (if ONT supports this method).

29.3.2 DBA profile configuration

This profile configures *dynamic bandwidth allocation (DBA)*. These parameters allow specification of any T-CONT type described in G.984.3.

Step 1. First of all, choose **service-class** to define the basic DBA algorithm.

Step 2. After that, configure **status-reporting** to define the type of ONT queues status report.

Step 3. The **fixed-bandwidth**, **guaranteed-bandwidth**, and **besteffort-bandwidth** parameters define the fixed, guaranteed, and best-effort bandwidth correspondingly.

DBA configuration is described in detail in [DBA configuration](#).

29.3.3 Shaper profile configuration

Configuration of this profile allows restriction of upstream and downstream services.

Step 1. Downstream restriction in OLT uses the *policing* algorithm. The restriction can either use one policer for all services or individual policers for each separate service. This is specified in the **one-policer** parameter. When one policer is used for all services, only **policer 0** should be specified; otherwise, policers for all services should be adjusted.

Step 2. Upstream restriction in ONT uses the *shaping* algorithm. You can specify either a global shaper or individual shapers for unicast, multicast, and broadcast traffic (ONT functionality).

29.3.4 Ports profile configuration

The *ports* profile allows you to group ports in ONT. The profile also contains IGMP and multicast setting as they are separately adjusted for each port.

You can adjust up to 4 Ethernet ports and a VEIP virtual port, which will serve as a link between the OMCI and RG domains in ONT.

Step 1. Ethernet ports are grouped with the help of the **bridge group** parameter. Value 0 means that the port is associated with the RG domain (router). Other values mean port association with the OMCI domain, i. e. the port can be directly used in OLT to establish a data communication channel.

Step 2. IGMP and multicast configuration is described in details in Section [Multicast configuration](#).

29.3.5 Management profile configuration

The *management* profile enables specific configuration of the TR-069 management protocol, namely configuration of a TR-client in ONT.

Step 1. The **enable-omci-configuration** parameter defines the TR client configuration which can be done either automatically with DHCP (all other parameters of the profile are not used in this case) or with OMCI using the profile settings.

Step 2. The **url** parameter corresponds to the address of the auto configuration server (ACS), which access parameters are defined by the **username** and **password** parameters.

The TR-069 protocol configuration is described in details in Section [TR-069 management configuration](#).

29.4 ONT configuration procedure

Figure 37 shows a step-by-step procedure of ONT configuration.




Figure 37 – ONT configuration procedure

Step 1. Prior to proceed to ONT configuration, add an ONT into the OLT configuration. For an ONT to be added and configured, it does not need to be physically connected to the OLT. You can view the list of inactive ONTs with the help of the **show interface ont unactivated** command:

```
ma4000# show interface ont 0/0/0 unactivated

Slot 0 GPON-port 0 has no unactivated ONTs

Slot 0 total ONT count: 0
```

Step 2. To specify ONT settings, go to the corresponding view with the help of the **interface ont** command. Specify ONT serial number, password, or their combination:

```
ma4000# configure terminal
ma4000(config)# interface ont 0/0/0
ma4000(config)(if-ont-0/0/0)# serial ELTX5C00008C
ma4000(config)(if-ont-0/0/0)# password 0000000000
```

Step 3. Apply the configuration by using the **commit** command:

```
ma4000(config)(if-ont-0/0/0)# do commit
```

Step 4. OLT entry configuration has pre-defined ONT profiles which will be automatically assigned to ONT. View the ONT configuration by using the **do show interface ont 0/0/0 configuration** command:

```
ma4000(config)(if-ont-0/0/0)# do show interface ont 0/0/0 configuration
```

```
-----
[ONT0/0] configuration
-----
```

```

Description:          ''
Status:              UP
Serial:              0000000000000000
Password:            ''
Fec up:              false
Downstream broadcast: true
Ber interval:        100000
Ber update period:   60
Rf port state:       no change
Omci error tolerant: false
Service [0]:
  Profile cross connect: crossconnect-00   ONT Profile Cross
Connect 0
  Profile dba:          dba-00           ONT Profile DBA 0
Service [1]:
  Profile cross connect: unassigned
  Profile dba:          unassigned
Service [2]:
  Profile cross connect: unassigned
  Profile dba:          unassigned
Service [3]:
  Profile cross connect: unassigned
  Profile dba:          unassigned
Service [4]:
  Profile cross connect: unassigned
  Profile dba:          unassigned
Service [5]:
  Profile cross connect: unassigned
  Profile dba:          unassigned
Service [6]:
  Profile cross connect: unassigned
  Profile dba:          unassigned
Service [7]:
  Profile cross connect: unassigned
  Profile dba:          unassigned
Profile shaping:     shaping-00         ONT Profile Shaping 0
Profile ports:       ports-00          ONT Profile Ports 0
Profile management:  management-00     ONT Profile Management
0
Profile scripting:   unassigned
Custom model:        none
Template:            unassigned
Pppoe sessions unlimited: false
Ports:
  Port [0]:
    shutdown:        false
    PoE:
      Enable:        false
      Pse class control: 0
      Power priority: high
  Port [1]:
    shutdown:        false
    PoE:

```

```

    Enable: false
    Pse class control: 0
    Power priority: high
Port [2]:
  shutdown: false
  PoE:
    Enable: false
    Pse class control: 0
    Power priority: high
Port [3]:
  shutdown: false
  PoE:
    Enable: false
    Pse class control: 0
    Power priority: high

```

29.4.1 Model 1

Consider configuration of a data communication channel which is based on model 1 and implements 'VLAN for Subscriber'. Figure 38 shows a configuration of two abstract services with subscriber C-VLAN 200 and U-VLAN 10 and 11 for each service correspondingly.




Figure 38 – Service abstract representation for Model 1

Step 1. Assign a service model:

```

ma4000# configure terminal
ma4000(config)# gpon olt model 1

```

Step 2. Create a **Service1** cross-connect profile to configure the first service. Configure a bridged service and specify a bridged group which will be associated with an ONT port. Configure U-VLAN with the help of the **set u-vid** command (it equals 10 for the first service in this case):

```

ma4000(config)# profile cross-connect Service1
ma4000(config-cross-connect)("Service1")# bridge
ma4000(config-cross-connect)("Service1")# bridge group 1
ma4000(config-cross-connect)("Service1")# user vid 10

```

Step 3. Check the changes made:

```

ma4000(config-cross-connect)("service1")# do show profile cross-connect service1
  Name:                                     'service1'
  Description:                              'ONT Profile Cross Connect 1'
  Model:                                    ont
  Bridge group:                             1
  Tag mode:                                 single-tagged
  Outer vid:                                1
  Outer cos:                                unused
  Inner vid:                                -
  U vid:                                    10
  U cos:                                    unused
  Mac table entry limit:                   unlimited
  Type:                                     general
  IP host index:                            0
  Priority queue:                           0

```

Step 4. By analogy with the described above, create another *cross-connect* profile (**Service2**) for the second service and configure it with **U-VLAN 11**:

```

ma4000(config)# profile cross-connect Service2
ma4000(config-cross-connect)("Service2")# bridge
ma4000(config-cross-connect)("Service2")# bridge group 1
ma4000(config-cross-connect)("Service2")# user vid 11

```

Step 5. Check the changes made:

```

ma4000(config-cross-connect)("service2")# do show profile cross-connect service2
  Name:                                     'service2'
  Description:                              'ONT Profile Cross Connect 2'
  Model:                                    ont
  Bridge group:                             1
  Tag mode:                                 single-tagged
  Outer vid:                                1
  Outer cos:                                unused
  Inner vid:                                -
  U vid:                                    untagged
  U cos:                                    unused
  Mac table entry limit:                   unlimited
  Type:                                     general
  Iphost eid:                              0
  Priority queue:                           0

```

Step 6. Set the DBA parameters. To do this, create a *dba* profile and adjust the corresponding settings. We set a value of a guaranteed bandwidth in this example:

```

ma4000(config)# profile dba AllServices
ma4000(config-dba)("AllServices")# bandwidth guaranteed 500

```

Step 7. Check the changes made:


```
ma4000(config-dba)("AllServices")# do show profile dba AllServices
Name:                                     'AllServices'
Description:                              'ONT Profile DBA 2'
Dba:
  Sla data:
    Service class:                         type5
    Status reporting:                       nsr
    Alloc size:                             0
    Alloc period:                           0
    Fixed bandwidth:                       0
    Guaranteed bandwidth:                   500
    Besteffort bandwidth:                   1244000
```

Step 8. Bind bridge group to ONT port. To do this, create a *ports* profile and assign value **1** to the **bridge group** parameter for the **eth 0** port:

```
ma4000(config)# profile ports Ports1
ma4000(config-ports)("Ports1")# port 0 bridge group 1
```

Step 9. Check the changes made:

```

ma4000(config-ports)("Ports1")# do show profile ports Ports1

Name:                               'Ports1'
Description:                         'ONT Profile Ports 2'
Multicast IP version:                IPv4
Icmp settings:
  Version:                           IGMP v3
  Mode:                               snooping
  Immediate leave:                   false
  Robustness:                         2
  Querier ip:                         0.0.0.0
  Query interval:                    125
  Query response interval:            100
  Last member query interval:         30
Mld settings:
  Version:                           MLD v2
  Mode:                               snooping
  Immediate leave:                   false
  Robustness:                         2
  Querier ipv6:                      ::
  Query interval:                    125
  Query response interval:            100
  Last member query interval:         10
Veip:
  Multicast enable:                  false
  Multicast port settings:
    Upstream igmp vid:                1
    Upstream igmp prio:                0
    Upstream igmp tag control:         pass
    Downstream multicast vid:          1
    Downstream multicast prio:          0
    Downstream multicast tag control:   pass
    Max groups:                        0
    Max multicast bandwidth:           0
Port [0]:
  Speed:                             auto
  Duplex:                             auto
  Bridge group:                       1
  Spanning tree for bridge group:     false
  Multicast enable:                   false
  Multicast port settings:
    Upstream igmp vid:                1
    Upstream igmp prio:                0
    Upstream igmp tag control:         pass
    Downstream multicast vid:          1
    Downstream multicast prio:          0
    Downstream multicast tag control:   pass
    Max groups:                        0
    Max multicast bandwidth:           0
  Shaper downstream:
    Enable:                           false
    Committed rate:                   1000000
  Shaper upstream:
    Enable:                            false
Committed rate:                       1000000

```

Step 10. Assign the created profiles in the ONT:

```

ma4000(config)# interface ont 0/0/0
ma4000(config)(if-ont-0/0/0)# service 0 profile dba AllServices
ma4000(config)(if-ont-0/0/0)# service 0 profile cross-connect Service1
ma4000(config)(if-ont-0/0/0)# service 1 profile dba AllServices
ma4000(config)(if-ont-0/0/0)# service 1 profile cross-connect Service2
ma4000(config)(if-ont-0/0/0)# profile ports Ports1
ma4000(config)(if-ont-0/0/0)# do show interface ont 0/0/0 configuration

```

```

-----
[ONT0/0/0] configuration
-----

```

```

Description:                ''
Status:                     UP
Serial:                     0000000000000000
Password:                   ''
Fec up:                     false
Downstream broadcast:      true
Ber interval:               100000
Ber update period:         60
Rf port state:              no change
Omci error tolerant:        false
Service [0]:
  Profile cross connect:    Service1           ONT Profile Cross
Connect 4
  Profile dba:              AllServices       ONT Profile DBA 2
Service [1]:
  Profile cross connect:    Service2           ONT Profile Cross
Connect 3
  Profile dba:              AllServices       ONT Profile DBA 2
  Profile shaping:          shaping-00         ONT Profile Shaping
0
Profile ports:              Ports1           ONT Profile Ports 1
Profile management:         management-00    ONT Profile Management
0
Profile scripting:          unassigned
Custom model:               none
Template:                   unassigned

```

Step 11. 'VLAN for Subscriber' requires a C-VLAN to be assigned for this ONT (subscriber). Assign **C-VLAN 200** for both services by using the **set custom cross-connect** command:

```
ma4000(config)(if-ont-0/0/0)# service 0 custom cvid 200
ma4000(config)(if-ont-0/0/0)# service 1 custom cvid 200
ma4000(config)(if-ont-0/0/0)# do show interface ont 0/0/0 configuration

-----
[ONT0/0/0] configuration
-----

Description:           ''
Status:                UP
Serial:                0000000000000000
Password:              ''
Fec up:               false
Downstream broadcast: true
Ber interval:         100000
Ber update period:    60
Rf port state:        no change
Omc error tolerant:   false
Service [0]:
  Profile cross connect: Service1      ONT Profile Cross
Connect 4
  Profile dba:         AllServices    ONT Profile DBA 2
  Custom vlan:         200
  Custom CoS:         unused
Service [1]:
  Profile cross connect: Service2      ONT Profile Cross
Connect 3
  Profile dba:         AllServices    ONT Profile DBA 2
  Custom vlan:         200
  Custom CoS:         unused
...
```

Step 12. Apply the changes by using the commit command:

```
ma4000(config)(if-ont-0/0/0)# do commit
```

Step 13. Configure **VLAN 200** in the **switch view** (see Section [VLAN configuration](#)):

```
ma4000# configure terminal
ma4000(config)# vlan 200
ma4000(vlan-200)# tagged front-port 1/0
ma4000(vlan-200)# tagged slot-channel 0
ma4000(vlan-200)# tagged plc-pon-port 0/0-7
ma4000(vlan-200)# tagged plc-slot-channel 0/0
ma4000(vlan-200)# exit
ma4000(vlan-200)# do commit
```

29.4.2 Model 2

Configuration of the Model 2 is the same as for Model 3. Abstract view is represented in section [28.2.2](#).

29.4.3 Model 3

A service model which classified as model 3 implements the 'VLAN for Service' principle. [Figure 39](#) shows an abstract service configured with S-VLAN 30.




Figure 39 – Service abstract representation for Model 3

Step 1. Assign a service model:

```
ma4000# configure terminal
ma4000(config)# gpon olt model 3
```

Step 2. Create a **Service3** cross-connect profile to configure the first service. Configure a bridged service and specify the bridged group the ONT port will be associated with:

```
ma4000(config)# profile cross-connect Service3
ma4000(config-cross-connect)("Service3")# bridge
ma4000(config-cross-connect)("Service3")# bridge group 1
```

Step 3. To assign an S-VLAN, use the **outer vid 30** command:

```
ma4000(config-cross-connect)("Service3")# outer vid 30
```

Step 4. Specify U-VID in order to have untagged traffic coming from the ONT port:

```
ma4000(config-cross-connect)("Service3")# user vid untagged
```

Step 5. Check the changes made:

```
ma4000(config-cross-connect)("Service3")# do show profile cross-connect Service3
Name:                               'Service3'
Description:                         'ONT Profile Cross Connect 3'
Model:                               ont
Bridge group:                        1
Tag mode:                            single-tagged
Outer vid:                           30
Outer cos:                           unused
Inner vid:                           -
U vid:                               untagged
U cos:                               unused
Mac table entry limit:               unlimited
Type:                                general
IP host index:                       0
Priority queue:                       0
```

Step 6. Set the DBA parameters. To do this, create a *dba* profile and adjust the corresponding settings. We set a value of a guaranteed bandwidth in this example:

```
ma4000(config)# profile dba AllServices
ma4000(config-dba)("AllServices")# bandwidth guaranteed 500
```

Step 7. Check the changes made:

```
ma4000(config-dba)("AllServices")# do show profile dba AllServices
Name:                                     'AllServices'
Description:                              'ONT Profile DBA 2'
Dba:
  Sla data:
    Service class:                         type5
    Status reporting:                       nsr
    Alloc size:                             0
    Alloc period:                           0
    Fixed bandwidth:                       0
    Guaranteed bandwidth:                   500
    Besteffort bandwidth:                   1244000
```

Step 8. Bind bridge group to ONT port. To do this, create a *ports* profile and assign value **1** to the **bridge group** parameter for the **eth 0** port:

```
ma4000(config)# profile ports Ports1
ma4000(config-ports)("Ports1")# port 0 bridge group 1
```

Step 9. Check the changes made:

```
ma4000(config-ports)("Ports1")# do show profile ports Ports1
Name:                                     'Ports1'
Description:                              'ONT Profile Ports 1'
...
Port [0]:
  Bridge group:                            1
  Spanning tree for bridge group:          false
  Multicast enable:                         false
  Multicast port settings:
    Upstream igmp vid:                      1
    Upstream igmp prio:                     0
    Upstream igmp tag control:               pass
    Downstream multicast vid:                1
    Downstream multicast prio:               0
    Downstream multicast tag control:        pass
    Max groups:                              0
    Max multicast bandwidth:                 0
  Shaper downstream:
    Enable:                                  false
    Committed rate:                          1000000
  Shaper upstream:
    Enable:                                   false
    Committed rate:                          1000000
...
```

Step 10. Assign the created profiles in the ONT:

```

ma4000(config)# interface ont 0/0/1
ma4000(config)(if-ont-0/0/1)# service 0 profile dba AllServices
ma4000(config)(if-ont-0/0/1)# service 0 profile cross-connect Service1
ma4000(config)(if-ont-0/0/1)# profile ports Ports1
ma4000(config)(if-ont-0/0/1)# do show interface ont 0/0/1 configuration
-----
[ONT0/0/1] configuration
-----

Description:                ''
Status:                     UP
Serial:                     0000000000000000
Password:                   '0000000000'
Fec up:                     false
Downstream broadcast:      true
Ber interval:               100000
Ber update period:         60
Rf port state:              no change
Omc error tolerant:        false
Service [0]:
  Profile cross connect:    Service1          ONT Profile Cross
Connect 4
  Profile dba:              AllServices        ONT Profile DBA 2
  Profile shaping:         shaping-00           ONT Profile
Shaping 0
  Profile ports:           Ports1              ONT Profile Ports 1
  Profile management:      management-00    ONT Profile Management
0
Profile scripting:         unassigned
Custom model:              none
Template:                  unassigned
Pppoe sessions unlimited: false
Ports:
  Port [0]:
    shutdown:              false
    PoE:
      Enable:              false
      Pse class control:   0
      Power priority:      high
  Port [1]:
    shutdown:              false
    PoE:
      Enable:              false
      Pse class control:   0
      Power priority:      high
  Port [2]:
    shutdown:              false
    PoE:
      Enable:              false
      Pse class control:   0
      Power priority:      high

```

Step 11. Apply changes by the **commit** command:

```

ma4000(config)(if-ont-0/0/1)# do commit

```

Step 12. Configure **S-VLAN 30** in the **switch view** (see Section [VLAN configuration](#)):

```

ma4000# configure terminal
ma4000(config)# vlan 30
ma4000(vlan-30)# tagged front-port 1/0
ma4000(vlan-30)# tagged slot-channel 0
ma4000(vlan-30)# tagged plc-pon-port 0/0-7
ma4000(vlan-30)# tagged plc-slot-channel 0/0
ma4000(vlan-30)# exit
ma4000(vlan-30)# do commit

```

29.5 Tunnelling configuration

Simple profiles in the tag-mode, single-tag or double-tag modes are aimed at mapping the traffic, which is transmitted to the gem port and tagged as user vid or untagged, into the traffic tagged outer vid or outer:inner vid respectively.

Models 2 and 3 allow traffic tunnelling configuration, which extends the range of possible GPON applications in operator's network.

Using the profiles tagged as selective-tunnel allows a tag to be **added** to incoming packets with a certain set of user vid tags. The profiles tagged as tunnel allow a tag to be **added** to incoming packets with any user-vid tags.

Consider the following diagram and its configuration as an example.




Figure 40 – Communication diagram

VLAN 300 (multicast) and QinQ VLAN 1100 and 1200 (Internet) come to the uplink OLT. It is necessary to let them pass to the switch integrated in the OLT via SFP-ONU. In addition, a corporate client is connected to the splitter via SFP-ONU that sends a random set of VLANs to be passed to remote devices after removing tags of these VLANs at the ONT LAN port. To organise a tunnel for this client, VLAN 500 is selected in the operator's network.

Consider the procedure of OLT configuration for the above diagram.

Step 1. Configure the switch:

```

interface plc-pon-port 0/0
  bridging to plc-pon-port 0/1
exit
interface plc-pon-port 0/1
  bridging to plc-pon-port 0/0
exit
vlan 300
  name VLAN0300
  tagged plc-pon-port 0/0
  tagged front-port 1/0
exit
vlan 500
  name VLAN0500
  tagged plc-pon-port 0/0
  tagged plc-pon-port 0/1
  tagged front-port 1/0
exit
vlan 1100
  name VLAN1100
  tagged plc-pon-port 0/0
  tagged front-port 1/0
exit
vlan 1200
  name VLAN1200
  tagged plc-pon-port 0/0
  tagged front-port 1/0
exit

```

Step 2. Configure cross-connect profiles:

```

profile cross-connect "cc-tunnel"
  bridge
  bridge group "10"
  tag-mode tunnel
exit
profile cross-connect "cc-selecttunnel"
  bridge
  bridge group "10"
  tag-mode selective-tunnel
exit
profile cross-connect "cc-single"
  bridge
  bridge group "10"
  user vid "300"
exit
profile cross-connect "cc-double"
  bridge
  bridge group "10"
  tag-mode double-tagged
exit

```

Step 3. Configure ports profiles:

```
profile ports "bridge-10"
port 0 bridge group "10"
exit
```

Step 4. Set up the address-table profile by specifying the VLANs used for tunnels and assign the profile to GPON ports:

```
profile address-table "at-tunnel"
s-vlan 1100 use c-vlan
s-vlan 1200 use c-vlan
s-vlan 500 use c-vlan
exit interface gpon-port 0/0
profile address-table "at-tunnel"
exit
interface gpon-port 0/1
profile address-table "at-tunnel"
exit
```

Step 5. Set up the SFP-ONU to be used for switch connection:

```
interface ont 0/0/0
serial "454C545300000001"
service 0 profile cross-connect "cc-tunnel"
service 0 profile dba "dba-00"
service 1 profile cross-connect "cc-selecttunnel"
service 1 profile dba "dba-00"
service 2 profile cross-connect "cc-single"
service 2 profile dba "dba-00"
profile ports "bridge-10"
service 0 custom svid "1100"
service 1 custom svid "1200"
service 1 selective-tunnel uvid 201-203
service 2 custom svid "300"
```

Step 6. Set up the SFP-ONU to be used for connection of the corporate client:

```
interface ont 0/0/1
serial "454C545300000002"
service 0 profile cross-connect "cc-tunnel"
service 0 profile dba "dba-00"
profile ports "bridge-10"
service 0 custom svid "500"
```

Step 7. Set up the ONTs to be used for connection of remote offices:

```

interface ont 0/1/0
serial "454C545800000002"
service 0 profile cross-connect "cc-double"
service 0 profile dba "dba-00"
profile ports "bridge-10"
service 0 custom cvid "10"
service 0 custom svid "500"
exit
interface ont 0/1/1
serial "454C545800000003"
service 0 profile cross-connect "cc-double"
service 0 profile dba "dba-00"
profile ports "bridge-10"
service 0 custom cvid "20"
service 0 custom svid "500"

```

- ✔ **The number of UVIDs processed in all selective-tunnel services on one ONT does not exceed 42. The VLANs used for tunnel services cannot be used for other types of services within one GPON channel.**

The tunnel service is the last one to be configured on the ONT, therefore the user-vid used by other services will not be processed by the tunnel service.

The traffic with a random user-vid tag should not contain additional 802.1q tags. Otherwise, it will be declined by any service provided for this user-vid.

It is impossible to use double-tagged and tunnel services simultaneously on one terminal.

It is not recommended to use untagged traffic for tunnelling.

30 DBA configuration

30.1 Introduction

This section considers DBA configuration for ONT.

GPON technology implies that all ONTs of one GPON channel use common communication medium (fibre). It is necessary to provide a mechanism that will ensure data transfer from all ONTs without collisions. The mechanism is called *dynamic bandwidth allocation (DBA)* and ensures allocation of time intervals in OLT for data transfer to ONTs.

A logical unit of the DBA algorithm is *Alloc-ID* (allocation) with a corresponding T-CONT (traffic counter) on the ONT side. Data transfer parameters (frequency, transmission window) are separately configured for every Alloc-ID (T-CONT) and are referred to as *service level agreement (SLA)*.

G.984.3 provides several SLA combinations called T-CONT type. There are the following T-CONT types:

- T-CONT type 1 with a fixed bandwidth only. It is suitable for traffic, which is transferred at a constant speed (or with very low variations) and is sensitive to delays and jitter.
- T-CONT type 2 with a guaranteed bandwidth only.

This type is suitable for bursty traffic with a well defined upper bound, without strict delay and jitter restrictions.

- T-CONT type 3 is a counter with a guaranteed bandwidth and a possibility to allocate a best-effort bandwidth. This type is suitable for bursty traffic with peak values that requires a certain throughput to be guaranteed.
- T-CONT type 4 allows allocation of a best-effort bandwidth without fixed or guaranteed bandwidths. This type is suitable for bursty traffic with peak values that does not require any guaranteed throughput.
- T-CONT type 5 is a counter with fixed and guaranteed bandwidths and a possibility to allocate a best-effort bandwidth. This type summarises all other types and is suitable for most types of traffic.

The terminal allows configuring up to 256 general allocations, 64 allocations for OMCI service traffic and 128 CBR (constant bitrate) type allocations per channel. When one ONT is connected, one allocation will be assigned as a default one. Thus, if 64 ONT are connected, 64 service allocations will be assigned on the channel. 256 general allocations is enough for data processing, but not enough for more than 4 services processing in the own allocation. You need to follow the rule: $A_{max} = 256 / N - 1$, where A_{max} – the maximum quantity of allocations for user data of an ONT, N – the quantity of ONTs on a channel. If the calculated amount of services exceeds ONT A_{max} , configure a combination of multiple services into a single allocation. For more detailed information, see [Services in one T-CONT](#).

DBA parameters are configured in the *dba* profile. These parameters allow specification of any T-CONT type described in G.984.3. First of all, choose *service-class* to define the basic DBA algorithm. After that, configure *status-reporting* to define the type of ONT queues status report. The **fixed bandwidth**, **guaranteed-bandwidth**, and **besteffort-bandwidth** parameters define the fixed, guaranteed, and best-effort bandwidth correspondingly. [Table 23](#) shows the correspondence between the dba profile settings and T-CONT types.

Table 23 – DBA profile configuration and T-CONT types

	T-CONT type 1	T-CONT type 2	T-CONT type 3	T-CONT type 4	T-CONT type 5
service-class	cbr	voip	type5	type5	type5
status-reporting	-	+	+	+	+

	T-CONT type 1	T-CONT type 2	T-CONT type 3	T-CONT type 4	T-CONT type 5
fixed-bandwidth	+	-	-	-	+
guaranteed-bandwidth	-	+	+	-	+
besteffort-bandwidth	-	-	+	+	+

The following rules apply to dba profile assignment:

- When an ONT service is assigned a dba profile, an Alloc-ID is created for the ONT on the OLT side, and a corresponding T-CONT is configured on the ONT side.
- If different ONTs are assigned the same profile, they will each have a separate Alloc-ID created with the same allocation parameters.
- If different services of one ONT are assigned the same *alloc* profile, the services will operate with one allocation.
- If different services of one ONT are assigned different *dba* profiles, the services will operate with different allocations. The number of Alloc-IDs created for an ONT equals the number of *alloc* profiles assigned to it.

30.2 DBA profiles assignment

30.2.1 Services in different T-CONTs

Two *Alloc-ID* will be allocated for ONTs in the OLT. Each service will operate in its allocation. There will be two T-CONTs on the ONT side corresponding to the allocations.

Step 1. Each ONT should have two services in different T-CONTs. To do this, assign two *dba* profiles by using the **profile dba** command:

```
ma4000# configure terminal
ma4000(config)# profile dba ServiceInternet
ma4000(config-dba)("ServiceInternet")# exit
ma4000(config)# profile dba ServiceVoIP
ma4000(config-dba)("ServiceVoIP")# exit
```

Step 2. Assign the profiles to services by using the **service <id> profile dba** command:

```
ma4000(config)(if-ont-0/0/0)# service 0 profile dba ServiceInternet
ma4000(config)(if-ont-0/0/0)# service 1 profile dba ServiceVoIP
```

You will obtain the following configuration:

```

ma4000(config)(if-ont-0/0/0)# do show interface ont 0/0/0 configuration

...
  Service [0]:
    Profile cross connect:           Service1           ONT Profile Cross
Connect 4
    Profile dba:                     ServiceInternet    ONT Profile DBA 3
    Custom vlan:                     200
    Custom CoS:                      unused
  Service [1]:
    Profile cross connect:           Service2           ONT Profile Cross
Connect 3
    Profile dba:                     ServiceVoIP        ONT Profile DBA 4
    Custom vlan:                     200
    Custom CoS:                      unused
...

```

Step 3. Apply the changes by using the **commit** command:

```

ma4000(config)(if-ont-0/0/0)# do commit

```

30.2.2 Services in one T-CONT

One Alloc-ID will be allocated for ONTs in the OLT. ONT will have one T-CONT configured. The T-CONT will be used to transfer traffic from multiple services. Traffic priority will be based on the value of the *priority queue* field of the corresponding *cross-connect* profiles.

Step 1. Each ONT should have three services in one T-CONT. To do this, assign a *dba* profile by using the **profile dba** command:

```

ma4000(config)# profile dba AllServices

```

Step 2. Assign the profile to three services by using the **service <id> profile dba** command:

```

ma4000(config)(if-ont-0/0/1)# service 0 profile dba AllServices
ma4000(config)(if-ont-0/0/1)# service 1 profile dba AllServices
ma4000(config)(if-ont-0/0/1)# service 2 profile dba AllServices

```

You will obtain the following configuration:

```

ma4000(config)(if-ont-0/0/1)# do show interface ont 0/0/1 configuration

...
  Service [0]:
    Profile cross connect:           Service1           ONT Profile Cross
Connect 4
    Profile dba:                     AllServices        ONT Profile DBA 2
  Service [1]:
    Profile cross connect:           unassigned
    Profile dba:                     AllServices        ONT Profile DBA 2
  Service [2]:
    Profile cross connect:           unassigned
    Profile dba:                     AllServices        ONT Profile DBA 2
...

```

Step 3. Apply the changes by using the **commit** command:

```
ma4000(config)(if-ont-0/0/1)# do commit
```

30.2.3 One profile for multiple ONTs

This is a typical scenario in most cases, when similar services require the same DBA parameters on different ONTs.

Step 1. Define a *dba* profile by using the **profile dba** command:

```
ma4000(config)# profile dba ServiceInternet
ma4000(config-dba)("ServiceInternet")#
```

Step 2. Assign the profile to the corresponding service of every ONT by using the **service <id> profile dba** command:

```
ma4000(config)# interface ont 0/0/0-1
ma4000(config)(if-ont-0/0/0-1)# service 0 profile dba ServiceInternet
```

You will obtain the following ONT configurations:

```
ma4000(config)(if-ont-0/0/0-1)# do show interface ont 0/0/0-1 configuration
-----
[ONT0/0/0] configuration
-----
...
Service [0]:
  Profile cross connect:      Service1      ONT Profile Cross
Connect 4
  Profile dba:                ServiceInternet  ONT Profile DBA 3
  Custom vlan:                200
  Custom CoS:                 unused
...
-----
[ONT0/0/1] configuration
-----
...
Service [0]:
  Profile cross connect:      Service1      ONT Profile Cross
Connect 4
  Profile dba:                ServiceInternet  ONT Profile DBA 3
...

```

Step 3. Apply the changes by using the **commit** command:

```
ma4000(config)(if-ont-0/0/0-1)# do commit
```

30.2.4 Profiles assignment example

Consider two ONTs, which need to have the following three services: Internet, VoIP, SecurityAlarm. The VoIP service should operate in a separate allocation (a definite throughput should be ensured). The Internet and SecurityAlarm services may operate in one allocation.

This configuration implies that the OLT allocates two Alloc-IDs to each ONT. The Internet and SecurityAlarm services operate in one allocation, the VoIP service uses another one. Each ONT has two T-CONT configured

which correspond to the Alloc-IDs of the ONT. Traffic priority between the Internet and SecurityAlarm services on the ONT side is based on the **priority-queue** value of the *ServiceInternet* and *ServiceAlarm cross-connect* profiles, which were assigned to the services.

Step 1. Define two *dba* profiles by using the **profile dba** command:

```
ma4000(config)# profile dba ServiceVoIP
ma4000(config-dba)("ServiceVoIP")# exit
ma4000(config)# profile dba OtherServices
ma4000(config-dba)("OtherServices")#
```

Step 2. Assign profiles to the corresponding services of each ONT by using the **service <id> profile dba** command:

```
ma4000(config)# interface ont 0/0/0-1
ma4000(config)(if-ont-0/0/0-1)# service 0 profile dba OtherServices
ma4000(config)(if-ont-0/0/0-1)# service 1 profile dba ServiceVoIP
ma4000(config)(if-ont-0/0/0-1)# service 2 profile dba OtherServices
```

You will obtain the following ONT configurations:


```

ma4000(config)(if-ont-0/0/0-1)# do show interface ont 0/0/0-1 configuration

-----
[ONT0/0/0] configuration
-----
...
  Service [0]:
    Profile cross connect:      Service1      ONT Profile Cross
Connect 4
    Profile dba:                ServiceVoIP   ONT Profile DBA 4
    Custom vlan:                200
    Custom CoS:                 unused
  Service [1]:
    Profile cross connect:      Service2      ONT Profile Cross
Connect 3
    Profile dba:                ServiceVoIP   ONT Profile DBA 4
    Custom vlan:                200
    Custom CoS:                 unused
  Service [2]:
    Profile cross connect:      unassigned
    Profile dba:                OtherServices ONT Profile DBA 5
...

-----
[ONT0/0/1] configuration
-----

...
  Service [0]:
    Profile cross connect:      Service1      ONT Profile Cross
Connect 4
    Profile dba:                ServiceVoIP   ONT Profile DBA 4
  Service [1]:
    Profile cross connect:      unassigned
    Profile dba:                ServiceVoIP   ONT Profile DBA 4
  Service [2]:
    Profile cross connect:      unassigned
    Profile dba:                OtherServices ONT Profile DBA 5
...

```

Step 3. Apply the changes by using the commit command:

```
ma4000(config)(if-ont-0/0/0-1)# do commit
```

30.3 DBA parameters configuration

30.3.1 T-CONT type 1 configuration

Consider configuration of a 100 Mbps fixed bandwidth.

Step 1. Specify a T-CONT type by using the **sla class** command:

```

ma4000(config)# profile dba dba-00
ma4000(config-dba)("dba-00")# sla class cbr

```

Step 2. Specify a type of status reports for ONT queues by using the **sla status-reporting** command:

```
ma4000(config-dba)("dba-00")# sla status-reporting nsr
```

Step 3. Set fixed bandwidth parameters by using the **bandwidth fixed** command. Set other bandwidth parameters to 0.

✔ **The bandwidth has a value in Kbps (1000 bps) and is not rounded down to 64 Kbps.**

```
ma4000(config-dba)("dba-00")# bandwidth fixed 100000
ma4000(config-dba)("dba-00")# bandwidth guaranteed 0
ma4000(config-dba)("dba-00")# bandwidth besteffort 0
```

Step 4. Check the parameters:

```
ma4000(config-dba)("dba-00")# do show profile dba dba-00
Name:                               'dba-00'
Description:                         'ONT Profile DBA 0'
Dbas:
Sla data:
  Service class:                     cbr
  Status reporting:                  nsr
  Alloc size:                         0
  Alloc period:                      0
  Fixed bandwidth:                   100000
  Guaranteed bandwidth:              0
  Besteffort bandwidth:              0
```

Step 5. Apply the changes by using the **commit** command:

```
ma4000(config-dba)("dba-00")# do commit
```

30.3.2 T-CONT type 2 configuration

Consider configuration of a 100 Mbps guaranteed bandwidth.

Step 1. Specify a T-CONT type by using the **sla class** command:

```
ma4000(config)# profile dba dba-00
ma4000(config-dba)("dba-00")# sla class voip
```

Step 2. Specify a type of status reports for ONT queues by using the **sla status-reporting** command:

```
ma4000(config-dba)("dba-00")# sla status-reporting nsr
```

Step 3. Set guaranteed bandwidth parameters by using the **bandwidth guaranteed** command.

Set other bandwidth parameters to 0.

✔ **The bandwidth has a value in Kbps (1000 bps) and is not rounded down to 64 Kbps.**

```
ma4000(config-dba)("dba-00")# bandwidth fixed 0
ma4000(config-dba)("dba-00")# bandwidth guaranteed 100000
ma4000(config-dba)("dba-00")# bandwidth besteffort 0
```

Step 4. Check the parameters:

```

ma4000(config-dba)("dba-00")# do show profile dba dba-00
  Name:                               'dba-00'
  Description:                         'ONT Profile DBA 0'
  Dba:
    Sla data:
      Service class:                   voip
      Status reporting:                nsr
      Alloc size:                       0
      Alloc period:                    0
      Fixed bandwidth:                 0
      Guaranteed bandwidth:             100000
      Besteffort bandwidth:             0

```

Step 5. Apply the changes by using the **commit** command:

```

ma4000(config-dba)("dba-00")# do commit

```

30.3.3 T-CONT type 3 configuration

Consider configuration of a 100 Mbps guaranteed bandwidth with a possibility of allocation of a 200 Mbps best-effort bandwidth.

Step 1. Specify a T-CONT type by using the **sla class** command:

```

ma4000(config)# profile dba dba-00
ma4000(config-dba)("dba-00")# sla class type5

```

Step 2. Specify a type of status reports for ONT queues by using the **sla status-reporting** command:

```

ma4000(config-dba)("dba-00")# sla status-reporting nsr

```

Step 3. Set guaranteed bandwidth parameters by using the **bandwidth guaranteed** command.

Set best-effort bandwidth parameters by using the **bandwidth besteffort** command. Set other bandwidth parameters to 0.

 **The bandwidth has a value in Kbps (1000 bps) and is not rounded down to 64 Kbps.**

```

ma4000(config-dba)("dba-00")# bandwidth fixed 0
ma4000(config-dba)("dba-00")# bandwidth guaranteed 100000
ma4000(config-dba)("dba-00")# bandwidth besteffort 200000

```

Step 4. Check the parameters:

```

ma4000(config-dba)("dba-00")# do show profile dba dba-00
  Name:                               'dba-00'
  Description:                         'ONT Profile DBA 0'
  Dba:
    Sla data:
      Service class:                   type5
      Status reporting:                nsr
      Alloc size:                       0
      Alloc period:                    0
      Fixed bandwidth:                 0
      Guaranteed bandwidth:             100000
      Besteffort bandwidth:             200000

```

Step 5. Apply the changes by using the **commit** command:

```
ma4000(config-dba)("dba-00")# do commit
```

30.3.4 T-CONT type 4 configuration

Consider configuration of a 200 Mbps best-effort bandwidth without allocation of a guaranteed bandwidth.

Step 1. Specify a T-CONT type by using the **sla class** command:

```
ma4000(config)# profile dba dba-00
ma4000(config-dba)("dba-00")# sla class type5
```

Step 2. Specify a type of status reports for ONT queues by using the **sla status-reporting** command:

```
ma4000(config-dba)("dba-00")# sla status-reporting nsr
```

Step 3. Set best-effort bandwidth parameters by using the **bandwidth besteffort** command.

Set other bandwidth parameters to 0.

 **The bandwidth has a value in Kbps (1000 bps) and is not rounded down to 64 Kbps.**

```
ma4000(config-dba)("dba-00")# bandwidth fixed 0
ma4000(config-dba)("dba-00")# bandwidth guaranteed 0
ma4000(config-dba)("dba-00")# bandwidth besteffort 200000
```

Step 4. Check the parameters:

```
ma4000(config-dba)("dba-00")# do show profile dba dba-00\
Name:                               'dba-00'
Description:                         'ONT Profile DBA 0'
Dba:
  Sla data:
    Service class:                   type5
    Status reporting:                 nsr
    Alloc size:                       0
    Alloc period:                     0
    Fixed bandwidth:                  0
    Guaranteed bandwidth:              0
    Besteffort bandwidth:              200000
```

Step 5. Apply the changes by using the **commit** command:

```
ma4000(config-dba)("dba-00")# do commit
```

30.3.5 T-CONT type 5 configuration

Consider configuration of a 100 Mbps fixed bandwidth and a 200 Mbps guaranteed bandwidth with a possibility of allocation of a 1244 Mbps best-effort bandwidth.

Step 1. Specify a T-CONT type by using the **sla class** command:

```
ma4000(config)# profile dba dba-0
ma4000(config-dba)("dba-00")# sla class type5
```

Step 2. Specify a type of status reports for ONT queues by using the **sla status-reporting** command:

```
ma4000(config-dba)("dba-00")# sla status-reporting nsr
```

Step 3. Specify fixed bandwidth parameters with the **set dba sla-data fixed bandwidth** command, guaranteed bandwidth parameters with the **set dba sla-data guaranteed bandwidth** command, and best-effort bandwidth parameters with the **set dba sla-data besteffort bandwidth** command:

✓ **The bandwidth has a value in Kbps (1000 bps) and is not rounded down to 64 Kbps.**

```
ma4000(config-dba)("dba-00")# bandwidth fixed 100000
ma4000(config-dba)("dba-00")# bandwidth guaranteed 200000
ma4000(config-dba)("dba-00")# bandwidth besteffort 1244000
```

Step 4. Check the parameters:

```
ma4000(config-dba)("dba-00")# do show profile dba dba-00
Name:                               'dba-00'
Description:                         'ONT Profile DBA 0'
Dbas:
  Sla data:
    Service class:                    type5
    Status reporting:                 nsr
    Alloc size:                       0
    Alloc period:                     0
    Fixed bandwidth:                  100000
    Guaranteed bandwidth:             200000
    Besteffort bandwidth:             1244000
```

Step 5. Apply the changes by using the **commit** command:

```
ma4000(config-dba)("dba-00")# do commit
```

31 RG ONT configuration

31.1 Introduction

This section considers issues related to configuration of *Residential Gateway (RG) ONTs*. The section introduces the notion of *Bridged* and *Routed* services.

Consider the concept of OMCI and RG management domains. These terms are determined in TR-142 Issue 2. In terms of management domains, an ONT is considered as a device, which operates in the OMCI domain only. The devices, which operate in both management domains (i. e. have an integrated router), are denoted as ONT/RG. Everything that refers to the OMCI domain can be applied to both ONT and ONT/RG devices. For this reason, we will further denote ONT/RG as ONT. If an ONT is configured without the RG domain (without a router), skip all steps concerning RG.

Figure 41 shows an ONT/RG scheme and its management domains.




Figure 41 – ONT/RG management domains

- ✔ **Bridged service is a service, which configuration requires the OMCI management domain only, i. e. it can be completely configured with the help of the OMCI protocol in ONT. Routed service is a service, which configuration requires both the OMCI and RG management domains.**

In addition to configuration in access node, a routed service requires the RG domain to be configured by using one of the following methods:

- Pre-defined configuration – subscriber is provided with an ONT having fixed configuration;
- Local ONT configuration using WEB interface;
- ONT configuration using the TR-069 protocol and auto configuration server (ACS).

- ✔ **Contact ONT vendor for information about RG domain configuration.**

ONT is connected to RG using a Virtual Ethernet interface point (VEIP), which corresponds to the TR-069 WAN interface (described in TR-098) on the RG side. VEIP is represented by a virtual port in access node parameters. The port has the same configuration procedure as Ethernet ports in the *ports* profile.




Figure 42 – Services configuration in ONT and RG domains

Figure 42 shows two services (each with a corresponding GEM port on the ONT side), with one of them being routed and using both the OMCI and RG management domains and the other one being bridged and using only OMCI for configuration. Access node configuration includes configuration of bridge interfaces (green areas in the figure) and distribution of LAN ports between the management domains.

The **bridge** parameter of the *cross-connect* profile is responsible for association of a service with a management domain. Being set, the bridge parameter creates a bridged service (the **bridge group** parameter is the bridge number in this case). When **no bridge** is set, a routed service is created (there is only one bridge associated with RG; it has a special bridge number – 0).

31.2 Mixed configuration

Consider an example of ONT configuration, which simultaneously uses both management domains. Port numbers and the internal structure are shown in Figure 42.

Step 1. Create a VLAN for services on the switch. VLAN configuration is described in detail in [VLAN configuration](#):

```
ma4000(config)# vlan 20
ma4000(vlan-20)# tagged front-port 1/0
ma4000(vlan-20)# tagged slot-channel 0
ma4000(vlan-20)# tagged plc-pon-port 0/0-7
ma4000(vlan-20)# tagged plc-slot-channel 0/0
ma4000(vlan-20)# exit
ma4000(config)# vlan 30
ma4000(vlan-30)# tagged front-port 1/0
ma4000(vlan-30)# tagged slot-channel 0
ma4000(vlan-30)# tagged plc-pon-port 0/0-7
ma4000(vlan-30)# tagged plc-slot-channel 0/0
```

Step 2. Specify 3 as a service model value corresponding to the VLAN for Service model by using the **gpon olt model** command:

```
ma4000# configure terminal
ma4000(config)# gpon olt model 3
```

Step 3. Define *cross-connect* profiles for services:

```

ma4000(config)# profile cross-connect RG-service
ma4000(config-cross-connect)("RG-service")# exit
ma4000(config)# profile cross-connect OMCI-service
ma4000(config-cross-connect)("OMCI-service")#
ma4000(config-cross-connect)("OMCI-service")# exit

```

Step 4. Define the *dba* profile. DBA parameters are not important for the purposes of this section. Thus, we will not configure DBA parameters, just use the default values. We will also assign one profile to both services that means that upstream services will operate with one T-CONT. DBA configuration is described in detail in [DBA configuration](#):

```

ma4000(config)# profile dba basic
ma4000(config-dba)("basic")# exit

```

Step 5. Create *ports* profile:

```

ma4000(config)# profile ports 2RG-20MCI
ma4000(config-ports)("2RG-20MCI")# exit

```

Step 6. Configure routed service. Use one VLAN 20 on both the OLT and ONT sides. Specify a routed service by using the **no bridge** command. Configure a cross-connect profile for the routed service:

```

ma4000(config)# profile cross-connect RG-service
ma4000(config-cross-connect)("RG-service")# no bridge
ma4000(config-cross-connect)("RG-service")# type general
ma4000(config-cross-connect)("RG-service")# tag-mode single-tagged
ma4000(config-cross-connect)("RG-service")# outer vid 20
ma4000(config-cross-connect)("RG-service")# outer cos unused
ma4000(config-cross-connect)("RG-service")# user vid untagged
ma4000(config-cross-connect)("RG-service")# mac-table-limit unlimited
ma4000(config-cross-connect)("RG-service")# priority 0

```

Step 7. Configure bridged service. Use one VLAN 30 on both the OLT and ONT sides. Specify a bridged service by using the **no bridge** command. Set 1 as the OMCI bridge number. Configure a cross-connect profile for the bridged service:

```

ma4000(config)# profile cross-connect OMCI-service
ma4000(config-cross-connect)("OMCI-service")# bridge
ma4000(config-cross-connect)("OMCI-service")# bridge group 1
ma4000(config-cross-connect)("OMCI-service")# type general
ma4000(config-cross-connect)("OMCI-service")# tag-mode single-tagged
ma4000(config-cross-connect)("OMCI-service")# outer vid 30
ma4000(config-cross-connect)("OMCI-service")# outer cos unused
ma4000(config-cross-connect)("OMCI-service")# user vid untagged
ma4000(config-cross-connect)("OMCI-service")# mac-table-limit unlimited
ma4000(config-cross-connect)("OMCI-service")# priority 1

```

You specified different *priority queue* values for the services. The routed service will have a higher priority than the bridged service as they work with one T-CONT.

Step 8. Configure *ports* profile. According to [Figure 42](#), we need to associate the first two LAN ports with the RG management domain, while the other two should be associated with the OMCI domain and bound to bridge 1:


```

ma4000(config)# profile ports 2RG-20MCI
ma4000(config-ports)("2RG-20MCI")# port 0 bridge group 0
ma4000(config-ports)("2RG-20MCI")# port 1 bridge group 0
ma4000(config-ports)("2RG-20MCI")# port 2 bridge group 1
ma4000(config-ports)("2RG-20MCI")# port 3 bridge group 1

```

Step 9. Set the ONT configuration. Create an ONT configuration. ONT management is described in details in Section [ONT configuration](#):

```

ma4000(config)# interface ont 0/0/0
ma4000(config)(if-ont-0/0/0)#

```

Step 10. Assign created profiles. Assign the *cross-connect RG-service* profile to service 0 and the *cross-connect OMCI-service* profile to service 1:

```

ma4000(config)# interface ont 0/0/0
ma4000(config)(if-ont-0/0/0)# serial ELTX10203040
ma4000(config)(if-ont-0/0/0)# service 0 profile cross-connect RG-service
ma4000(config)(if-ont-0/0/0)# service 0 profile dba basic
ma4000(config)(if-ont-0/0/0)# service 1 profile cross-connect OMCI-service
ma4000(config)(if-ont-0/0/0)# service 1 profile dba basic
ma4000(config)(if-ont-0/0/0)# profile ports 2RG-20MCI

```

Step 11. Use the **show interface ont <id> configuration** command to check the created configuration:

```
ma4000(config)(if-ont-0/0/0)# do show interface ont 0/0/0 configuration
```

```
-----
[ONT0/0/0] configuration
-----
```

```

Description:          ''
Status:              UP
Serial:              ELTX10203040
...

Service [0]:
  Profile cross connect:  RG-service          ONT Profile Cross
Connect 6
  Profile dba:           basic                ONT Profile DBA 6
  Custom vlan:           200
  Custom CoS:            unused
  Service [1]:
  Profile cross connect:  OMCI-service         ONT Profile Cross
Connect 7
  Profile dba:           basic                ONT Profile DBA 6
  Custom vlan:           200
  Custom CoS:            unused
...

Profile shaping:      shaping-00          ONT Profile Shaping 0
Profile ports:        2RG-20MCI          ONT Profile Ports 2
Profile management:   management-00       ONT Profile Management
0

Profile scripting:    unassigned
Custom model:         none
Template:             unassigned
Pppoe sessions unlimited: false
Ports:
  Port [0]:
    shutdown:          false
    PoE:
      Enable:          false
      Pse class control: 0
      Power priority:  high
  Port [1]:
    shutdown:          false
    PoE:
      Enable:          false
      Pse class control: 0
      Power priority:  high
  Port [2]:
    shutdown:          false
    PoE:
      Enable:          false
      Pse class control: 0
      Power priority:  high
  Port [3]:
    shutdown:          false
    PoE:
      Enable:          false
      Pse class control: 0
      Power priority:  high

```

Step 12. Apply changes by the **commit** command:

```
ma4000(config)(if-ont-0/0/0)# do commit
```

As a result, you will have the mixed configuration of the ONT. One of the services is managed completely by the OMCI domain (the bridged service), LAN2 and LAN3 ports on the ONT are connected as bridges. The second service is managed by both OMCI and RG (the routed service; the RG domain can be configured, for instance, through the WEB interface on the ONT). LAN0 and LAN1 ports are connected to RG ONT.

32 High Speed Internet configuration

Configuration of the High Speed Internet (HSI) service does not have any peculiarities and can be easily performed as described in Section [ONT configuration](#).

33 Multicast configuration

33.1 Introduction

This section describes peculiarities of multicast service configuration for model 1 and model 3.

33.2 Model 1 Multicast configuration

This section provides an example of multicast service configuration for model 1.

An STB, which works in VLAN 14, is connected to an ONT port in this example. Upstream IGMP packets arrive to VLAN 14 through a GEM port and the OLT changes VLAN 14 to subscriber's VLAN 200. As we have a multicast server in VLAN 98 in our example, we need to configure a proxy on the switch to translate IGMP packets from VLAN 200 to VLAN 98 (for more information, see [VLAN configuration](#)). The multicast service comes downstream to the ONT port in VLAN 98 and changes to VLAN 14.

For more information on general configuration principles of data communication channels, see Section [ONT configuration](#).




Figure 43 – Model 1 Multicast

Step 1. Specify the ONT serial number in the configuration:

```
ma4000# configure terminal
ma4000(config)# interface ont 0/0/0
ma4000(config)(if-ont-0/0/0)# serial ELTX01234567
ma4000(config)(if-ont-0/0/0)# exit
```

Step 2. Assign a service model:

```
ma4000(config)# gpon olt model 1
```

Step 3. Create an UsIGMP *cross-connect* profile to configure the service, which will be used to send IGMP requests upstream. Configure a bridged service and specify the bridged group (it equals 1 in our example) the ONT port will be associated with; specify U-VLAN 14:

```

ma4000(config)# profile cross-connect UsIGMP
ma4000(config-cross-connect)("UsIGMP")# bridge
ma4000(config-cross-connect)("UsIGMP")# bridge group 1
ma4000(config-cross-connect)("UsIGMP")# user vid 14
ma4000(config-cross-connect)("UsIGMP")# do show profile cross-connect UsIGMP
  Name:                               'UsIGMP'
  Description:                         'ONT Profile Cross Connect 8'
  Model:                               ont
  Bridge group:                        1
  Tag mode:                            single-tagged
  Outer vid:                           1
  Outer cos:                           unused
  Inner vid:                           -
  U vid:                               14
  U cos:                               unused
  Mac table entry limit:               unlimited
  Type:                                general
  Iphost eid:                          0
  Priority queue:                      0

```

Step 4. Bind bridge group to ONT port. To do this, create a *ports* profile and assign value 1 to the bridge group parameter for the LAN1 port:

```

ma4000(config)# profile ports Ports1
ma4000(config-ports)("Ports1")# port 1 bridge group 1

```

Step 5. Enable multicasting and configure VLAN replacement rules for the ONT port:

```

ma4000(config-ports)("Ports1")# port 1 multicast
ma4000(config-ports)("Ports1")# port 1 igmp downstream vid 14
ma4000(config-ports)("Ports1")# port 1 igmp downstream tag-control replace-vid
ma4000(config-ports)("Ports1")# port 1 igmp upstream vid 14
ma4000(config-ports)("Ports1")# port 1 igmp upstream tag-control replace-vid

```

Step 6. You also need to configure VLAN 98 multicasting and specify the group range:

```

ma4000(config-ports)("Ports1")# igmp multicast dynamic-entry 0 vid 98
ma4000(config-ports)("Ports1")# igmp multicast dynamic-entry 0 group 224.0.0.0 239.255.255.255
ma4000(config-ports)("Ports1")# do show profile ports Ports1
  Name:                               'Ports1'
  Description:                         'ONT Profile Ports 1'
  Igmp settings:
    Version:                           3
    Mode:                               snooping
    Immediate leave:                   false
    Robustness:                         2
    Querier ip:                        0.0.0.0
    Query interval:                    125
    Query response interval:           100
    Last member query interval:        10
    Multicast dynamic entry [0]:
      Vlan id:                          98
      First group ip:                   224.0.0.0
      Last group ip:                    239.255.255.255
...
  Port [1]:
    Bridge group:                       1
    Spanning tree for bridge group:     false
    Multicast enable:                   true
    Multicast port settings:
      Upstream igmp vid:                 14
      Upstream igmp prio:                0
      Upstream igmp tag control:         replace vid
      Downstream multicast vid:          14
      Downstream multicast prio:         0
      Downstream multicast tag control:  replace vid
      Max groups:                        0
      Max multicast bandwidth:           0
    Shaper downstream:
      Enable:                            false
      Committed rate:                    1000000
    Shaper upstream:
      Enable:                            false
      Committed rate:                    1000000
      Committed rate:                    1000000
...

```

Step 7. Assign the created profiles in the ONT. Configure a *custom-cross-connect* profile, specify C-VLAN 200, and apply the configuration:

```

ma4000(config)# interface ont 0/0/0
ma4000(config)(if-ont-0/0/0)# service 0 profile cross-connect UsIGMP
ma4000(config)(if-ont-0/0/0)# profile ports Ports1
ma4000(config)(if-ont-0/0/0)# service 0 custom cvid 200
ma4000(config)(if-ont-0/0/0)# do commit

```

Step 8. Add VLAN 98 and VLAN 200. Enable IGMP snooping:

```

ma4000# configure terminal
ma4000(config)# vlan 200
ma4000(vlan-200)# tagged front-port 1/0
ma4000(vlan-200)# tagged slot-channel 0
ma4000(vlan-200)# tagged plc-pon-port 0/0-7
ma4000(vlan-200)# tagged plc-slot-channel 0/0
ma4000(vlan-200)# ip igmp snooping enable
ma4000(vlan-200)# exit
ma4000(config)# vlan 98
ma4000(vlan-98)# tagged front-port 1/0
ma4000(vlan-98)# tagged slot-channel 0
ma4000(vlan-98)# tagged plc-pon-port 0/0-7
ma4000(vlan-98)# tagged plc-slot-channel 0/0
ma4000(vlan-98)# ip igmp snooping enable
ma4000(vlan-98)# exit

```

Step 9. Configure IGMP proxy for IGMP packets transmission from VLAN 200 to VLAN 98. Apply the configuration:

```

ma4000(config)# ip igmp proxy report enable
ma4000(config)# ip igmp proxy report range 224.0.0.0 239.255.255.255 from 200 to 98
ma4000(config)# ip igmp snooping enable
ma4000(config)# do commit

```

33.3 Model 3 Multicast configuration

Consider configuration of a multicast service for Model 3.

In our example, the multicast server operates in VLAN 98. An STB, which works in VLAN 14, is connected to an ONT port. Upstream IGMP packets pass through VLAN 14 to ONT, where VLAN 14 is replaced by the service VLAN 98. The data goes through the GEM port upwards. The multicast service comes downstream to the ONT port in VLAN 98 and changes to VLAN 14. For more information on general configuration principles of data communication channels, see Section [ONT configuration](#).




Figure 44 – Model 3 Multicast

Step 1. Specify the ONT serial number in the configuration:

```

ma4000# configure terminal
ma4000(config)# interface ont 0/0/0
ma4000(config)(if-ont-0/0/0)# serial ELTX01234567
ma4000(config)(if-ont-0/0/0)# exit

```


Step 2. Assign a service model:

```
ma4000(config)# gpon olt model 3
```

Step 3. Create an UsIGMP cross-connect profile to transfer IGMP requests upstream. Configure a bridged service and specify the bridged group (it equals 1 in our example) the ONT port will be associated with. Specify U-VLAN 14 and S-VLAN 98:

```
ma4000(config)# profile cross-connect UsIGMP
ma4000(config-cross-connect)("UsIGMP")# bridge
ma4000(config-cross-connect)("UsIGMP")# bridge group 1
ma4000(config-cross-connect)("UsIGMP")# outer vid 98
ma4000(config-cross-connect)("UsIGMP")# user vid 14
ma4000(config-cross-connect)("UsIGMP")# do show profile cross-connect UsIGMP
  Name:                               'UsIGMP'
  Description:                         'ONT Profile Cross Connect 8'
  Model:                               ont
  Bridge group:                       1
  Tag mode:                           single-tagged
  Outer vid:                           98
  Outer cos:                           unused
  Inner vid:                           -
  U vid:                               14
  U cos:                               unused
  Mac table entry limit:              unlimited
  Type:                               general
  Iphost eid:                         0
  Priority queue:                     0
```

Step 4. Bind bridge group to ONT port. To do this, create a *ports* profile and assign value 1 to the bridge group parameter for the LAN1 port:

```
ma4000(config)# profile ports Ports1
ma4000(config-ports)("Ports1")# port 1 bridge group 1
```

Step 5. Enable multicasting and configure VLAN replacement rules for the ONT port:

```
ma4000(config-ports)("Ports1")# port 1 multicast
ma4000(config-ports)("Ports1")# port 1 igmp downstream vid 14
ma4000(config-ports)("Ports1")# port 1 igmp downstream tag-control replace-vid
ma4000(config-ports)("Ports1")# port 1 igmp upstream vid 98
ma4000(config-ports)("Ports1")# port 1 igmp upstream tag-control replace-vid
```

Step 6. You also need to configure VLAN 98 multicasting and specify the group range:

```

ma4000(config-ports)("Ports1")# igmp multicast dynamic-entry 0 vid 98
ma4000(config-ports)("Ports1")# igmp multicast dynamic-entry 0 group 224.0.0.0 239.255.255.255
ma4000(config-ports)("Ports1")# do show profile ports Ports1
  Name:                               'Ports1'
  Description:                         'ONT Profile Ports 1'
  Igmp settings:
    Version:                           3
    Mode:                               snooping
    Immediate leave:                   false
    Robustness:                         2
    Querier ip:                        0.0.0.0
    Query interval:                    125
    Query response interval:           100
    Last member query interval:        10
    Multicast dynamic entry [0]:
      Vlan id:                          98
      First group ip:                   224.0.0.0
      Last group ip:                    239.255.255.255
...
  Port [1]:
    Bridge group:                       1
    Spanning tree for bridge group:     false
    Multicast enable:                   true
    Multicast port settings:
      Upstream igmp vid:                 98
      Upstream igmp prio:                0
      Upstream igmp tag control:         replace vid
      Downstream multicast vid:          14
      Downstream multicast prio:         0
      Downstream multicast tag control:  replace vid
      Max groups:                        0
      Max multicast bandwidth:           0
    Shaper downstream:
      Enable:                            false
      Committed rate:                    1000000
    Shaper upstream:
      Enable:                             false
      Committed rate:                    1000000
...

```

Step 7. Assign the created profiles in the ONT and apply the configuration:

```

ma4000(config)# interface ont 0/0/0
ma4000(config)(if-ont-0/0/0)# service 0 profile cross-connect UsIGMP
ma4000(config)(if-ont-0/0/0)# profile ports Ports1
ma4000(config)(if-ont-0/0/0)# do commit

```

Step 8. Add VLAN 98 and enable IGMP snooping:

```

ma4000(config)# vlan 98
ma4000(vlan-98)# tagged front-port 1/0
ma4000(vlan-98)# tagged slot-channel 0
ma4000(vlan-98)# tagged plc-pon-port 0/0-7
ma4000(vlan-98)# tagged plc-slot-channel 0/0
ma4000(vlan-98)# ip igmp snooping enable
ma4000(vlan-98)# exit
ma4000(config)# ip igmp snooping enable
ma4000(config)# do commit

```

34 VoIP configuration

VoIP service is configured in a usual way for routed services. The procedure is described in detail in [ONT configuration](#). All the general steps of service configuration are applied to VoIP as well.

MA4000-PX supports telephony configuring via OMCI (ONT made by ELTEX are not supported). The procedure is described in details in [Appendix A. VoIP configuration section](#).

35 TR-069 management configuration

35.1 Introduction

This section describes configuration of a data communication channel for the CPE management service via the TR-069 protocol.

An ONT management channel can be established in one of the two modes: Inband and OutOfBand. Inband is the preferred mode as it is simpler. Contact your ONT vendor for information about operation capabilities of both modes.

ONT management via TR-069 is a special service. All general steps of service configuration apply to TR-069 management. Operator's actions required for services configuration are described in detail in [ONT configuration](#).

As opposed to other services, the management service requires the *management* type in the *cross-connect* profile. You also need to specify the **lphost eid** parameter. As a rule, it should be equal to 0.

35.2 Configuration of a TR-069 Inband management

This mode is characterised by its simple implementation. Management traffic goes through the same bridge as user traffic. [Figure 45](#) shows a part of the OMCI layout. Arrows show the traffic flow.




Figure 45 – TR-069 Inband management channel

Step 1. Set the *management* type in the cross-connect profile:

```
ma4000(config)# profile cross-connect TR069
ma4000(config-cross-connect)("TR069")# type management
ma4000(config-cross-connect)("TR069")# no bridge
```

Step 2. Set the *IP Host* identifier to 0:

```
ma4000(config-cross-connect)("TR069"># iphost eid 0
```

Step 3. Check the changes made:

```
ma4000(config-cross-connect)("TR069"># do show profile cross-connect TR069
Name:                                     'TR069'
Description:                              'ONT Profile Cross Connect 10'
Model:                                     ont-rg
Bridge group:                             -
Tag mode:                                  single-tagged
Outer vid:                                 1
Outer cos:                                 unused
Inner vid:                                 -
U vid:                                     untagged
U cos:                                     unused
Mac table entry limit:                    unlimited
Type:                                      management
Iphost eid:                               0
Priority queue:                            0
```

Step 4. Apply the changes by using the **commit** command:

```
ma4000(config-cross-connect)("TR069"># do commit
```

35.3 Configuration of a TR-069 OOB management channel

Not all ONT vendors support creation of Inband management channels via TR-069. To solve this, a capability to create an OutOfBand management channel was developed as an alternative. The main peculiarity of the mode is that it uses a separate bridge for management. [Figure 46](#) shows a part of the OMCI layout. Arrows show the traffic flow.

Step 1. Set the *management* type in the cross-connect profile:

```
ma4000(config)# profile cross-connect TR069
ma4000(config-cross-connect)("TR069"># type management
```

Step 2. Set the ont model of the cross-connect profile. Specify a separate *bridge group*:

```
ma4000(config-cross-connect)("TR069"># bridge
ma4000(config-cross-connect)("TR069"># bridge group 20
```

Step 3. Set the *IP Host* identifier to 0:

```
ma4000(config-cross-connect)("TR069"># iphost eid 0
```

Step 4. Check the changes by using the **show** command:

```

ma4000(config-cross-connect)("TR069")# do show profile cross-connect TR069
Name: 'TR069'
Description: 'ONT Profile Cross Connect 10'
Model: ont
Bridge group: 20
Tag mode: single-tagged
Outer vid: 1
Outer cos: unused
Inner vid: -
U vid: untagged
U cos: unused
Mac table entry limit: unlimited
Type: management
Iphost eid: 0
Priority queue: 0
    
```

Step 5. Apply the changes by using the **commit** command:

```

ma4000(config-cross-connect)("TR069")# do commit
    
```




Figure 46 – TR-069 OutOfband management channel

35.4 TR-069 client parameters configuration

To configure TR-069 client parameters, use the *management* profile:

```
ma4000# show profile management management-00
  Name:                               'management-00'
  Description:                         'ONT Profile Management 0'
  Enable omci configuration:           true
  Url:                                 ''
  Username:                            ''
  Password:                            ''
```

When the DHCP server transmits the TR-069 parameters via option 43, there is no need to transfer them via OMCI. Disable this phase with the **no omci-configuration** command.

Otherwise, specify TR-069 client parameters explicitly.

Step 1. Enable TR-069 configuration:

```
ma4000# configure terminal
ma4000(config)# profile management management-00
ma4000(config-management)("management-00")# omci-configuration
```

Step 2. Set the connection parameters:

```
ma4000(config-management)("management-00")# url http://acs-tele.com:9595/acs
ma4000(config-management)("management-00")# username acs
ma4000(config-management)("management-00")# password acsacs
```

Step 3. Check the changes made:

```
ma4000(config-management)("management-00")# do show profile management management-00
  Name:                               'management-00'
  Description:                         'ONT Profile Management 0'
  Enable omci configuration:           true
  Url:                                 'http://acs-tele.com:9595/acs'
  Username:                            'acs'
  Password:                            'acsacs'
```

Step 4. Apply the changes by using the **commit** command:

```
ma4000(config-management)("management-00")# do commit
```

36 ONT configuration templates

36.1 Introduction

It is not always convenient, especially for large-scale operators, to build ONT configuration from separate profiles for each subscriber. This process is painstaking and risky in a certain sense, as it is highly prone to operator error.

As a rule, such companies employ at least one service plan with pre-defined ONT profiles. This section describes ONT templates, an effective solution to simplify the work of subscriber service specialists.

The essence of configuration templates is simple. Network administrator prepares required quantity of templates for the quantity of service plans. Configuration template contains detailed profile list and a set of ONT parameters. Subscriber service specialist or OSS/BSS system assigns the template to an ONT and identifies additional configuration parameters if necessary. As a rule, configuration assignment is performed in one click or by using one command.

36.2 Preparing ONT configuration template

Step 1. Define an ONT configuration template:

```
ma4000(config)# template HSI-100-CaTV
ma4000(ont-template)("HSI-100-CaTV")#
```

Step 2. Set the ONT configuration. Template configuration does not have any peculiarities and exactly follows the ONT configuration process described in [ONT configuration](#):

```
ma4000(ont-template)("HSI-100-CaTV")# service 0 profile dba AllServices
ma4000(ont-template)("HSI-100-CaTV")# service 0 profile cross-connect Service1
ma4000(ont-template)("HSI-100-CaTV")# service 1 profile dba AllServices
ma4000(ont-template)("HSI-100-CaTV")# service 1 profile cross-connect Service2
ma4000(ont-template)("HSI-100-CaTV")# profile ports Ports1
...
```

Step 3. Disable all configuration parameters that should be specified explicitly for the ONT with the **undefine** command, if necessary:

```
ma4000(ont-template)("HSI-100-CaTV")# undefine rf-port-state
...
```

Step 4. Apply the changes:

```
ma4000(ont-template)("HSI-100-CaTV")# do commit
```

36.3 ONT configuration template assignment

Step 1. Switch to the ONT view. You can use a range of ONT IDs for group operations if necessary:

```
ma4000(config)# interface ont 0/0/0-10
ma4000(config)(if-ont-0/0/0-10)#
```

Step 2. Assign an ONT configuration template by using the **template** command:

```
ma4000(config)(if-ont-0/0/0-10)# template HSI-100-CaTV
```


Step 3. Define individual ONT parameters not specified in the template if necessary:

```
ma4000(config)(if-ont-0/0/0-10)# rf-port-state enabled
```

Step 4. Apply the changes:

```
ma4000(config)(if-ont-0/0/0-10)# do commit
```

36.4 ONT configuration preview with templates

You can view the ONT configuration using the same command: **show interface ont <id> configuration**. You can distinguish the template parameters from the general ones by [T](Template) markers. In this example, **Rf port state** is the only general parameter:

```
ma4000(config)(if-ont-0/0/0-10)# do show interface ont 0/0/0 configuration
```

```
-----
[ONT0/0/0] configuration
-----
```

```

Description:                ''
Enabled:                    true
Serial:                     ELTX01234567
Password:                   '0000000000'
[T] Fec up:                 false
[T] Downstream broadcast:   true
[T] Ber interval:           100000
[T] Ber update period:     60
Rf port state:              enabled
[T] Omci error tolerant:   false
Service [0]:
[T] Profile cross connect:  Service1          ONT Profile Cross
Connect 4
[T] Profile dba:            AllServices        ONT Profile DBA 2
Custom vlan:                200
Custom CoS:                 unused
Service [1]:
[T] Profile cross connect:  Service2          ONT Profile Cross
Connect 3
[T] Profile dba:            AllServices        ONT Profile DBA 2
Custom vlan:                200
Custom CoS:                 unused
[T] Profile shaping:       shaping-00         ONT Profile Shaping 0
[T] Profile ports:         Ports1           ONT Profile Ports 1
[T] Profile management:    management-00    ONT Profile Management
0
[T] Profile scripting:     unassigned
Custom model:               none
Template:                   HSI-100-CaTV      ONT Template 1
Pppoe sessions unlimited:  false
Ports:
  Port [0]:
    shutdown:               false
    PoE:
      Enable:               false
      Pse class control:    0
      Power priority:       high
  Port [1]:
    shutdown:               false
    PoE:
      Enable:               false
      Pse class control:    0
      Power priority:       high
  Port [2]:
    shutdown:               false
    PoE:
      Enable:               false
      Pse class control:    0
      Power priority:       high
  Port [3]:
    shutdown:               false
    PoE:
      Enable:               false

```

Pse **class** control:
Power priority:

0
high

37 ONT licensing

37.1 Introduction

By default, OLT supports only Eltex ONTs operation. To enable any third-party ONTs, OLT requires a license. To purchase the license, contact Eltex Marketing Department.

- ✔ **If a third-party ONT is connected to OLT without a license, the following entry will be made in the log file:**
2017-01-18 05:11:39 pmchal: error: [ONT2/0] License is not valid, configuration will not continue

37.2 Loading a license file to OLT

A license is a text file of the following format:

```
{
  "version": "<VER>",
  "type": "all",
  "count": "<count>",
  "sn": "<SN>",
  "mac": "<MAC>",
  "sign": "<hash>"
}
```

Where:

- *VER* – license file version number;
- *count* – number of third-party ONTs that can run on OLT;
- *SN* – LTP serial number;
- *MAC* – LTP MAC address;
- *hash* – license file digital signature.

There are two ways to load a license to OLT:

1. Use the copy command:

```
ma4000# copy tftp://<IP>/<PATH> fs://license
  Download file from TFTP-server..
License successfully installed. Please reboot device for changes to make effect
```

Where:

- *IP* – TFTP server IP address;
- *PATH* – license file path on TFTP server.

2. Use CLI:

```
ma4000# license set ""<license>""
License successfully installed. Please reboot device for changes to make effect
```

Where:

- *license* – full content of the license file including curly brackets.

To view information about the license on the device, use the **show** command:

```
ma4000# show license
Active license information:
  License valid:          yes
  Version:                1.1
  Carrier:                Eltex Enterprise LLC
  Licensed vendor:       all
  Licensed ONT count:    unlimited
  Licensed ONT online:   2
  SN:                    OL02000000
  Mac:                   A8:F9:4B:00:00:00
```

The license file remains after device reload, firmware update, and configuration load. If OLT is reset to factory settings, the license is also deleted.

38 ONT ports management

38.1 Introduction

This chapter describes management of Ethernet ports via OMCI. You may switch Ethernet ports on and off on a connected ONT, manage and control PoE as power source .

If PoE ports are supported on ONTs you may manage ports:

- enable/disable PoE on ports;
- control power class;
- priority management.

All the attributes mentioned above are transmitted via OMCI (ITU-T G.988 ME 11 "PPTP Ethernet UNI").

38.2 Managing ONT Ethernet ports

ONT Ethernet ports management involves enabling/disabling of these ports and implements with the help of **[n o] port <port number> shutdown** command, where **<port number>** is the number of needed port "0-3".

Step 1. For disabling an Ethernet port use the following commands:

```
MA4000(config)# interface ont 10/4/0
MA4000(config)(if-ont-10/4/0)# port 0 shutdown
MA4000(config)(if-ont-10/4/0)# do commit
MA4000(config)(if-ont-10/4/0)# do confirm
```

Step 2. Make sure the changes has been applied:

```
MA4000(config)(if-ont-10/4/0)# do show interface ont 10/4/0 configuration
...
  Pppoe sessions unlimited:                false
  Ports:
    Port [0]:
      shutdown:                             true
      PoE:
        Enable:                             false
        Pse class control:                  0
        Power priority:                     high
    Port [1]:
      shutdown:                             false
      PoE:
        Enable:                             false
        Pse class control:                  0
        Power priority:                     high
    Port [2]:
      shutdown:                             false
      PoE:
        Enable:                             false
        Pse class control:                  0
        Power priority:                     high
    Port [3]:
      shutdown:                             false
      PoE:
        Enable:                             false
        Pse class control:                  0
        Power priority:                     high
```

Step 3. To enable an Ethernet port do the following:

```
MA4000(config)# interface ont 10/4/0
MA4000(config)(if-ont-10/4/0)# no port 0 shutdown
MA4000(config)(if-ont-10/4/0)# do commit
MA4000(config)(if-ont-10/4/0)# do confirm
```

38.3 Managing PoE on ONT ports

Managing PoE on ONT ports is implemented by using **port <port number> poe enable pse-class-control <class> power-priority <level>** command, where

- **<port number>** – the number of port "0-3";
- **<class>** – power class "0-5";
- **<level>** – priority level "critical/high/low".

38.3.1 Enabling PoE on ONT ports

For enabling PoE on ONT ports, use the following commands:

```
MA4000(config)(if-ont-10/4/0)# port 0 poe enable
MA4000(config)(if-ont-10/4/0)# do commit
MA4000(config)(if-ont-10/4/0)# do confirm
```

38.3.2 Power class control

This attribute might be used for limiting of power class. Available values:

- 0 – power supply is enabled and has a default power level for this port;
- 1 – power supply is enabled on the level of power class 0;
- 2 – power supply is enabled on the level of power class 1;
- 3 – power supply is enabled on the level of power class 2;
- 4 – power supply is enabled on the level of power class 3;
- 5 – power supply is enabled on the level of power class 4.

For changing the power class of PoE on the ports, use the following commands:

```
MA4000(config)(if-ont-10/4/0)# port 0 poe pse-class-control 0
MA4000(config)(if-ont-10/4/0)# do commit
MA4000(config)(if-ont-10/4/0)# do confirm
```

38.3.3 Managing PoE priority

This attribute manages port priority according to power management algorithm. The priority set by this attribute might be used by management system which prevents electrical current overloads. To avoid overloads, the system will disable ONT LAN ports starting with the ports with the lowest PoE priority.

Available values:

- **critical;**
- **high** (default value);
- **low.**

To change the PoE priority in the ONT ports, do the following:

```
MA4000(config)(if-ont-10/4/0)# port 0 poe power-priority low
MA4000(config)(if-ont-10/4/0)# do commit
MA4000(config)(if-ont-10/4/0)# do confirm
```

39 General information

39.1 Viewing current access node firmware version

To view information on the current version of access node firmware, use the **show firmware** command:

```
ma4000# show firmware

Firmware status:
~~~~~
Unit   Image   Running  Boot      Version          Date
----   -
1      0        No       *         3 24 0 448 44346 26-Nov-2015 08:26:00
1      1        Yes      *         3 24 0 451 44381 26-Nov-2015 12:06:47
2      0        No       *         3 24 0 448 44346 26-Nov-2015 08:26:00
2      1        Yes      *         3 24 0 451 44381 26-Nov-2015 12:06:47

"*" designates that the image was selected for the next boot
```

39.2 View information on access node

To view information about PP4X modules, use the **show system information** command. PP4X module number shall be specified as a parameter.

```
ma4000# show system information 1
System information (1):
Uptime (d:h:m:s): 3:7:33:38
CPU load (1/5/15 minutes): 0.31/1.29/1.41
RAM (total/free), Mbytes: 498/25
Partition '/' (total/free), Mbytes: 57/21
Partition '/mnt/tools' (total/free), Mbytes: 1024/932
Partition '/mnt/config' (total/free), Mbytes: 64/59
Partition '/mnt/log' (total/free), Mbytes: 128/117
Temperature (SFP): 22C
Temperature (CPU): 32C
Temperature (Switch) : 44C
Firmware version: 3.24.0.451 r44381 12:06:40 26/11/2015
Linux version: Linux version 2.6.22.18 (jenkins@xpon.eltex.loc) (gcc version 4.3.2
(sdksdk3.2rc1-ct-ng-1.4.1) ) #1 Thu Nov 26 18:21:10 NOVT 2015
MAC address: a8:f9:4b:81:82:20
Serial number: 0L02000032
```

To view information about the chassis, use the **show system environment** command:


```

ma4000# show system environment
MFC board status:      ok
MFC board version:    0x2
MFC firmware:
  Status:              0x00 (ok)
  Version:             8 2 1 1 5 05/11/2013
  Timestamp (UTC):    05-Nov-2013 12:19:22

Fan configured speed, %: 56
Fan minimum speed, %:  15
Fan speed levels, %:   15 25 36 46 57 68 78 89 100

                        Fan0      Fan1      Fan2
Status:                ok        ok        ok
RPM:                   3678      3624      3582

                        Feeder1   Feeder2
Status:                ok        REVERSED
Current, A:            4.25      0.00
Voltage, V:            -54.18    1.73

Shelf voltage, V:     -53.48

                        Feeder1   Feeder2
Status:                REVERSED ok
Current, A:            0.00      1.00
Voltage, V:            1.92      -53.69

Shelf voltage, V:     -54.35

```

39.3 Viewing interface modules status

To view information on interface modules, use the **show shelf** command:

```
ma4000# show shelf

Shelf status
~~~~~
Slot #   Configured Type   Detected Type   Version         Serial #         Link State      Slot State
-----
0        plc8                 plc8            3.24.0.451     OL04001750      up
Operational
1        none                 none            0.0.0.0
2        none                 none            0.0.0.0
3        none                 none            0.0.0.0
4        none                 none            0.0.0.0
5        none                 none            0.0.0.0
6        none                 none            0.0.0.0
7        none                 none            0.0.0.0
8        none                 none            0.0.0.0
9        none                 none            0.0.0.0
10       none                 none            0.0.0.0
11       none                 none            0.0.0.0
12       none                 none            0.0.0.0
13       none                 none            0.0.0.0
14       none                 none            0.0.0.0
15       none                 none            0.0.0.0
```

39.4 Viewing access node uptime

To view access node operating time, use the **show uptime** command.

```
ma4000# show uptime
up 3 days, 7:35
```

39.5 Checking network connection

To check network connection, use the **ping** command. As a parameter, pass the IP address of the node to be checked.

```
ma4000# ping 192.168.1.254
PING 192.168.1.254 (192.168.1.254): 56 data bytes
64 bytes from 192.168.1.254: seq=0 ttl=64 time=0.422 ms
64 bytes from 192.168.1.254: seq=1 ttl=64 time=0.426 ms
64 bytes from 192.168.1.254: seq=2 ttl=64 time=0.360 ms
64 bytes from 192.168.1.254: seq=3 ttl=64 time=0.397 ms
64 bytes from 192.168.1.254: seq=4 ttl=64 time=0.404 ms

--- 192.168.1.254 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 0.360/0.401/0.426 ms
```

40 Access node operation log

To view a list of logs, use the **show log** command:

```
ma4000# show log

Log files
~~~~~
##      Name                Size in bytes      Date of last modification
----  -
1      daemon                 450                Thu Dec 14 17:55:38 2017
2      pp                      126432             Thu Dec 14 17:55:12 2017
3      slot0                   65934              Thu Dec 14 17:55:12 2017
----  -
Total files: 2
```

Table 24 – Operation logs purpose

Name	Description
daemon	Log messages of MA4000 auxiliary services get saved in the log
pp	Log messages of master PP4X module get saved in the log
pp-other	Log messages of slave PP4X module get saved in the log
slot	Log messages of definite interface module get saved in the log

To view operation log, use the **show log** command. Pass the log name as a parameter.

```
ma4000# show log pp
2014-09-11 16:58:10 rebootd started
2014-09-11 16:58:10 cli-mgr <main>
2014-09-11 16:58:10 cli-mgr <climgr_initialize>
2014-09-11 16:58:10 cli-mgr <main_loop>
2014-09-11 16:58:10 switch %SWITCH: starting up
2014-09-11 16:58:10 switch %SWITCH: start
2014-09-11 16:58:10 syslog-ng syslog-ng starting up; version='3.2.3'
2014-09-11 16:58:10 switch %STARTUP: init
2014-09-11 16:58:10 switch %STARTUP: Position is left
2014-09-11 16:58:10 switch %STARTUP: ShelfId is 15
2014-09-11 16:58:10 switch %FACTORY: reading factory settings...
2014-09-11 16:58:10 switch %FACTORY: OK
2014-09-11 16:58:10 switch %PARSE-CFG: processing configuration file "/tmp/boot.conf.1"...
2014-09-11 16:58:10 switch %PARSE-CFG: Operation successful.
2014-09-11 16:58:10 switch %PARSE-CFG: Operation successful.
2014-09-11 16:58:10 switch %PARSE-CFG: Operation successful.
2014-09-11 16:58:10 switch %PARSE-CFG: Operation successful.
2014-09-11 16:58:10 switch %PARSE-CFG: Operation successful.
2014-09-11 16:58:10 switch %PARSE-CFG: Operation successful.
2014-09-11 16:58:10 switch %PARSE-CFG: parse config: ...done.
2014-09-11 16:58:11 switch Device[0] ID 0xE00D11AB revision B1 or above
...
```

The log messages can be filtered. To do this, use the **show log <journal> grep** command. The command takes a string as a parameter that is used for search in the log. Only the messages containing the string will be displayed on the screen.

```
ma4000# show log pp grep pp4x
2014-09-11 16:58:57 switch %FIRMWARE: by entering 'firmware pp4x confirm unit 1' command in the
CLI.
2014-09-11 16:59:46 switch %FIRMWARE: 'firmware pp4x confirm unit 1' command entered.
```

41 Active alarms log

41.1 Introduction

The system of logging is built on a central application *systemdb*, which organizes interfaces to events database (DB). All emerging events both from interface boards and PP4X switch itself are sent into *systemdb* to be saved in the base.

All events are divided into 2 types: one-time and state changing events. One-time events are saved in the base and generate SNMP trap, if necessary. State changing events imply the following: if the state has changed (e.g., Link Flapping has been found on interface) and this state is normalized, then we will get a new event indicating situation improvement. State changing events, if they are alarms, are to be added into a list of active alarms during registration in the base. If situation gets corrected the alarm will be removed from active alarms.

41.2 Alarm generation and registration

An event can get into the system of logging by two methods: it can be generated at PP4X itself, or on one of interface boards in MA4000 basket. All codes of events in the basket are entered into a common list for convenience to promptly get SNMP OID code for any event.

41.2.1 Alarm/Event structure

- Alarm code – code of alarm MA4000, an integer value which can range from 1000 to 7000. PP4X uses a range from 1000 to 3000.
- Time – time of occurrence of alarm of this type. Number in seconds since the beginning of the era.
- Priority – alarm rate. An integer from 0 to 3.
- Text – a text field with description up to 255 characters. The name of alarm as well as auxiliary parameters are always preserved in Text field.
- Params – array of 4 integers specific for every particular alarm or notification.

The Active field will indicate, whether this particular alarm is currently active. The alarm will be active from the time of arriving of the first alarm of this type until arrival of an event for its normalization. E.g.: the state will always be Active for ALARM_LINK_CHANGED after dropping the port unless ALARM_LINK_CHANGED event arrives indicating that the port has recovered again.

Time field – time of occurrence of the event.

41.2.2 Alarms rates

- Critical – Critical, level 0. Basket operation functionality is disturbed.
- Major – High, level 1. Separate basket modules operation is affected.
- Minor – Low, level 2. Non-critical problems in separate modules.
- Notify – Notification, level 3. Not an alarm, informs on the event that occurred.

41.2.3 Alarms

Alarms from MA4000_ALARM_SLOT family are generated in case of non-standard situations with interface modules in the basket.

All of them feature the following parameters:

- 0 – slot number
- 1 – device type code
- 2 – device version (hw, major, minor)
- 3 – build of device version

Name: MA4000_ALARM_SLOT_INVALID
 Description: Alarm occurring when board type in a slot does not correspond to basket configuration.
 Alarm rate: Major

Name: MA4000_ALARM_SLOT_DOWN
 Description: Alarm in case of link (slot-channel) drop towards interface board.
 Alarm rate: Critical

Name: MA4000_ALARM_SLOT_ERROR
 Description: Alarm in case of error in connection with interface board. May be caused due to board pending.
 Alarm rate: Critical

Name: MA4000_ALARM_PP4X_UNIT_LOST
 Description: Alarm on unplanned loss of one of PP4X units in a basket.
 Alarm rate: Critical
 Parameters:

- 0 – number of a missing unit;
- 1 – right or left unit is missing.

Name: MA4000_ALARM_SYNC_DISALLOWED
 Description: Alarm when configuration synchronization between PP4X units in a basket is disallowed.
 Alarm rate: Critical
 Parameters:

- 0 – number of a unit, with which synchronization is disallowed.

Name: MA4000_FAN_CONTROLLER_FAIL
 Description: Alarm at fan controller failure.
 Alarm rate: Major
 Parameters: none.

Name: MA4000_CONFIG_SAVE_FAIL
 Description: Alarm at error of PP4X configuration saving to memory.
 Alarm rate: Major
 Parameters: none.

Name: MA4000_ALARM_LINK_DOWN
 Description: Alarm as a result of link drop on PP4X.
 Alarm rate: Minor
 Parameters:

- 0 – interface idb ID.

Name: MA4000_PORT_CNTR_ERRORS_FOUND
 Description: Alarm at revealing errors at PP4X ports.

Alarm rate: Minor

Parameters:

- 0 – idb ID of port, where errors have been detected.

Name: MA4000_FAN_FAIL

Description: Alarm at failure of one of the basket fans.

Alarm rate: Major

Parameters:

- 0 – Number of a failing basket fan.

41.2.4 Alarms normalization

Name: MA4000_ALARM_SLOT_OK

Description: Notification on interface board being in a normal operation state. It clears all other alarms of MA4000_ALARM_SLOT family for this slot.

Alarm rate: Notify

Name: MA4000_ALARM_PP4X_UNIT_LOST_OK

Description: Notification on revealing PP4X unit lost earlier in the basket.

Alarm rate: Notify

Parameters:

- 0 – number of a found unit;
- 1 – right or left unit is found.

Name: MA4000_ALARM_SYNC_DISALLOWED_OK

Description: Notification on allowing configuration synchronization with this unit. It clears alarm MA4000_ALARM_SYNC_DISALLOWED.

Alarm rate: Notify

Parameters:

- 0 – number of a unit, with which synchronization is allowed.

Name: MA4000_FAN_CONTROLLER_FAIL_OK

Description: Notification on restoring serviceability of fans controller. It clears alarm MA4000_FAN_CONTROLLER_FAIL. It clears alarm MA4000_FAN_CONTROLLER_FAIL.

Alarm rate: Notify

Parameters: none.

Name: MA4000_ALARM_LINK_UP

Description: Notification on a link appearing at port PP4X. It clears alarm MA4000_ALARM_LINK_DOWN for this port.

Alarm rate: Notify

Parameters:

- 0 – interface idb ID.

Name: MA4000_PORT_CNTR_ERRORS_FREE

Description: Notification on discontinued errors at ports PP4X. It clears alarm MA4000_PORT_CNTR_ERRORS_FOUND.

Alarm rate: Notify

Parameters:

- 0 – idb ID of a port, where no more errors have been detected.

Name: MA4000_FAN_OK

Description: Notification on restoring serviceability of fan. It clears alarm MA4000_FAN_FAIL.

Alarm rate: Notify

Parameters:

- 0 – number of the fan that has restored its operability.

41.2.5 Notifications

Name: MA4000_ALARM_BUFFER_OVERFLOW

Description: A system event occurring in case of alarm queue overflow prior to saving into database.

Alarm rate: Notify

Parameters:

- 0 – number of alarms lost.

Name: MA4000_ALARM_REBOOT_STACK

Description: Notification on entire basket reboot by a command.

Alarm rate: Notify

Parameters: none.

Name: MA4000_ALARM_REBOOT_UNIT

Description: Notification on a separate unit reboot by a command.

Alarm rate: Notify

Parameters:

- 0 – unit number;
- 1 – whether this unit was a master.

Name: MA4000_ALARM_REBOOT_FW_TIMER

Description: Notification on expired confirmation timer after firmware update on PP4X board.

Alarm rate: Notify

Parameters:

- 0 – unit number.

Name: MA4000_ALARM_OMS

Description: Family of notifications on errors at loading/unloading basket configuration through EMS network control system.

Alarm rate: Notify

Parameters:

- 0 – type of command, which reached completion with an error. Configuration downloading or uploading to a remote server;
- 1 – field is constant. Indication that the error has occurred during file operation;
- 2 – code of error, with which operation reached completion.

Name: MA4000_ALARM_OMS_OK
 Description: Notification for the EMS network control system on successful downloading/uploading of configuration.
 Alarm rate: Notify
 Parameters: none.

Name: MA4000_ALARM_FW_UPDATE_FAIL
 Description: Notification on the error occurred during updating firmware version and libraries for interface boards in MA4000 basket.
 Alarm rate: Notify
 Parameters:

- 0 – code of error, with which operation reached completion.

Name: MA4000_ALARM_FW_UPDATE_OK
 Description: Notification on successful updating of firmware version and libraries for interface boards in MA4000 basket.
 Alarm rate: Notify
 Parameters: none.

Name: MA4000_ALARM_FW_CONFIRM_NEEDED
 Description: Notification sent to the EMS network control system after updating firmware on PP4X informing on the necessity to perform a confirm command.
 Alarm rate: Notify
 Parameters:

- 0 – unit number.

Name: MA4000_CONFIG_APPLIED
 Description: Notification on PP4X configuration applied.
 Alarm rate: Notify
 Parameters:

- 0 – current number of configuration revision

Name: MA4000_CONFIG_SAVED
 Description: Notification on PP4X configuration saved to flash memory.
 Alarm rate: Notify
 Parameters: none.

Name: MA4000_CONFIG_RESTORE
 Description: Notification on restoration of PP4X configuration or interface board to a previous version. It is a result of a restore command; also appears in case of expiry of a timer set for a confirm command.
 Alarm rate: Notify
 Parameters:

- 0 – type of device, which has rolled back configuration;
- 1 – slot number (if it is interface board).

Name: MA4000_CSCD_MASTER_CHANGED
Description: Notification on a change of a master in basket.
Alarm rate: Notify
Parameters:

- 0 – number of a new master unit;
- 1 – RH or LH unit became a master.

42 PP4X monitoring

42.1 PP4X resource status

To view the command dispatcher information, use the **show cmd-dispatcher** command:

```
ma4000# show cmd-dispatcher
Command Dispatcher memory state:
  overload count      0
  errors              0
  size of element    1192
  free                500
  length              500
```

To view the event dispatcher information, use the **show evt-dispatcher** command:

```
ma4000# show evt-dispatcher
Command Dispatcher memory state:
  overload count      0
  errors              0
  size of element    992
  free                500
  length              500
```

To view the system queue identifiers, use **the show queue** command:

```

ma4000# show queue
Registered queues:
command top manager          id 1
event exchange              id 2
control exchange            id 3
mac sync event descriptors  id 4
mac sync control descriptors id 5
cscd event descriptors      id 6
cscd command descriptors    id 7
config manager event descriptor id 8
config manager command descriptor id 9
pstate check event descriptors id 10
pstate check control descriptor id 11
sshd event descriptors      id 12
telnetd event descriptors   id 13
firmware manager event descriptor id 14
firmware manager command descriptor id 15
maep cmd descriptors        id 16
maep evt descriptors        id 17
vlan cmd descriptors        id 18
vlan evt descriptors        id 19
acsd event descriptors      id 20
fan event descriptors       id 21
arp event descriptors       id 22
arp command descriptors     id 23
iprouting event descriptors id 24
iprouting command descriptors id 25
igmp snooping event descriptors id 26
igmp snooping command descriptor id 27
snmpag evt descriptors      id 28
snmpag cmd descriptors      id 29
bonding event descriptors   id 30
bonding command descriptors id 31
dhcp client event descriptors id 32
dhcp proxy event descriptors id 33
dhcp proxy command descriptors id 34
dhcp server event descriptors id 35
stp event descriptors       id 36
stp command descriptors     id 37
lldp event descriptors      id 38
lldp command descriptors    id 39
sntp client event descriptors id 40
Total queues 40

```

To view the state of the selected queue, use the **show queue** command with the queue identifier as a parameter.

```

ma4000# show queue 0
Queue event top manager      :
    tx count                  17
    rx count                  17
    overload count            0
    read from empty count     0
    pipe read errors          0
    pipe write errors         0
    size of element           4
    free                      500
    length                    500

```

42.2 MAC table preview

To view the MAC address table, use the **show mac pp4** command:

```
ma4000# show mac pp4
```

```

Mac table
~~~~~

```

##	VID	MAC address	Port
1	1	00:80:c2:00:00:00	0/CPU
2	1	00:80:c2:00:01:01	slot-channel 0
3	1	a8:f9:4b:88:50:40	slot-channel 0
4	1	00:80:c2:00:01:02	slot-channel 1
5	1	00:80:c2:00:01:03	slot-channel 2
6	1	00:80:c2:00:01:04	slot-channel 3
7	1	00:80:c2:00:01:05	slot-channel 4
8	1	00:80:c2:00:01:06	slot-channel 5
9	1	00:80:c2:00:01:07	slot-channel 6
10	1	00:80:c2:00:01:08	slot-channel 7
11	1	00:80:c2:00:01:09	slot-channel 8
12	1	00:80:c2:00:01:0a	slot-channel 9
13	1	00:80:c2:00:01:0b	slot-channel 10
14	1	00:80:c2:00:01:0c	slot-channel 11
15	1	00:80:c2:00:01:0d	slot-channel 12
16	1	00:80:c2:00:01:0e	slot-channel 13
17	1	00:80:c2:00:01:0f	slot-channel 14
18	1	00:80:c2:00:01:10	slot-channel 15
19	30	a8:f9:4b:82:8b:80	port-channel 1
20	30	a8:f9:4b:82:99:80	port-channel 1
21	30	a8:f9:4b:c0:2a:7a	slot-channel 0
22	199	a8:f9:4b:81:85:b0	1/CPU
23	199	a8:f9:4b:81:85:f0	2/CPU
24	199	00:15:17:e4:27:ca	port-channel 1
25	199	a8:f9:4b:82:8b:80	port-channel 1
26	199	a8:f9:4b:84:d0:c0	port-channel 1
27	1101	00:15:17:e4:27:ca	port-channel 1
28	1101	1c:bd:b9:d8:08:e5	port-channel 1
29	1101	a8:f9:4b:84:f5:40	port-channel 1
30	1200	00:15:17:e4:27:ca	port-channel 1
31	1200	00:aa:bb:cc:dd:ee	port-channel 1
32	1200	08:60:6e:6d:1a:97	port-channel 1
33	1200	a8:f9:4b:03:53:67	port-channel 1
34	1200	a8:f9:4b:03:54:b1	port-channel 1
35	1200	a8:f9:4b:03:66:2d	port-channel 1
36	1200	a8:f9:4b:03:74:08	port-channel 1
37	1200	a8:f9:4b:03:74:a3	port-channel 1
38	1200	a8:f9:4b:2a:58:e7	port-channel 1
39	1200	a8:f9:4b:2a:59:37	port-channel 1
40	1200	a8:f9:4b:2a:59:57	port-channel 1
41	1200	a8:f9:4b:2a:59:8f	port-channel 1
42	1200	a8:f9:4b:2a:75:b2	port-channel 1
43	1200	a8:f9:4b:2a:75:e2	port-channel 1
44	1200	a8:f9:4b:2a:76:4a	port-channel 1
45	1200	a8:f9:4b:2a:76:8a	port-channel 1
46	1200	a8:f9:4b:2a:76:aa	port-channel 1
47	1200	a8:f9:4b:2a:76:fa	port-channel 1
48	1200	a8:f9:4b:2a:77:8a	port-channel 1
49	1200	a8:f9:4b:2a:77:fa	port-channel 1
50	1200	a8:f9:4b:2a:78:3a	port-channel 1
51	1200	a8:f9:4b:2a:78:42	port-channel 1

```

52      1200  e0:d9:e3:58:0c:57  port-channel 1
53      1342  1c:bd:b9:d8:08:e5  port-channel 1
54      4094  a8:f9:4b:81:85:b0  1/CPU
55      4094  a8:f9:4b:81:85:f0  2/CPU

```

55 valid mac entries

```
ma4000# show mac pp4 include vlan 30
```

```

      Mac table
      ~~~~~
##      VID      MAC address      Port
-----
1       30       a8:f9:4b:82:8b:80  port-channel 1
2       30       a8:f9:4b:82:99:80  port-channel 1
3       30       a8:f9:4b:c0:2a:7a  slot-channel 0

```

3 valid mac entries

```
ma4000# show mac slot 0 include vlan 30
```

```

      Mac table
      ~~~~~
##      VID      MAC address      Port
-----
1       30       a8:f9:4b:c0:2a:7a  plc-pon-port 0/0
2       30       a8:f9:4b:81:85:b0  plc-slot-channel 0/0
3       30       a8:f9:4b:82:8b:80  plc-slot-channel 0/0
4       30       a8:f9:4b:82:99:80  plc-slot-channel 0/0

```

4 valid mac entries

42.3 PP4X interface status preview

To view the PP4X interface status, use the **show interface <id> status** command:

PP4X interfaces include: front-port, slot-port.

```

ma4000# show interface front-port 1/0-5 status
Interface          Status      Media      Speed      Duplex      Flow control
-----
front-port 1/0    up         copper     1 Gbps     full        no
front-port 1/1    down      none      10 Mbps    half        no
front-port 1/2    down      none      10 Mbps    half        no
front-port 1/3    down      none      10 Mbps    half        no
front-port 1/4    down      none      10 Mbps    half        no
front-port 1/5    down      none      10 Mbps    half        no
ma4000# show interface slot-channel 0-15 status
Interface          Status      Media      Speed      Duplex      Flow control
-----
slot-channel 0     up         none      10 Gbps    full        no
slot-channel 1     down      none      10 Mbps    full        no
slot-channel 2     down      none      10 Mbps    full        no
slot-channel 3     down      none      10 Mbps    full        no
slot-channel 4     down      none      10 Mbps    full        no
slot-channel 5     down      none      10 Mbps    full        no
slot-channel 6     down      none      10 Mbps    full        no
slot-channel 7     down      none      10 Mbps    full        no
slot-channel 8     down      none      10 Mbps    full        no
slot-channel 9     down      none      10 Mbps    full        no
slot-channel 10    down      none      10 Mbps    full        no
slot-channel 11    down      none      10 Mbps    full        no
slot-channel 12    down      none      10 Mbps    full        no
slot-channel 13    down      none      10 Mbps    full        no
slot-channel 14    down      none      10 Mbps    full        no
slot-channel 15    down      none      10 Mbps    full        no

```


42.4 PP4X interface statistics preview

Step 1. To view the PP4X interface statistics, execute the **show interface <id> counters** command:

PP4X interfaces include: front-port, slot-port.

```

ma4000# show interface front-port 1/0-5 counters

```

Port	UC recv	MC recv	BC recv	Octets
front-port 1/0	518876	700984	621179	355511502
front-port 1/1	0	0	0	0
front-port 1/2	0	0	0	0
front-port 1/3	0	0	0	0
front-port 1/4	0	0	0	0
front-port 1/5	0	0	0	0

Port	UC sent	MC sent	BC sent	Octets
front-port 1/0	72143	32429	65	16839599
front-port 1/1	0	0	0	0
front-port 1/2	0	0	0	0
front-port 1/3	0	0	0	0
front-port 1/4	0	0	0	0
front-port 1/5	0	0	0	0

Step 2. For detailed statistics, use the **show interface <id> counters detail** command:

```

ma4000# show interface front-port 1/0 counters detail
Counter                               Value
-----                               -
UC sent                               127
MC sent                               13
BC sent                               8
Octets sent                           11899
UC rcv                                182
MC rcv                                131
BC rcv                                50
Octets rcv                             40473
Bad octets rcv                         0
MAC transmit err                       0
Bad frames rcv                         0
Frames 64 octets pass                   47
Frames 65-127 octets pass               320
Frames 128-255 octets pass              142
Frames 256-511 octets pass              2
Frames 512-1023 octets pass             0
Frames 1024-max octets pass             0
Excessive collisions                   0
Unrec MAC cntr rcv                     0
FC sent                                0
Good fc rcv                            0
Drop events                            0
Undersize packets                      0
Fragments packets                      0
Oversize packets                       0
Jabber packets                         0
MAC receive err                        0
Bad CRC                                 0
Collisions                             0
Late collisions                        0
Bad FC rcv                             0
Current load Kbits sent/sec             1
Current load Kbits rcv/sec              3
Current load frames sent/sec            2
Current load frames rcv/sec             5
5:00 average Kbits sent/sec             0
5:00 average Kbits rcv/sec              1
5:00 average frames sent/sec            0
5:00 average frames rcv/sec             1

```

Step 3. To view the interface load, execute the **show interface <id> utilization** command. Command output shows the load for the last period, defined by the **load-average** command:

```

ma4000# show interface front-port 1/0 utilization

  Last utilization counters
  ~~~~~
Port          Kbits sent/sec   Kbits rcv/sec   Frames sent/sec   Frames rcv/sec
-----
front-port 1/0  2                 3                 3                 5

  5m:00s utilization average
  ~~~~~
Port          Kbits sent/sec   Kbits rcv/sec   Frames sent/sec   Frames rcv/sec
-----
front-port 1/0  0                 1                 0                 1

```

42.5 Interface mirroring

Port mirroring is used to duplicate the traffic on monitored ports by sending ingress or and/or egress packets to the controlling port. Users can define a controlled port and controlling ports and select the type of the traffic (ingress or egress), which will be sent to the controlling port. In this example, all the traffic from the *slot-port 0* will be forwarded to the *front-port 1/5*, where it may be viewed using protocol analyzers (e.g. wireshark).

42.5.1 Configuration of the controlled port

Step 1. Define mirroring parameters for the inbound and outbound traffic:

```
ma4000# configure terminal
ma4000(config)# mirror rx interface slot-port 0
ma4000(config)# mirror tx interface slot-port 0
```

Step 2. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
```

42.5.2 Configuration of the controlling port

Step 1. Configure mirroring and traffic analysis for any **front-port**:

```
ma4000(config)# mirror rx analyzer front-port 1/5
ma4000(config)# mirror tx analyzer front-port 1/5
```

Step 2. Apply the configuration by using the **commit** command:

```
ma4000(config)# do commit
```

43 PLC8 monitoring

43.1 GPON OLT state

Step 1. To view the state of GPON OLT, use the **show slot <SLOT> gpon olt state** command:

```
ma4000# show slot 0 gpon olt state
Device count:          2
Gpon-ports per device: 4
Driver version:       1.2.561
Device 0:
  Firmware version:   2.3.37.1036
  Hardware version:   5211.2
Device 1:
  Firmware version:   2.3.37.1036
  Hardware version:   5211.2
```

GPON OLT parameters are listed and described in [Table 25](#).

Table 25 – GPON OLT parameters

Parameter	Description
Device count	The number of OLT chips
Channels per device	The number of channels in one OLT chip
Firmware version	OLT chip firmware version
Hardware version	OLT chip hardware version

43.2 GPON interface state

Step 1. To view the state of GPON interfaces, use the **show interface gpon-port <SLOT>/0-7 state** command:

```

ma4000# show interface gpon-port 0/0-7 state
Reading: .....
Gpon-ports status information:
  Gpon-port:                0          1          2          3
4      5      6      7
OK      OK      OK      OK
  State:                    OK      OK      OK      OK
0      0      0      0
  ONT count:                2          0          0          0
enabled enabled enabled enabled
  ONT autofind:             enabled  enabled  enabled  enabled
n/a     n/a     n/a     n/a
  SFP vendor:               NEOPHOTONICS  n/a     Ligent  n/a
n/a     n/a     n/a     n/a
  SFP product number:      38J0-6537E-ST+  n/a     LTE3680M-BC  n/a
n/a     n/a     n/a     n/a
  SFP vendor revision:    1.0          n/a     1.0          n/a
n/a     n/a     n/a     n/a
  SFP temperature [C]:    36           n/a     44           n/a
n/a     n/a     n/a     n/a
  SFP voltage [V]:        3.15         n/a     3.15         n/a
n/a     n/a     n/a     n/a
  SFP tx bias current [mA]: 10.72        n/a     17.09        n/a
n/a     n/a     n/a     n/a
  SFP tx power [dBm]:     5.31         n/a     3.89         n/a
n/a     n/a     n/a     n/a

```

Table 26 – GPON interface parameters

Parameter	Description
Channel	Channel number
State	Channel state
ONT count	The number of ONTs in the channel
SFP vendor	SFP vendor
SFP product number	SFP model
SFP vendor revision	SFP revision
SFP temperature	SFP temperature in Celsius degrees
SFP voltage	SFP voltage in volts
SFP tx bias current	Bias current in mA

Parameter	Description
SFP tx power	Transmission power in dBm

Table 27 – GPON interface states

Value	Description
INITED	The channel is initialised
CFGINPROGRESS	The channel configuration is in progress
CFGFAILED	The channel configuration completed with error
OK	The channel is in operation
FAILED	The channel is out of operation
DISABLED	The channel is disabled

Step 3. To view the state of only GPON interface, execute the **show interface gpon-port < SLOT > / < ID > state** command:

```
ma4000# show interface gpon-port 0/0 state
Reading: .
Gpon-port status information:
  Gpon-port:                0
  State:                    OK
  ONT count:                2
  ONT autofind:             enabled
  SFP vendor:               NEOPHOTONICS
  SFP product number:       38J0-6537E-ST+
  SFP vendor revision:      1.0
  SFP temperature [C]:      36
  SFP voltage [V]:          3.15
  SFP tx bias current [mA]: 10.72
  SFP tx power [dBm]:       5.31
```

43.3 MAC table preview

Step 1. To view the table of MAC addresses on the 2nd GPON interfaces slot 0 , execute the **show mac interface gpon-port 0/2** command:

```
ma4000# show mac interface gpon-port 0/2
Mac table
~~~~~
##      ONT Serial                ONT ID  GPON-port  GEM  UVID  CVID  SVID  MAC
--      -
1      454C54581A000035           40      2         640   10    302   1105  A8:F9:4B:5A:BD:15
2      454C54581A000035           40      2         643    9     9    1105  A8:F9:4B:5A:BD:14
3      454C54581C002D0A           35      2         603    9     9    1105  A8:F9:4B:71:66:49
4      454C54585C0104B0           39      2         635    9     9    1105  A8:F9:4B:C2:30:BA
5      454C54581A025A1F           63      2         825   12    305   1105  A8:F9:4B:6E:A4:02
6      454C54585F000010           38      2         627    9     9    1105  A8:F9:4B:C0:00:59
7      454C54581A025A1F           63      2         827    9     9    1105  A8:F9:4B:6E:A4:00
8      454C54581A025A1F           63      2         824   10    305   1105  A8:F9:4B:6E:A4:01

8 valid mac entries
```

43.4 Statistics for GPON interfaces

Step 1. To view statistics on GPON interfaces, use the **show interface gpon-port counters** command:

```
show interface gpon-port 0/0-7 counters

##      Downstream counters for channels:           0           1           2           ...

2      RX DS octets                                1627665    1627665    1627665
3      RX DS packets                               21044      21044      21044
5      RX DS octets for channel                    1627665           0           0
6      RX DS packets for channel                  21044           0           0
8      TX DS octets                               13585411           0           0
9      TX DS packets                              266867           0           0
11     DS octets                                  1422563           0           0
12     DS packets                                20261           0           0
13     DS unicast packets                        18424           0           0
14     DS multicast packets                       958            0           0
15     DS broadcast packets                       879            0           0
16     DS packet dropped                          383            0           0

##      Upstream counters for channels:           0           1           2

2      TX US octets                               1704580           0           0
3      TX US packets                              19966            0           0
5      US octets                                  1457760           0           0
6      US packets                                19560            0           0
7      US unicast packets                        18709            0           0
8      US multicast packets                       400              0           0
9      US broadcast packets                       451              0           0
10     US packed dropped                          50               0           0
11     Packet dropped (CRC)                       0                0           0
13     TX US octets reassembly                    17909382           0           0
14     TX US packets reassembly                  265915            0           0
```

43.5 Statistics for OLT V interfaces

Step 1. To view statistics of OLT V interfaces (ethernet interfaces that are connected to a switch interface module), execute the **show interface gpon-port <SLOT>/0-7 counters v-interface** command:

```
ma4000# show interface gpon-port 0/0-7 counters v-interface
```

##	Downstream counters	for	channels:	0	1	2	3	4	5	6	7
1	RX Alignment errors			0	0	0	0	0	0	0	0
2	RX Pause frames			0	0	0	0	0	0	0	0
3	RX CRC-32 errors			0	0	0	0	0	0	0	0
4	RX Oversize errors			0	0	0	0	0	0	0	0
5	RX Bad FCS			0	0	0	0	0	0	0	0
6	RX Too long frames			0	0	0	0	0	0	0	0
7	RX Undersize errors			0	0	0	0	0	0	0	0
8	RX Range errors			0	0	0	0	0	0	0	0
9	RX Ok frames			21229	0	0	0	2	0	0	0
10	RX total frames			21229	0	0	0	2	0	0	0
11	RX 64 octets frames			0	0	0	0	0	0	0	0
12	RX 65-127 octets frames			20715	0	0	0	2	0	0	0
13	RX 128-255 octets frames			65	0	0	0	0	0	0	0
14	RX 256-511 octets frames			404	0	0	0	0	0	0	0
15	RX 512-1023 octets frames			42	0	0	0	0	0	0	0
16	RX 1024-1518 octets frames			3	0	0	0	0	0	0	0
17	RX 1519-MAX octets frames			0	0	0	0	0	0	0	0
18	RX Total unicast packets			18994	0	0	0	0	0	0	0
19	RX Total multicast packets			966	0	0	0	0	0	0	0
20	RX Total broadcast packets			1269	0	0	0	2	0	0	0
22	RX Total octets			1641763	0	0	0	152	0	0	0
24	RX Ok octets			1641763	0	0	0	152	0	0	0
25	RX FIFO overflow errors			0	0	0	0	0	0	0	0
26	RX Bad FCS and <64 octets			0	0	0	0	0	0	0	0
27	RX Frame errors			0	0	0	0	0	0	0	0
##	Upstream counters			0	1	2	3	4	5	6	7
1	TX frames without errors			20146	0	0	0	0	0	0	0
2	TX valid pause frames			0	0	0	0	0	0	0	0
3	TX frames with errors			0	0	0	0	0	0	0	0
4	TX good unicast packets			19274	0	0	0	0	0	0	0
5	TX good multicast packets			404	0	0	0	0	0	0	0
6	TX good broadcast packets			468	0	0	0	0	0	0	0
8	TX octets			1719437	0	0	0	0	0	0	0

43.6 Multicast statistics

Step 1. To view statistics of MC flows, execute the **show interface gpon-port <SLOT>/<PORT> igmp groups** command. As a parameter, pass the channel number. Pass the interface interval as a parameter:

```
ma4000# show interface gpon-port 0/0 igmp groups
```

All IGMP groups (4):

#	Channel	Serial	Multicast address	Start	Stop
1	0	ELTX1A025A08	239.255.255.250	2014.04.17 13:54:54	2014.04.17 14:22:07
2	0	ELTX1A025A08	239.255.255.250	2014.04.17 14:26:06	2014.04.17 14:32:48
3	0	ELTX1A025A08	239.255.255.250	2014.04.17 14:36:35	2014.04.17 14:42:53
4	0	ELTX1A025A08	239.255.255.250	2014.04.17 14:46:57	2014.04.17 15:37:05

44 ONT monitoring

44.1 ONT configurations list

Step 1. To view active ONT configurations, use the **show interface ont <SLOT>/<PORT> configured** command:

```
ma4000# show interface ont 0/0 configured

-----
Slot 0 GPON-port 0 ONT configured list
-----

  ##          Serial      ONT ID  GPON-port      Status  RSSI[dBm]      Version
EquipmentID  Description
  1          ELTX5C090878    0        0             OFFLINE      n/a             n/a
n/a
  2          ELTX1A002E79    1        0             OK           -30.97         3.25.1.1225
NTP-RG-1402G-W:rev.C
  3          ELTX5F0003B0    2        0             OK           -28.65         3.25.4.915
NTU-2V
```

44.2 List of empty ONT configurations

Step 1. To view ONT empty configurations, execute the **show interface ont <SLOT>/<PORT> unconfigured** command:

```
ma4000# show interface ont 0/0 unconfigured

Slot 0 GPON-port 0 has no unconfigured ONTs
Slot 0 total ONT count: 0
```

44.3 List of connected ONTs

Step 1. To view the list of online ONTs, use the **show interface ont <SLOT>/<PORT> online** command:

```
ma4000# show interface ont 0-15/0-7 online

Slot 0 GPON-port 0 has no online ONTs
Slot 0 GPON-port 1 has no online ONTs
Slot 0 GPON-port 2 has no online ONTs
Slot 0 GPON-port 3 has no online ONTs
Slot 0 GPON-port 4 has no online ONTs
Slot 0 GPON-port 5 has no online ONTs
Slot 0 GPON-port 6 has no online ONTs
Slot 0 GPON-port 7 has no online ONTs

Slot 0 total ONT count: 0
```

Table 28 – ONT status description

ONT status	Description
UNACTIVATED	ONT has no configurations
ALLOCATED	ONT detected
AUTHINPROGRESS	ONT authentication is in progress
AUTHFAILED	Authentication failed
AUTHOK	Authentication successfully completed
PRECONFIG	Preparing ONT for configuration
CFGINPROGRESS	ONT configuration is in progress
CFGFAILED	Configuration failed
OK	ONT is in operation
BLOCKED	ONT is blocked
MIBRESET	ONT MIB reset
FAILED	ONT has a critical failure
FWUPDATING	ONT firmware update is in progress
DISABLED	ONT is disabled (technically blocked)

44.4 List of disconnected ONTs

Step 1. To view the list of disconnected ONTs, execute the **show interface ont <SLOT>/<PORT> offline** command. If necessary, pass the number of the GPON interface as a parameter.

```
ma4000# show interface ont 0-15/0-7 offline

-----
Slot 0 GPON-port 0 ONT offline list
-----

  ##                Serial          ONT ID   Assigned channel   Description
  1                0000000000000000          0           0

Slot 0 GPON-port 1 has no offline ONTs
Slot 0 GPON-port 2 has no offline ONTs
Slot 0 GPON-port 3 has no offline ONTs
Slot 0 GPON-port 4 has no offline ONTs
Slot 0 GPON-port 5 has no offline ONTs
Slot 0 GPON-port 6 has no offline ONTs
Slot 0 GPON-port 7 has no offline ONTs
Slot 0 total ONT count: 1
```

44.5 ONT statistics

To view ONT statistics, use the **show interface ont <SLOT>/<PORT>/<ID> counters** command. Pass the number of requested statistical data (see [Table 29](#)) and ONT ID as parameters.

```
ma4000# show interface ont 0/0/0 counters gem-port-nctp-performance-monitoring

-----
[ONT0/0/0] counters
-----

  ##   Downstream counters for cross-connects:   0   1   ...   7   MC   BC
  1   Finished intervals                        23  ---  ...  ---  ---  23
  2   Received GEM frames                       0   ---  ...  ---  ---  0
  4   Received payload bytes                    0   ---  ...  ---  ---  0

  ##   Upstream counters for cross-connects:     0   1   ...   7   MC   BC
  1   Finished intervals                        23  ---  ...  ---  ---  23
  2   Transmitted GEM frames                    0   ---  ...  ---  ---  0
  4   Transmitted payload bytes                 0   ---  ...  ---  ---  0
```

Table 29 – ONT statistics types

Statistics type	Description	Scope
cross-connect	GEM port statistics	OLT
gem-port-performance-monitoring	GEM port statistics	ONT

Statistics type	Description	Scope
gem-port-nctp-performance-monitoring	GEM port statistics	ONT
ethernet-performance-monitoring-history-data	ETH port statistics (G.984.4)	ONT
ethernet-performance-monitoring-history-data2	ETH port statistics (G.984.4)	ONT
ethernet-performance-monitoring-history-data3	ETH port statistics (G.984.4)	ONT
gal-ethernet-performance-monitoring-history-data	Statistics on transition of from GEM to ETH	ONT
fec-performance-monitoring-history-data	Statistics on redundant coding	ONT
ethernet-frame-extended-performance-monitoring	ETH port statistics (G.988)	ONT
multicast-subscriber-monitor	Multicast statistics	ONT

44.6 ONT bit error rate

✔ **Bit error rate (BER) is the rate of errors in data transmission.**

To view BER on reception at the ONT, use the **show interface gpon-port <slot>/<port> downstream-ber** command. As a parameter, pass the number of the GPON interface.

```
ma4000# show interface ont 0-15/0-7 downstream-ber
```

```
-----  
Slot 0 GPON-port 0 BER table
```

```
-----  
No records
```

```
-----  
Slot 0 GPON-port 1 BER table
```

```
-----  
No records
```

```
-----  
Slot 0 GPON-port 2 BER table
```

```
-----  
No records
```

```
-----  
Slot 0 GPON-port 3 BER table
```

```
-----  
No records
```

```
-----  
Slot 0 GPON-port 4 BER table
```

```
-----  
No records
```

```
-----  
Slot 0 GPON-port 5 BER table
```

```
-----  
No records
```

```
-----  
Slot 0 GPON-port 6 BER table
```

```
-----  
No records
```

```
-----  
Slot 0 GPON-port 7 BER table
```

```
-----  
No records
```

45 PWR IN modules replacement

This section describes the replacement procedure for one of the PWR IN modules without actual shutdown of the access node.

Step 1. Use the **show system environment** command to ensure that the power supply is present on both feeders:

```
ma4000# show system environment
MFC board status:      ok
MFC board version:    0x2
MFC firmware:
  Status:              0x00 (ok)
  Version:             8 2 1 1 5 05/11/2013
  Timestamp (UTC):    05-Nov-2013 12:19:22

Fan configured speed, %: auto
Fan current speed, %: 57
Fan minimum speed, %: 15
Fan speed levels, %:  15 25 36 46 57 68 78 89 100

                Fan0      Fan1      Fan2
Status:          ok        ok        ok
RPM:             1824     1818     1860

                Feeder1   Feeder2
Status:          ok        ok
Current, A:      0.52     1.00
Voltage, V:      -51.25   -53.75

Shelf voltage, V: -54.28
```

Step 2. Disable the power supply on one of the feeders using the power distribution device (depends on the project).

Step 3. Use the voltmeter gauge to make sure, that there is no voltage on the input terminals of the **PWR IN** module.

Step 4. Disconnect cables from the power module input terminals.

Step 5. Remove the screw that holds the power input module in the chassis. Pull out the module bracket and remove it from the chassis.

Step 6. Install a new **PWR IN** module into the chassis. Fasten the screw that holds the power input module in the chassis.

Step 7. Connect cables to the input terminals of the power module observing correct polarity.

Step 8. Power up the disabled feeder.

Step 9. Use the **show system environment** command to ensure that the power supply is present on both feeders.

46 MFC module replacement

You can replace the MFC module without actual shutdown of the access node.

Step 1. Remove the screw that holds the **MFC** module in the chassis.

Step 2. Pull out the module bracket and remove it from the chassis. Fans will switch to maximum performance mode.

Step 3. Install a new **MFC** module into the chassis. Fasten the screw that holds the **MFC** module in the chassis.

Step 4. Use the **show system environment** command to ensure that the new module has been successfully identified by the system. Fans will switch to normal performance mode:

```
ma4000# show system environment
MFC board status:      ok
MFC board version:    0x2
MFC firmware:
  Status:              0x00 (ok)
  Version:              8 2 1 1 5 05/11/2013
  Timestamp (UTC):     05-Nov-2013 12:19:22

Fan configured speed, %: auto
Fan current speed, %:  57
Fan minimum speed, %:  15
Fan speed levels, %:   15 25 36 46 57 68 78 89 100

                Fan0      Fan1      Fan2
Status:          ok        ok        ok
RPM:             1824      1818      1860

                Feeder1   Feeder2
Status:          ok        ok
Current, A:      0.52      1.00
Voltage, V:      -51.25    -53.75

Shelf voltage, V: -54.28
```

47 PP4X central switch module replacement

You can replace PP4X modules without actual shutdown of the access node only when there are two PP4X modules installed in the rack.

Step 1. If the module to be replaced is the master module, you should change the master for this access node:

```
ma4000# stack master change
```

Step 2. Make sure, that the master has been changed successfully for this access node:

```
ma4000# show stack

Stack Units
~~~~~
Unit  Position  Role    Prio  MAC Address          Version
----  -
*1    Left        MASTER  240   a8:f9:4b:81:85:b0    3 26 1 83 47784
2     Right        BACKUP  208   a8:f9:4b:81:85:f0    3 26 1 83 47784

Synchronization state in the stack: Enabled

Stack-channel State
~~~~~
Interface          Status
-----
stack-port 1/0     up
stack-port 1/1     up
```

Also, you may check the 'Master' LED indicator on the PP4X front panel – it should be solid green.

Step 3. Disconnect all optical and electric patch cords from the module to be replaced. Also, make sure to protect the connectors with the dust caps.

Step 4. Remove all SFP transceivers from the PP4X module. SFP transceiver removal procedure is described in details in section [SFP transceivers replacement](#).

Step 5. Remove the screws located on the module ejectors. Push the bottom ejector down and pull the top ejector up. Pull out the module and remove it from the chassis, [Figure 47](#).

Step 6. Install a new PP4X module in reversed order, [Figure 47](#).

- ⚠ To prevent the board damage, install/remove boards to/from the chassis carefully, do not apply any force.**
Do not allow the components of the board being installed to touch the board installed next to it.
If the board meets resistance while sliding through the guides, remove the board and try to install it again.
After all modules has been installed into the rack, secure the connection with screws, see [Figure 47](#).

Step 7. Install SFP transceivers back into the PP4X module. SFP transceiver installation procedure is described in details in section [SFP transceivers replacement](#).

Step 8. Reconnect optical and electric patch cords according to the wiring documentation.

Step 9. Check the state of PP4X module using the **show stack** command.

Step 10. If necessary, change the master module back with the **stack master change** command.

48 GPON PLC8 interface module replacement

You can replace the PLC8 modules without actual shutdown of the access node.

Step 1. Disconnect all optical patch cords from the module to be replaced. Also, make sure to protect the connectors with the dust caps.

Step 2. Remove all SFP transceivers from the PLC8 module. SFP transceiver removal procedure is described in details in section [SFP transceivers replacement](#).

Step 3. Remove the screws located on the module ejectors. Push the bottom ejector down and pull the top ejector up. Pull out the module and remove it from the chassis, [Figure 47](#).

Step 4. Install a new PLC8 module in reversed order, [Figure 47](#).




Figure 47 – Installing board into MA4000-PX

- ❗ **To prevent the board damage, install/remove boards to/from the chassis carefully, do not apply any force.**
Do not allow the components of the board being installed to touch the board installed next to it.
If the board meets resistance while sliding through the guides, remove the board and try to install it again.
After all modules has been installed into the rack, secure the connection with screws, see [Figure 47](#).

Step 5. Install SFP transceivers back into the PLC8 module. SFP transceiver installation procedure is described in details in section [SFP transceivers replacement](#).

Step 6. Reconnect optical patch cords according to the wiring documentation.

Step 7. Check the state of PLC8 module using the **show shelf** command. Replaced module should be in the **Operational** state:

```
ma4000# show shelf
```

```
Shelf status
```

```
~~~~~
```

Slot#	Configured Type	Detected Type	Version	Serial #	Link State	Slot State
0	plc8	plc8	3.26.3.83	OL04001768	up	Operational
1	none	none	0.0.0.0		down	Absent
2	none	none	0.0.0.0		down	Absent
3	none	none	0.0.0.0		down	Absent
4	none	none	0.0.0.0		down	Absent
5	none	none	0.0.0.0		down	Absent
6	none	none	0.0.0.0		down	Absent
7	none	none	0.0.0.0		down	Absent
8	none	none	0.0.0.0		down	Absent
9	none	none	0.0.0.0		down	Absent
10	none	none	0.0.0.0		down	Absent
11	none	none	0.0.0.0		down	Absent
12	none	none	0.0.0.0		down	Absent
13	none	none	0.0.0.0		down	Absent
14	none	none	0.0.0.0		down	Absent
15	none	none	0.0.0.0		down	Absent

49 SFP transceivers replacement

SFP transceivers can be installed when the device is turned on or off.

Step 1. Insert an SFP transceiver into a slot. SFP transceivers are set as shown in [Figure 48](#).




Figure 48 – SFP transceivers installation

Step 2. Push the module. When it is in place, you should hear a distinctive 'click'.




Figure 49 – Installed SFP transceivers

To remove a transceiver, perform the following actions:

Step 1. Unlock the module's latch.




Figure 50 – Opening SFP transceiver latch

Step 2. Remove the module from the slot.




Figure 51 – SFP transceivers removal

50 PP4X firmware update

50.1 Firmware Update via CLI

50.1.1 Introduction

Firmware files are stored in the non-volatile memory (flash memory).

The flash memory can store up to two firmware files simultaneously. The first file is active and used at the device startup. The second file is a backup file. Storing two firmware files in flash memory allows to protect the device, if one of the files becomes corrupted for some reason.

Another active file can be chosen in the following circumstances:

- When the active firmware file corruption is detected;
- On the operator's command;
- When the device firmware update is performed;
- When the automatic roll back to the previous version of the firmware is activated .

To use new firmware version:

1. Copy the new device firmware file into the device flash memory;
2. Set this file as active firmware file;
3. Reboot the device.

Use CLI commands to perform these operations.

50.1.2 New firmware version installation procedure

- ✓ **If there are two devices installed in a rack, we strongly recommend to use the same firmware version on both devices. This way you will be able to perform the firmware update simultaneously on both devices.**

Firmware update procedure:

Step 1. Copy the firmware file located on the external TFTP server into the flash memory of the device using the **copy**¹ command:

Command format: `copy tftp://<ip>/<path> fs://firmware`

where

- <ip> – TFTP server IP address;
- <path> – file path on TFTP server.

Step 2. Set the inactive firmware file as active using the **firmware select image-alternate unit**¹ command:

Command format: `firmware select image-alternate unit <unit>`

where <unit> is the PP4X module number; possible values [1-2].

If the firmware file has been copied into the flash memory of both devices at Step 1, you have to enter this command twice and pass numeric values 1 or 2 as the <unit> parameter.

Step 3. Reboot devices with updated firmware:

- If the firmware has been updated on both devices, enter the **reboot system**¹ command
- If the firmware has been updated only on one of the devices and this device is the stack master, enter the **reboot master**¹
- If the firmware has been updated only on one of the devices and this device is the stack slave, enter the **reboot slave**¹

You may also use the **reboot system** command for cases 'b' and 'c'. However, note that the **reboot system** command reboots the entire device.

Step 4. Make sure that the new firmware version is working correctly after devices' startup.

Use the **show firmware**¹ command to check the state of the firmware file installed during Steps 1-3 – it should be in 'TESTING' state:

```
MA4000# show firmware

Firmware status:
~~~~~
Unit   Image   Running   Boot           Version          Date
-----
1      0        No        FALLBACK*     1 3 2 267 40378  03-Oct-2014 20:10:03
1      1        Yes       TESTING       1 3 2 323 40564  20-Oct-2014 20:12:02
2      0        Yes       TESTING       1 3 2 323 40564  20-Oct-2014 20:12:02
2      1        No        FALLBACK*     1 3 2 267 40378  03-Oct-2014 20:10:03

"*" designates that the image was selected for the next boot
MA4000#
```

Step 5. Confirm the successful completion of the firmware update with the **firmware confirm**¹ command:

Command format: `firmware confirm`

¹ Basic level command (ROOT), help string appearance: `ma4000#`

- ✓ **If the device has the new firmware version installed and the 'firmware confirm' command is not executed within 5 minutes after its startup, the device will be automatically rebooted. At that, the active firmware file (new firmware version) will be marked as inactive by the bootloader and the active firmware file (previous firmware version) will be marked as active. After that, the active firmware file will be loaded.**

50.1.3 Example of the new firmware version installation procedure

Source data:

- Firmware file is located on the TFTP server;
- TFTP server IP address 192.168.0.100;
- path to the firmware file on TFTP server: `pp4x/firmware.pp4x`;
- firmware update is required for devices with stack numbers 1 and 2.

Step 1. Copy the firmware file located on the external TFTP server into the flash memory of both devices:

```
copy tftp://192.168.0.100/pp4x/firmware.pp4x fs://firmware
```

Step 2. Configure the inactive firmware file as active:

```
ma4000# firmware select image-alternate unit 1
ma4000# firmware select image-alternate unit 2
```

Step 3. Reboot devices with updated firmware. Firmware update has been performed on both devices, thus you should reboot both devices:

```
ma4000# reboot system
```

Step 4. Make sure, that the firmware update has been completed successfully. Check contents of devices' flash memory:

```
MA4000# show firmware

Firmware status:
~~~~~
Unit   Image   Running   Boot           Version           Date
-----
1      0        No        *              1 3 2 267 40378   03-Oct-2014 20:10:03
1      1        Yes       *              1 3 2 323 40564   20-Oct-2014 20:12:02
2      0        Yes       *              1 3 2 323 40564   20-Oct-2014 20:12:02
2      1        No        *              1 3 2 267 40378   03-Oct-2014 20:10:03

"*" designates that the image was selected for the next bootMA4000#
```

Step 5. Confirm, that the firmware update has been completed successfully:

```
ma4000# firmware confirm
```

50.2 Firmware update via bootloader (U-Boot)

As a rule, firmware update is performed through the command line interface (CLI), provided by means of the device firmware.

If necessary, you can update the firmware via the command line interface, provided by means of the bootloader.

50.2.1 Firmware update via bootloader

Step 1. Connect the device (through the CONSOLE port) to PC with RS-232 (DB-9F) cable.

Step 2. Connect the device (one of the ports 0-5) to the TFTP server or the router, that will establish connection to TFTP server.

Step 3. Run the terminal emulation application on PC (HyperTerminal, TeraTerm) and perform the following actions:

- Select the corresponding serial port.
- Set the data transfer rate to 115200 baud.
- Specify the data format: 8 data bits, 1 stop bit, non-parity.
- Disable hardware and software data flow control.

Step 4. Turn the device on. Wait until the text "Autobooting in 3 seconds, press 'stop' for stop" appears on the PC screen. Enter the **stop** command. Make sure, that the command prompt is displayed on the screen ('PP4X>').

Step 5. Define TFTP server IP address:

```
set serverip <IP-addr>
```

Step 6. Define the device IP address:

```
set ipaddr <IP-addr>
```

✔ **Default IP address of the device is 192.168.0.2**

Step 7. Define the gateway IP address for access to TFTP server. If the device IP address and TFTP server IP address belong to different subnets:

```
set gatewayip <IP-addr>
```

Step 8. Make sure, that the device is successfully connected to TFTP server:

```
ping <IP-addr TFTP-server>
```

Step 9. If the connection was successful, you will see the following message:

```
host <IP-addr TFTP-server> is alive
```

Step 10. If there is no connection, you will see the following message:

```
ping failed; host <IP-addr TFTP-server> is not alive
```

✔ **Depending on the IP filtering settings of TFTP server, gateway or intermediate routers, connection test may result in 'ping failed' message, regardless of a working connection between TFTP server and the device.**

Step 11. Set the path to the firmware file on TFTP sever:

```
set fw_name <path>
```

By default, path to the firmware file on TFTP sever appears as follows: **pp4x/firmware.pp4x**.

Step 12. Copy the firmware file from TFTP server to the device flash memory and mark the firmware file as active:

```
run upgrade
```

Step 13. Wait until 'run upgrade' command finishes ('PP4X>' will appear).

✔ **Command execution time is approximately 90 seconds.**

Step 14. Make sure, that the following messages were shown during the **run upgrade** command execution:

```
2 of 2 kernel images successfully installed
2 of 2 filesystem images successfully installed
Firmware installation finished.
```

Step 15. Reboot the device:

```
reset
```

Step 16. Wait until the device startup procedure finishes. Log in (enter user name and password).

- ✔ **If the device configuration matches the default configuration, log in using the following data: user name – 'admin', password – 'password'.**

Step 17. Make sure, that the required firmware version is located in the device flash memory and defined as active, using the **show firmware** command.

50.2.2 Possible abnormal situations during the firmware upgrade via bootloader

50.2.2.1 The following message appears when the run upgrade command is entered:

```
Loading: T T T T T T T T T T
Retry count exceeded; starting again
```

Reason: TFTP server is not available.

Solution: Make sure, that TFTP server or intermediate equipment, such as routers, are configured and operating properly. Abort the **run upgrade** command execution; press <Ctrl+C>. Check, if 'serverip', 'ipaddr', 'gatewayip' parameters are defined correctly. Retry the **run upgrade** command execution.

50.2.2.2 The following message appears when the run upgrade command is entered:

```
ERROR: installing new firmware is allowed only in CURRENT state.
Type "image rollback" to switch to CURRENT state.
```

Reason: Firmware update attempt using the **boot system** command was taken earlier. At that, the 'confirmed' parameter has been specified, that matches the firmware update mode with the user confirmation request ('boot confirm') after the reboot.

Error message means that the reboot was not performed after the **boot system** command entry or that the confirmation was not received ('boot confirm').

Solution: Enter the **image rollback** command. Roll back to the previous firmware version will be performed: the active firmware file will be marked as inactive, and the inactive firmware file will be marked as active. After that, retry the **run upgrade** command execution.

51 PP4X firmware emergency recovery

After the user has specified the file with new firmware version as the active file and executed the device reboot command, the device will be loaded with the new firmware version. If you experience problems while operating with the new firmware version, you can use automatic rollback procedure, that allows you to restore the previous firmware version.

When device starts up with the new firmware version, it waits for the firmware update confirmation from the user with the following command: **firmware confirm**¹.

If the confirmation is not provided within 5 minutes after the device startup, it will be rebooted automatically, and will be rolled back to the previous firmware version on the next startup:

- ✔ **If the device operation is interrupted before executing the confirmation command (*firmware confirm*¹), the device will be rolled back to the previous firmware version on the next startup. Device operation may be interrupted for one of the following reasons:**
 - **User has executed the device reboot command;**
 - **Device power supply has been switched off;**
 - **Device has performed an emergency reboot.**

¹ Basic level command (ROOT), help string appearance: ma4000#

52 ONT firmware update

52.1 Introduction

This section describes different methods of ONT firmware update using the OMCI protocol.

52.2 Overview

Figure 52 shows the ONT firmware update infrastructure.




Figure 52 – ONT firmware update infrastructure

The 128 MB ONT firmware files storage is located at PP4X module. The maximum size of an ONT firmware file is 24 MB. When a file is stored in the storage, it can be used by PLC8 modules. See section [ONT firmware files management](#) for detailed description of file management schemes for ONT firmware.

At the start of the ONT firmware update the firmware file is copied to the cache of PLC8 module. This takes about 1-2 minutes. Then an update stream transfers the file to ONT in small parts via OMCI. File transfer takes more time – usually about 10 minutes for a 16 MB file with window size of 96 kB. Thus, the firmware update for an ONT may totally take up to 12 minutes.

When the update is completed, the update file is not removed from the cache and can be used again later. This reduces the time required for further updates. However, the file can be replaced when both caches are full and a new firmware file should be used. To be replaced, the file should not be used by any update streams. If there are no unused files, the update operation will be put in a queue. It means that up to 4 ONTs with different firmware files can be simultaneously updated for each PLC8 module.

An access node can also update ONT firmware automatically. To control the mode, the following settings are provided. See section [ONT firmware auto update configuration](#) for description. There are two ONT auto update modes.

The *immediate* mode allows all ONTs to be updated within the shortest possible time because they are updated one by one. The mode's disadvantage is the necessary ONT reboot after activation of a new firmware image and, consequently, possible interruptions in operation of services.

The *postpone* mode is more delicate: a new update is performed only after the previously updated ONT firmware has been activated. User does not encounter any occasional difficulties with services operation. This mode may take more time to update all ONTs.

A decision to launch ONT update is made based on auto update rules. Every auto update rule contains the following information:

- unique rule name, which allows rule modification;
- ONT type (the Equipment-ID field);
- firmware version¹, which indicates that the firmware should be updated;
- name of the file from the ONT firmware files storage that should be used for update;
- rule scope: global or local.

ONT firmware auto update can be activated/deactivated based on global or local rules. For more details on auto update rules see section [ONT auto update rules](#).

¹ Firmware version field allows negation, i. e. the use of the prefix "!". This allows using of complex rules such as: if firmware version is not equal 1.2.3, use the 1_2_3.bin file for update.

52.3 ONT firmware files management

To download the firmware file, use the **copy** command and specify the file name and the address of the TFTP server as parameters:

```
ma4000# copy tftp://192.168.1.100/ntp-rg-d3.20.2.169.fw.bin fs://ont-firmware Download file
from TFTP-server..
.....
.....
ONT firmware vendor is Eltex Corporation, version 3.20.2.169 Write downloaded file to flash
memory..
.....
.....
```

Being downloaded, the ONT firmware file is moved to ONT firmware files storage in PP4X and can be used by PLC8 modules.

Use the **show firmware ont** command to view the content of the ONT firmware files storage in PP4X:

```
ma4000# show firmware ont

ONT firmware images:
~~~~~
#      Filename                                     Version                                     Hardware
-----
1      ntp-rg-revb-d3.20.2.174.fw.bin
-----
2      ntp-rg-revb-d3.20.2.170.fw.bin
-----
3      ntp-rg-d3.20.2.169.fw.bin
-----
4      ntp-rg-d3.20.2.165.fw.bin
-----
```

To remove a firmware file, use the **firmware ont delete image** command with the file's name:

```
ma4000# firmware ont delete image ntp-rg-d3.20.2.165.fw.bin
Firmware deleting finished.
```

52.4 ONT firmware manual update

This method is used to update the ONTs which are activated at the time of update.

To perform a forced update of an ONT, use the **update ont** command with the ONT's ID and name of the ONT firmware file available in PP4X storages:

```
ma4000# update ont 0/0 ntp-rg-r3.20.2.123.fw.bin
Task for updated successfully created. ONT firmware will be updated in 20 minutes or more
```

A task will be created to update the ONT firmware with the specified ID. The task will end with an error for the ONTs, which are not connected.

52.5 ONT firmware auto update configuration

52.5.1 ONT auto update modes

ONT auto update has two modes: immediate and postpone.

Step 1. Activate the update mode by the **firmware ont auto update** command:

```
ma4000# firmware ont auto update postpone
```

Step 2. Apply the changes by using the **commit** command:

```
ma4000# commit
```

You can view the configured mode with the help of the **show firmware ont auto update state** command:

```
ma4000# show firmware ont auto update state
Auto-update ONT: postpone
```

Step 3. To disable the ONT firmware auto update, use the **no firmware ont auto update enable** command:

```
ma4000# no firmware ont auto update enable
```

52.5.2 ONT auto update rules

Step 1. Use the **firmware ont auto update add command to add a new auto update rule**. Specify the rule's unique name, ONT type (Equipment-ID), firmware version to be updated, name of the file in the ONT firmware files storage to be used in the update, and the mode as parameters:

```
ma4000# firmware ont auto update add name2 NTP-RG 1.1.1 filename global
```

Step 2. To display the list of auto update rules, use the **show firmware ont auto update entries** command:

```
ma4000# show firmware ont auto update entries

Description  EquipmentID  FWVersion  FileName  Mode
Rule1|NTP-RG-1402G-W|3.20.2.123|ntp-rg-d3.20.2.124.fw.bin|global
Rule2|NTP-RG-1402G-W|3.20.2.124|ntp-rg-d3.20.2.125.fw.bin|global
```

Step 3. Use the **firmware ont auto update delete** command to remove an auto update rule:

```
ma4000# firmware ont auto update delete Rule1
```

53 APPENDIX A. Configuring services on ONT Ericsson, Atron, CIG

53.1 Introduction

Starting with version 3.30.0, ONT support has been added for Ericsson T063G, Ericsson T073G, Atron RFT620, Atron PSG590, CIG G-25A-J80. In setting up services on these ONTs, there are some features presented below.

53.2 VoIP configuration

To configure VoIP, you need to create two new profiles: cross-connect type voice, profile voice.

Step 1. Create required profiles:

```
MA4000(config)# profile cross-connect "VOICE-ERCS"
MA4000(config-cross-connect)("VOICE-ERCS")# description "For VOICE ont Ericsson"
MA4000(config-cross-connect)("VOICE-ERCS")# bridge
MA4000(config-cross-connect)("VOICE-ERCS")# bridge group "5"
MA4000(config-cross-connect)("VOICE-ERCS")# outer vid 354
MA4000(config-cross-connect)("VOICE-ERCS")# user vid 354
MA4000(config-cross-connect)("VOICE-ERCS")# type "voice"
MA4000(config-cross-connect)("VOICE-ERCS")# exit
MA4000(config)#
MA4000(config)# profile voice "voice-00-ERCS"
MA4000(config-voice)("voice-00-ERCS")# sip proxy "123.test.ru"
MA4000(config-voice)("voice-00-ERCS")# sip outbound-proxy "172.20.20.201"
MA4000(config-voice)("voice-00-ERCS")# sip domain "123.test.ru"
MA4000(config-voice)("voice-00-ERCS")# exit
```

Step 2. Assign profiles to ONT and configure additional VoIP data:

```
MA4000(config)# interface ont 0/2
MA4000(config)(if-ont-0/2)# service 0 profile cross-connect "VOICE-ERCS" dba "dba-00"
MA4000(config)(if-ont-0/2)# profile voice "voice-00-ERCS"
MA4000(config)(if-ont-0/2)# voice port 0 number "402153"
MA4000(config)(if-ont-0/2)# voice port 0 authentication username "402153"
MA4000(config)(if-ont-0/2)# voice port 0 authentication password "QFxy2EzfVdrL1"
```

Step 3. If necessary, configure Value Added Services for the ONT:

```
MA4000(config)(if-ont-0/2)# voice fax-mode t38
MA4000(config)(if-ont-0/2)# voice features call-presentation special-dialtone
MA4000(config)(if-ont-0/2)# voice features call-presentation visual
MA4000(config)(if-ont-0/2)# voice features call-presentation call-forward
MA4000(config)(if-ont-0/2)# voice features call-progress 3way
MA4000(config)(if-ont-0/2)# voice features call-progress transfer
MA4000(config)(if-ont-0/2)# voice features call-progress hold
MA4000(config)(if-ont-0/2)# voice features call-progress park
MA4000(config)(if-ont-0/2)# voice features call-progress emergency-hold
MA4000(config)(if-ont-0/2)# voice features call-progress 6way
MA4000(config)(if-ont-0/2)# voice features call-wait enable
MA4000(config)(if-ont-0/2)# voice features call-wait call-id-announce
MA4000(config)(if-ont-0/2)# voice features cid call-number
MA4000(config)(if-ont-0/2)# voice features cid call-name
MA4000(config)(if-ont-0/2)# voice features cid cid-number
MA4000(config)(if-ont-0/2)# voice features cid cid-name
```

Step 4. Apply changes:

```
MA4000(config)(if-ont-0/2)# do commit
```

TECHNICAL SUPPORT

For technical assistance in issues related to handling Eltex Ltd. equipment, please, address to Service Center of the company: <https://eltex-co.com/support/>

You are welcome to visit Eltex official website to get the relevant technical documentation and software, to use our knowledge base or consult a Service Center Specialist in our technical forum.

Official website: <https://eltex-co.com/>

Download center: <https://eltex-co.com/support/downloads/>